

Alohappy Fluted Dresser-5/6


Alohappy Fluted 6-Drawer Dresser with Charging Station User Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Alohappy Fluted 6-Drawer Dresser with Charging Station. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

IMPORTANT SAFETY INFORMATION

- Always secure the dresser to the wall using the anti-tipping device to prevent tipping and potential injury. This is crucial for household safety, especially in homes with children or pets.
- Ensure all screws and fasteners are tightened securely during assembly. Periodically check for loose connections and tighten as needed.
- Do not overload drawers. Distribute weight evenly to maintain stability.
- Keep liquids away from the integrated charging station to prevent electrical hazards.



PRODUCT OVERVIEW

The Alohappy Fluted 6-Drawer Dresser is designed for versatile storage and includes a convenient charging station. Its mid-century modern aesthetic features fluted side panels, fluted drawers, and tapered solid wood legs.



Image: Alohappy Fluted 6-Drawer Dresser in a bedroom setting

Key Features:

- **Six Spacious Drawers:** Equipped with metal slide rails for smooth operation, ideal for storing clothing, blankets, and other items.
- **Integrated Charging Station:** Features 1 Type-C port, 1 USB port, and 2 standard AC outlets for convenient device charging.
- **Durable Construction:** Built with a wood frame, metal handles, and 5 solid wood legs. Includes an anti-tipping device for enhanced stability.
- **Curved Profile Design:** Rounded sides and corners help prevent accidental bumping.



Image: Dresser with drawers open, showcasing storage space

ASSEMBLY INSTRUCTIONS

The Alohappy Fluted 6-Drawer Dresser is designed for straightforward assembly. All necessary tools, step-by-step instructions, and numbered accessories are included in one package.

Before You Begin:

- Unpack all components and verify against the parts list provided in the instruction manual. Ensure no parts are missing or damaged.
- Clear a spacious area for assembly to prevent damage to the product or your flooring.
- It is recommended to have two people for assembly due to the size and weight of the dresser.

Assembly Steps:

Follow the detailed, numbered instructions provided in the included assembly guide. Pay close attention to diagrams for correct orientation of parts.

Key Assembly Points:

- **Drawer Slides:** Ensure metal slide rails are installed correctly for smooth drawer operation. Incorrect installation can

cause drawers to stick.

- **Anti-Tipping Device:** Install the anti-tipping device as instructed. This device secures the dresser to the wall, preventing accidental tipping. This step is critical for safety.
- **Charging Station:** Integrate the charging station according to the instructions. Ensure all connections are secure before plugging into a power outlet.




Image: Easy Assembly with Numbered Parts

OPERATING THE CHARGING STATION

Your dresser is equipped with a built-in charging station for convenient power access.

Features:

- 2 Standard AC Outlets (125V/12A)
- 1 USB Port (5V/2A)
- 1 USB-C Port (5V/2A)
- 4.92-Foot Power Cord

Usage:

- Plug the dresser's power cord into a standard wall outlet.
- Connect your devices (e.g., TV, smartphone, tablet) to the appropriate AC, USB, or USB-C ports on the charging station.
- Ensure devices are compatible with the provided voltage and amperage.



50+
T-shirts



30+
Pants



60+
Socks



30+
Hat



30+
Toys



30+
Dresses



20+
Diapers



30+
Scarf

Image: Built-in Charging Station Detail

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Dust regularly with a soft, dry cloth. For spills, wipe immediately with a slightly damp cloth and dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Drawer Function:** Periodically check drawer slides for smooth operation. If drawers become stiff, a silicone-based lubricant can be applied to the slides.
- **Stability:** Regularly inspect all fasteners and the anti-tipping device to ensure they remain tight and secure.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood finish.

TROUBLESHOOTING

This section addresses common issues you might encounter.

Drawers Do Not Slide Smoothly:

- **Check Assembly:** Ensure drawer slides are installed correctly and are not bent or obstructed.
- **Lubrication:** Apply a small amount of silicone lubricant to the drawer slides.

- **Overload:** Reduce the weight in the drawer if it is overloaded.

Dresser Appears Unstable:

- **Check Fasteners:** Ensure all assembly screws are fully tightened.
- **Anti-Tipping Device:** Verify that the anti-tipping device is securely installed to the wall and the dresser.
- **Level Surface:** Ensure the dresser is placed on a flat, level surface.

Charging Station Not Working:

- **Power Connection:** Confirm the dresser’s main power cord is securely plugged into a functional wall outlet.
- **Device Compatibility:** Ensure your device is compatible with the charging station's output specifications (voltage/ampereage).
- **Overload Protection:** If multiple high-power devices are connected, the charging station may temporarily shut off. Unplug devices and try again.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Alohappy
Model Name	Fluted Dresser-5/6
Product Dimensions	17.7"D x 57"W x 31.5"H
Color	Walnut
Room Type	Bedroom, Living Room, Hallway, Entryway, Home Office
Furniture Finish	Walnut
Drawer Type	Standard, with metal slide rails
Assembly Required	Yes
Item Weight	119 Pounds
Charging Station	1 Type-C Port, 1 USB Port, 2 Standard AC Outlets
Power Cord Length	4.92 Feet
Max Weight Capacity (Top Surface)	220 lbs
Max Weight Capacity (Per Drawer)	25 lbs

PRODUCT SIZE



max weight
capacity



Slight color difference may exist vary from different light effect to device.

Image: Product Dimensions and Weight Capacities

WARRANTY AND CUSTOMER SUPPORT

Warranty Information:

Alohappy offers free parts replacement for any defective part within 12 months from the date of purchase.

Customer Support:

If you have any questions regarding assembly, missing parts, damages, or require further assistance, please contact Alohappy customer service. We aim to respond within 24 hours.

- Refer to the instruction manual for detailed contact information.
- For online support, visit the [Alohappy Store on Amazon](#).



Image: Customer Support and Service Information