Bellemave GZZ000078DFQ

Bellemave Full XL Over Queen Bunk Bed Frame Instruction Manual

Model: GZZ000078DFQ

1. Introduction

Thank you for choosing the Bellemave Full XL Over Queen Bunk Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information:

- Do not exceed the weight capacity of **400 lbs** for the upper bed and **600 lbs** for the lower bed.
- Always use the built-in ladder to access the upper bed.
- Ensure all connections are securely tightened before use.
- This bunk bed is designed for adults, teens, and kids, but adult supervision is recommended for younger users.
- The product will arrive in two separate boxes.

2. Product Overview

The Bellemave Full XL Over Queen Bunk Bed Frame is constructed from heavy-duty metal, designed for durability and stability. It features a noise-reduced design and a built-in ladder for convenient access to the upper bunk. The low bunk design increases the activity space between the upper and lower beds, reducing the risk of head bumps.



Image 2.1: The Bellemave Full XL Over Queen Bunk Bed Frame, showcasing its design and integrated ladder.

Key Features:

- **Sturdy Construction:** Made from heavy-duty metal with thickened steel pipes and slats for enhanced weight capacity and long-term use.
- **Noise-Reduced Design:** Equipped with noise-reducing rubber stoppers to firmly fix slats and prevent movement-related noise.
- **Safety Certified:** Certified by the Children's Product Certificate (CPC), featuring heightened guardrails and a reinforced built-in ladder.
- **Space-Saving:** Combines two beds into one compact unit, ideal for maximizing space in smaller rooms.*Note: This bunk bed cannot be separated into two individual beds.*




Image 2.2: Detailed view of the bunk bed's construction, highlighting metal slats, noise-reducing rubber stoppers, and thickened steel pipes.

3. Specifications

Feature	Detail
Model Number	GZZ000078DFQ
Size	Full XL over Queen
Product Dimensions (L x W x H)	82.6" x 63" x 57.4"
Upper Bed Weight Capacity	400 lbs
Lower Bed Weight Capacity	600 lbs
Material	Metal (Powder Coated)
Color	Black Floor Bed
Compatible Mattress Size	Full, XL, Queen (No Box Spring Needed)
Height Between Beds	48.8"
Included Components	Headboard, Slats
Item Weight	42 pounds




Image 3.1: Detailed dimensions of the bunk bed frame.

4. Setup and Assembly

Assembly of the Bellemave Full XL Over Queen Bunk Bed Frame is required. The product comes with detailed instructions and all parts are numbered for convenience. While assembly is designed to be straightforward, it is recommended to have two people for the initial steps to ensure ease and safety.

Assembly Steps:

1. Unpack all components and verify against the parts list provided in the separate assembly guide.
2. Follow the step-by-step instructions in the included assembly manual.
3. Ensure all screws and bolts are tightened securely at each stage.
4. Do not fully tighten all fasteners until the entire frame is assembled to allow for minor adjustments.
5. Once assembled, re-check all connections for tightness.



Image 4.1: An assembled Bellemave bunk bed frame, ready for use.

5. Operating and Usage

This bunk bed is designed for sleeping and resting. Adhere to the following guidelines for safe operation:

- Always use the built-in ladder for climbing to and from the upper bunk. Do not jump on or off the bed.
- Ensure mattresses are of appropriate size and thickness to maintain the effectiveness of the guardrails.
- Do not attach or hang items on any part of the bunk bed that are not designed for use with the bed, such as ropes, belts, or other items that could pose a strangulation hazard.
- Periodically check all connections and fasteners to ensure they remain tight.



Image 5.1: View of the lower bed's high fence and the clearance between the upper and lower bunks.

6. Maintenance

Proper care and maintenance will extend the life of your bunk bed frame.

- **Cleaning:** Wipe with a damp cloth to clean. Avoid using harsh chemicals or abrasive materials. Do not submerge in water.
- **Regular Checks:** Periodically inspect all bolts, screws, and connections to ensure they are tight. Re-tighten as necessary.
- **Environmental Conditions:** Avoid exposing the bed to extreme temperatures or humidity, which can affect the metal finish.

7. Troubleshooting

Common Issues and Solutions:

- **Squeaking Noise:** If the bed makes squeaking noises, check all connections and ensure they are tightly secured. Verify that the noise-reducing rubber stoppers are correctly installed on the slats.
- **Bed Wobbles:** If the bed feels unstable or wobbles, ensure all assembly screws and bolts are fully tightened. A second check of all connections after initial assembly can often resolve this.
- **Missing Parts:** If any parts are missing upon delivery, please contact customer support immediately.

8. Warranty and Support

Bellemave is committed to providing quality products. For any issues, questions, or concerns regarding your bunk bed frame, please contact our customer support team.

- **Customer Support Email:** US-VC@bellemavehome.com
- **Returns:** This product is eligible for 90-day easy returns. Please refer to your purchase documentation for specific return policies.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question