

INIU P73

INIU MagSafe Portable Charger User Manual

Model: P73

1. INTRODUCTION

Thank you for choosing the INIU MagSafe Portable Charger. This user manual provides essential information for the safe and efficient operation of your new power bank. Please read this manual thoroughly before use and retain it for future reference.

2. PRODUCT OVERVIEW

2.1. Package Contents

- INIU 10,000mAh Magnetic Power Bank (P73) x 1
- 0.4ft/12cm Lanyard USB-C Cable x 1
- User Manual x 1

2.2. Key Features

- Ultra-slim 0.5-inch design for portability.
- Qi2-Certified 15W wireless charging.
- Speedy PD 45W wired charging via USB-C.
- 10,000mAh capacity providing extended power.
- Integrated foldable kickstand for hands-free viewing.
- Lanyard USB-C cable for convenience.
- Multiple safety protections.

2.3. Product Diagram

Below is a diagram illustrating the main components of your INIU MagSafe Portable Charger.



Figure 1: INIU MagSafe Portable Charger (Black) with a phone attached, highlighting its compact design and the included lanyard USB-C cable.

Market's Slimmest

10000mAh Magnetic Power Bank



Figure 2: Side profile of the power bank demonstrating its ultra-slim 0.5-inch thickness.

3. SETUP

3.1. Initial Charge of the Power Bank

Before first use, fully charge your INIU MagSafe Portable Charger. Use the included USB-C cable and a compatible power adapter (not included) to connect the power bank to a power source.

1. Connect the small end of the USB-C cable to one of the USB-C ports on the power bank.
2. Connect the large end of the USB-C cable to a USB power adapter.
3. The LED indicator lights will illuminate to show charging progress. A full charge is indicated when all lights are solid.



Figure 3: LED indicator lights showing charge status. Each segment represents approximately 20% charge.

4. OPERATING INSTRUCTIONS

4.1. Charging Devices Wirelessly (MagSafe Compatible)

The power bank supports 15W Qi2 wireless charging for compatible devices, such as iPhone 12-16 series and AirPods 3/Pro 2.

1. Ensure your device is MagSafe compatible or has a MagSafe-compatible case.
2. Align the back of your device with the magnetic charging area of the power bank. The magnets will snap into place, and charging will begin automatically.
3. The LED indicator on the power bank will show charging activity.

Qi2-Certified 15W Fastest Wireless Charging

2X Faster



INIU Qi2 15W



25min

Other 7.5W



Figure 4: Wireless charging in progress, demonstrating the magnetic connection.

Video: INIU Ultra Slim Qi2 Certified 10000mAh 45W Magnetic Power Bank. This video demonstrates the magnetic attachment and wireless charging capabilities of the power bank.

4.2. Charging Devices via USB-C Cable

The power bank features two USB-C ports for wired charging, supporting up to 45W Power Delivery (PD).

1. Use the included lanyard USB-C cable or another compatible USB-C cable.

2. Connect one end of the cable to a USB-C port on the power bank.
3. Connect the other end to your device's charging port.
4. Charging will begin automatically.

45W Fast Charging

with Lanyard USB-C Cable



USB-C
Cable included

27min

50%



Power 3 Devices at Once

1*Wireless + 2*USB-C



*Data based on internal testing, charging an iPhone 16 from 0% to 50% in 27 minutes.

Figure 5: Wired charging using the integrated lanyard USB-C cable.

4.3. Using the Foldable Kickstand

The integrated kickstand allows for hands-free viewing in both portrait and landscape orientations.

1. Gently pull out the kickstand from the back of the power bank.
2. Position the power bank and attached device on a flat surface.
3. Adjust the angle for optimal viewing.

Vast Compatibility



✓ Magnetic Cases



✗ Non-Magnetic Cases



✓ iPhone 12-16 Series



✓ AirPods 3 / Pro 2



Figure 6: Power bank with kickstand in use, supporting a phone for hands-free viewing.

5. MAINTENANCE

- Keep the power bank away from extreme temperatures, direct sunlight, and liquids.
- Do not disassemble, modify, or attempt to repair the device.
- Clean the surface with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use for extended periods.
- Avoid dropping or subjecting the power bank to strong impacts.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging.	Cable not properly connected; faulty cable/adapter; power bank fully discharged.	Ensure cable is securely connected. Try a different cable or power adapter. Allow a few minutes for the power bank to respond if deeply discharged.
Device not charging wirelessly.	Misalignment; non-compatible device/case; foreign objects between power bank and device.	Ensure proper alignment. Verify device/case is MagSafe compatible. Remove any foreign objects.
Device not charging via wired connection.	Cable not properly connected; faulty cable/device port.	Ensure cable is securely connected. Try a different USB-C cable. Test with another device if possible.
Slow charging speed.	Using a non-fast charging adapter/cable; device not supporting fast charging; multiple devices charging simultaneously.	Use a PD-compatible adapter and cable. Ensure your device supports fast charging. Charging multiple devices may reduce individual charging speeds.

7. SPECIFICATIONS

Feature	Detail
Model Number	P73
Battery Capacity	10,000 mAh
Wireless Charging Output	Up to 15W (Qi2 Certified)
Wired Charging Output	USB Type-C x 2, up to 45W PD

Feature	Detail
Dimensions	4.1 x 2.8 x 0.5 inches
Weight	8.1 ounces
Special Features	LED Indicator Lights, Fast Charging, Pocket Size, Lanyard USB-C Cable, Foldable Kickstand

8. WARRANTY AND SUPPORT

INIU provides an industry-leading 3-year warranty for this product, along with lifetime technical support. For any inquiries or support needs, please contact INIU customer service through their official website or the platform where you purchased the product.
Website: www.iniu.com

© 2025 INIU. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

