

COREPLAY LT004

Crazy Figure 1/12 Scale Female Body with Head Sculpt LT004 Instruction Manual

Model: LT004 | Brand: COREPLAY

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Crazy Figure 1/12 Scale Female Body with Head Sculpt LT004 action figure. This product is designed for collectors and enthusiasts, offering high poseability and customization options. Please read this manual thoroughly before handling the figure to ensure proper use and longevity.

SAFETY INFORMATION

Warning: This product contains small parts and is not suitable for children under 3 years old due to choking hazards. Recommended for ages 15 and up. Handle with care to avoid damage to delicate parts.

PARTS LIST

Before assembly, please verify that all components listed below are present in your package:

- Girl head sculpt: 1 unit
- Replaceable front hair: 1 unit
- Body: 1 unit
- Big chest: 1 unit
- Middle chest: 1 unit
- Small chest: 1 unit
- Bare hand type: 16 units (various poses)
- Glasses: 1 unit
- Telesports Shoes: 2 units (1 pair)
- Blue vest: 1 unit
- Blue sweatpants: 1 unit



Figure 1: Complete set of components included with the LT004 action figure.

SETUP AND ASSEMBLY

Follow these steps to assemble your action figure:

1. **Attach Head Sculpt:** Gently align the neck peg of the body with the socket in the head sculpt. Apply gentle, even pressure to secure it.
2. **Interchangeable Chests:** The figure comes with three different chest sizes (big, middle, small). To change, carefully pull the current chest piece off the torso. Align the desired chest piece with the pegs on the torso and press firmly until it clicks into place.
3. **Hand Replacement:** The figure includes 16 different hand types for various poses. To replace hands, gently pull the existing hand from the wrist joint. Align the new hand with the wrist peg and push it in until it is secure. Avoid excessive force to prevent damage to the pegs.
4. **Attaching Clothing:** Carefully dress the figure with the blue vest and blue sweatpants. Ensure the clothing fits smoothly over the figure's body without excessive stretching.
5. **Wearing Shoes:** Place the Telesports Shoes onto the figure's feet.
6. **Glasses:** The glasses can be carefully placed onto the head sculpt.



Figure 2: The figure demonstrating a seated, flexible pose.



Figure 3: The figure in a kneeling pose, highlighting articulation.

OPERATING AND POSING

The Crazy Figure LT004 is designed with multiple articulation points to allow for a wide range of dynamic poses. Exercise caution and gentle force when posing the figure to prevent damage to joints or parts.

- **Joint Movement:** The figure features articulated joints at the neck, shoulders, elbows, wrists, torso, hips, knees, and ankles. These joints allow for bending, rotating, and swiveling movements.
- **Dynamic Posing:** Experiment with different joint positions to achieve desired poses. For example, the figure can perform running, jumping, sitting, and various action stances.
- **Interchangeable Parts:** Utilize the different hand types and chest pieces to further customize the

figure's appearance and expression for specific poses.



Figure 4: The figure in an action pose, demonstrating its flexibility with clothing.



Figure 5: The figure performing a ballet pose, highlighting range of motion.



Figure 6: The figure demonstrating extreme flexibility with a high kick.



Figure 7: The figure in a yoga pose, showcasing flexibility with clothing.



Figure 8: The figure in a running pose, complete with clothing and shoes.

MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to gently wipe the figure to remove dust. For stubborn dirt, a slightly damp cloth can be used, but avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent material degradation and discoloration.
- **Handling:** Always handle the figure by its main body parts. Avoid pulling or twisting limbs with excessive force, especially at the joints, to prevent breakage.
- **Small Parts:** Keep all small interchangeable parts in a secure container to prevent loss.

TROUBLESHOOTING

- **Loose Joints:** If a joint becomes loose over time, a small amount of clear nail polish or a specialized joint-tightening fluid can be applied to the peg and allowed to dry before reassembly. Apply sparingly.
- **Stiff Joints:** If a joint is too stiff, gently warm the area with a hairdryer on a low setting for a few seconds to make the plastic more pliable. Do not overheat.
- **Difficulty Attaching Parts:** Ensure parts are correctly aligned before applying pressure. If a part is difficult to attach, check for any obstructions or excess material. Gentle warming may also help.
- **Lost Parts:** Refer to the "Parts List" section to identify any missing components. Contact customer support if essential parts are missing from a new package.

SPECIFICATIONS

Model Number	LT004
Brand	COREPLAY
Product Dimensions	5 x 5 x 5 inches (approximate)
Item Weight	3 pounds (approximate)
Material	ABS, PVC
Recommended Age	15 years and up (Manufacturer's general recommendation: 75 years and up)
ASIN	B0DMPFX51H

CUSTOMER SUPPORT

If you have any questions about the product, require assistance with assembly, or encounter any issues not covered in this manual, please contact COREPLAY customer support. We are committed to providing excellent service.

For inquiries, please refer to the contact information provided on the product packaging or the retailer's website where the product was purchased.

Note: Please retain your proof of purchase for any warranty or support claims.