

[Manuals.plus](#) /

› [Hikiddo](#) /

› Hikiddo 24V 4WD Kids UTV 2 Seater Ride-On Toy Car Instruction Manual

Hikiddo B0DMPGR93W

Hikiddo 24V 4WD Kids UTV 2 Seater Ride-On Toy Car Instruction Manual

Model: B0DMPGR93W | Brand: Hikiddo

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Hikiddo 24V 4WD Kids UTV 2 Seater Ride-On Toy Car. Please read all instructions carefully before use to ensure proper function and safety.

The Hikiddo UTV is designed for children aged 3-8 years, supporting a maximum load capacity of 110 lbs. It features a 24V 10Ah battery, four 200W motors, and switchable 2WD/4WD modes for varied terrain. It includes both manual and parental remote control options, along with entertainment features like Bluetooth connectivity and integrated lights.



Figure 1: Front view of the Hikiddo 24V 4WD Kids UTV 2 Seater Ride-On Toy Car. This image displays the vehicle's robust design, large wheels, and front bumper.

2. IMPORTANT SAFETY WARNINGS

- **Adult Supervision Required:** Always supervise children during operation.
- **Age and Weight Limits:** Suitable for children 3-8 years old. Maximum weight capacity is 110 lbs. Do not exceed these limits.
- **Seat Belts:** Ensure all occupants are securely fastened with the provided seat belts.
- **Operating Environment:** Use on flat, dry surfaces away from roads, steep inclines, swimming pools, or other water hazards. Avoid operating in wet conditions or on loose terrain that could cause loss of control.
- **Protective Gear:** Always wear appropriate safety gear, such as helmets, when operating the vehicle.
- **Charging:** Only use the provided charger. Do not overcharge the battery.
- **Modifications:** Do not modify the vehicle or its components. Unauthorized modifications can lead to injury and void the warranty.

3. PACKAGE CONTENTS

Before assembly, verify that all parts listed in the owner's manual are present and undamaged. Contact customer support immediately if any parts are missing or defective.



Figure 2: An overview of the Hikiddo UTV components as they appear upon unboxing, including the main body, wheels, steering wheel, and various accessories.

4. SETUP AND ASSEMBLY

Adult assembly is required. Follow the steps below for proper setup.

1. **Unboxing and Inspection:** Carefully remove all components from the packaging. Inspect for any damage or missing parts.
2. **Wheel Assembly:** Attach the wheels to the axles, ensuring all washers and nuts are securely fastened.
3. **Steering Wheel Installation:** Connect the steering wheel's electrical wires and then secure the steering wheel to the steering column.
4. **Seat Installation:** Place the seats into the designated slots and secure them with screws.
5. **Roll Bar and Lights:** Attach the roll bar and any auxiliary lights, ensuring all connections are firm.
6. **Battery Connection:** Connect the battery terminals as instructed in the manual. Ensure the main power switch is in the OFF position before connecting.

Video 1: Installation Video of Hikiddo 24V 4WD Kids UTV 2 Seater. This video provides a step-by-step visual guide for assembling the UTV, including attaching wheels, connecting wiring, and securing components.

5. BATTERY CHARGING

The vehicle is powered by a 24V 10Ah rechargeable battery. For optimal performance and battery life, follow these charging instructions:

- **Initial Charge:** Charge the battery for 8-12 hours before first use. Do not charge for more than 20 hours.
- **Regular Charging:** Recharge the battery after each use for 8-12 hours.
- **Charger Connection:** Locate the charging port (typically under the seat or on the dashboard). Plug the charger into the port, then plug the charger into a standard wall outlet.
- **Indicator Light:** The charger will typically have an indicator light to show charging status (e.g., red for charging, green for fully charged).
- **Storage:** If storing the vehicle for an extended period, charge the battery fully every 3 months to maintain its health.

6. OPERATING INSTRUCTIONS

6.1 Manual Operation

Once the battery is charged and connected, the child can operate the vehicle using the foot pedal and steering wheel.

- **Power On:** Press the power button on the dashboard.

- **Speed Selection:** Use the high/low speed switch to select the desired speed mode.
- **Direction:** Use the forward/reverse switch to select the driving direction.
- **Acceleration:** Press the foot pedal to move the vehicle. Release the pedal to brake.
- **Steering:** Turn the steering wheel to change direction.

6.2 Parental Remote Control

The remote control allows parents to override manual controls for added safety, especially for younger children.

- **Pairing:** Follow the instructions in the remote control manual to pair it with the vehicle.
- **Controls:** The remote typically includes buttons for forward/reverse, left/right steering, speed selection, and an emergency stop button.
- **Emergency Stop:** Press the 'P' (Park/Pause) button on the remote to immediately stop the vehicle.



Figure 3: A child operates the Hikiddo UTV while an adult uses the remote control, demonstrating the dual control functionality for safety and guidance.

6.3 2WD/4WD Switching

The vehicle offers switchable 2WD and 4WD modes to adapt to different terrains.

- **Switch Location:** The 2WD/4WD switch is located on the dashboard.
- **2WD Mode:** Provides longer driving time and is suitable for flat, smooth surfaces.
- **4WD Mode:** Offers increased power and traction, ideal for rougher terrains like grass or dirt.

Video 2: Hikiddo 24V Electric UTV - The Perfect Ride for Kids. This video showcases the UTV's features and operation, including its ability to handle various terrains and the ease of use for children.

6.4 Entertainment Features

The UTV includes integrated entertainment options for an enhanced driving experience.

- **Bluetooth Connectivity:** Connect a mobile device via Bluetooth to play custom music through the vehicle's speakers.
- **Pre-programmed Music:** The vehicle comes with pre-programmed songs.
- **Lights:** Front headlights and a light bar provide illumination and visual appeal.




Figure 4: The UTV's dashboard with controls for music, volume, and Bluetooth connectivity, allowing users to play their own audio.

7. MAINTENANCE

- **Cleaning:** Wipe the vehicle with a damp cloth. Do not use abrasive cleaners or submerge the vehicle in water.
- **Battery Care:** Follow charging guidelines. Do not store the battery in extreme temperatures.
- **Tire Inspection:** Regularly check tires for wear and tear.
- **General Inspection:** Periodically check all screws, nuts, and electrical connections to ensure they are secure.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vehicle does not move	Low battery; Loose battery connection; Blown fuse; Motor malfunction	Charge battery; Check and secure connections; Replace fuse; Contact customer support
Vehicle runs slowly	Low battery; Overloaded vehicle; Operating on rough terrain in 2WD	Charge battery; Reduce load; Switch to 4WD mode or smoother terrain
Remote control not working	Remote not paired; Remote battery low/dead	Re-pair remote control; Replace remote batteries
Wheels not turning (e.g., front wheels)	Motor defect; Wiring issue	Contact customer support for motor replacement or wiring inspection.

9. SPECIFICATIONS

- **Model:** B0DMPGR93W
- **Brand:** Hikiddo
- **Product Dimensions:** 47 x 32 x 33 inches
- **Recommended Age:** 3 - 8 years
- **Load Capacity:** 110 lbs
- **Battery:** 24V 10Ah
- **Motors:** 4 x 200W
- **Drive Modes:** 2WD/4WD Switchable
- **Speed Modes:** 3-speeds (3.1-5.0 MPH)
- **Features:** Remote Control, Bluetooth, Lights, 21" Wide Two Seater

Product Dimensions



Recommended age:
3-8 Years old



Load Capacity:
110 lbs



Figure 5: Visual representation of the Hikiddo UTV's dimensions (47.2" L x 31.9" W x 32.7" H), recommended age (3-8 years), and load capacity (110 lbs).

10. WARRANTY AND SUPPORT

For warranty information, technical support, or replacement parts, please contact Hikiddo customer service. Refer to your purchase documentation for specific contact details and warranty terms.

Hikiddo is committed to providing quality products and customer satisfaction. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DMPGR93W>

More documents and user manuals: <https://manuals.plus/>