

oho sunshine T8 PRO

OhO Sunshine Smart Glasses User Manual

Model: T8 PRO

1. SAFETY INFORMATION

Please read all safety instructions carefully before using the OhO Sunshine Smart Glasses. Failure to follow these instructions may result in injury or damage to the device.

- Do not expose the device to extreme temperatures, moisture, or corrosive substances.
- Avoid dropping or subjecting the glasses to severe impact.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel for assistance.
- Keep out of reach of children.
- Use only the provided charging cable and adapter.
- Be aware of your surroundings when using the glasses, especially in traffic or hazardous environments.

2. PRODUCT OVERVIEW

The OhO Sunshine Smart Glasses combine stylish eyewear with advanced audio technology, allowing you to enjoy music, make calls, and interact with voice assistants while keeping your ears open to your surroundings.



Front view of the OhO Sunshine Smart Glasses, showcasing the black frame and red-tinted lenses.

Key Features:

- **Open-Ear Speaker System:** Protects your eardrums while allowing you to hear ambient sounds.
- **HD Microphone:** Provides high-quality audio during phone calls.
- **Voice Control:** Seamlessly connect to smart assistants like Siri, Cortana, and Google Now.
- **Integrated Controls:** Volume up/down and track forward/backward buttons for easy audio management.
- **Ultra-Thin Unisex Design:** Lightweight TR90 frame, similar in weight to regular sunglasses, offering comfortable wear.
- **Impact-Resistant Lenses & Frame:** Meets ANSI/ISEA Z87.1-2015 impact protection standards.
- **100% UV400 Protection:** Polarized lenses protect your eyes from harmful UV rays.



Diagram illustrating key features: Wireless Bluetooth, Waterproof (implied by outdoor use, though not explicitly stated as waterproof in specs), Open Ears, Pick Up The Phone, Music, Outdoor Sports, and Super Slim (45g).

3. SETUP

3.1. Charging the Glasses

Before first use, fully charge your OhO Sunshine Smart Glasses. The battery provides up to 10 hours of continuous use.

- Locate the charging port on the glasses.
- Connect the provided charging cable to the glasses and a compatible USB power source.
- An indicator light will show the charging status. Refer to the specific light behavior in the quick start guide for details (not provided in this manual).
- Once fully charged, disconnect the cable.

3.2. Bluetooth Pairing

To connect your OhO Sunshine Smart Glasses to your smartphone or other Bluetooth-enabled device:

1. Ensure the glasses are charged and powered on.
2. Activate Bluetooth on your smartphone or device.
3. Search for available Bluetooth devices. The glasses should appear as "OhO sunshine" or a similar name.
4. Select the glasses from the list to initiate pairing.
5. Once paired, the glasses will indicate a successful connection (e.g., an audible prompt or indicator light change).

IMPACT RESISTANT LENSES AND FRAME



100% UV400



Impact Resistant



ANSI/ISEA
Z87.1-2015



Illustration of Bluetooth connection from a smartphone to the OhO Sunshine Smart Glasses.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

- **Power On:** Press and hold the power button (usually located on the temple) for a few seconds until you hear a power-on prompt or see an indicator light.
- **Power Off:** Press and hold the power button again for a few seconds until you hear a power-off prompt or the indicator light turns off.

4.2. Music Playback

Once connected via Bluetooth, you can control music playback directly from the glasses.

- **Play/Pause:** Press the multi-function button (often the power button or a dedicated button).
- **Volume Up:** Press the volume up button.
- **Volume Down:** Press the volume down button.
- **Next Track:** Press the next track button.
- **Previous Track:** Press the previous track button.

4.3. Call Management

The integrated microphone allows for hands-free calling.

- **Answer Call:** Press the multi-function button when a call comes in.
- **End Call:** Press the multi-function button during a call.
- **Reject Call:** Press and hold the multi-function button when a call comes in.

4.4. Voice Control

Access your smartphone's voice assistant (Siri, Cortana, Google Now) directly through the glasses.

- **Activate Voice Assistant:** Press and hold the multi-function button (or a dedicated voice control button) until you hear the voice assistant prompt.
- You can then ask for directions, weather updates, traffic information, or connect to music services like Pandora, iTunes, or Spotify.



Bluetooth Connection

Bluetooth connection to your cell phone to take calls and listen to music box sounds



Image highlighting the voice control, volume adjustment, and UV400 protection features of the smart glasses.

5. MAINTENANCE

Proper care will extend the life of your OhO Sunshine Smart Glasses.

- Cleaning Lenses:** Use a soft, clean microfiber cloth specifically designed for eyewear. Do not use paper towels or abrasive materials. For stubborn smudges, use a lens cleaning spray.
- Cleaning Frame:** Wipe the frame with a soft, damp cloth. Avoid using harsh chemicals or solvents.
- Storage:** When not in use, store the glasses in their protective case to prevent scratches and damage.
- Avoid Water Exposure:** While suitable for outdoor activities, avoid submerging the glasses in water.
- Temperature:** Do not expose the glasses to extreme heat (e.g., leaving them in a hot car) or extreme cold, as this can damage the battery and electronic components.

6. TROUBLESHOOTING

If you encounter issues with your OhO Sunshine Smart Glasses, try the following solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cannot power on	Low battery; Device frozen	Charge the glasses fully; Perform a soft reset (refer to quick start guide for button combination, if available).
Cannot pair via Bluetooth	Bluetooth off; Glasses not in pairing mode; Device too far	Ensure Bluetooth is on for both devices; Put glasses in pairing mode; Move devices closer (within 10 meters).
No sound or low volume	Volume too low; Not connected; Audio source issue	Increase volume on glasses and connected device; Re-pair Bluetooth; Check audio source on your device.
Noise or static during playback/calls	Interference; Loose connection; Speaker issue	Move away from other electronic devices; Re-pair Bluetooth; If persistent, contact customer support.
Charging issues (e.g., not charging, red light not on)	Faulty cable/adapter; Charging port issue	Try a different charging cable/adapter; Ensure charging port is clean and free of debris. If issue persists, contact customer support.

If the problem persists after trying these solutions, please contact OhO Sunshine customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Model Number	T8 PRO
Brand	OhO sunshine
Color	Black + Red Lens
Shape	Rectangular
Material	TR90
Size	Free Size
Connectivity Technology	Bluetooth
Continuous Use Time	10 Hours
Battery Capacity	270 mAh
Memory Storage Capacity	128 MB
Product Weight	36.29 g (0.08 pounds)
Package Dimensions	17.6 x 8 x 6.7 cm
Other Features	Wear resistance
Release Year	2024

8. WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your OhO Sunshine Smart Glasses, please contact the manufacturer or your point of purchase. Keep your proof of purchase for warranty claims.

Manufacturer: oho sunshine

For further assistance, please visit the OhO Sunshine store on Amazon:[OhO Sunshine Amazon Store](#)

© 2025 OhO Sunshine. All rights reserved.