



Manuals.plus /

› BUDI /

› BUDI Universal Travel Plug Adapter AC358B20 Instruction Manual

## BUDI AC358B20

# BUDI Universal Travel Plug Adapter AC358B20 Instruction Manual

Model: AC358B20 | Brand: BUDI

## 1. INTRODUCTION AND OVERVIEW

---

Thank you for choosing the BUDI Universal Travel Plug Adapter AC358B20. This all-in-one wall charger is designed to provide global connectivity and fast charging for your electronic devices across over 150 countries, including Europe, UK, EU, AUS/US, and Japan. It features an innovative built-in MicroSD card holder for secure storage and multiple USB ports with Quick Charge (QC) and USB Power Delivery (PD) technology. Its sleek and portable design makes it an essential travel companion.

## 2. PRODUCT FEATURES

---

- **Universal Compatibility:** Supports Type C/E/F plugs for Europe, UK, EU, AUS/US, and Japan, covering over 150 countries.
- **Innovative Card Holder Design:** Integrated MicroSD card holder for secure storage of TF cards, keeping your essentials organized.
- **Dual USB Ports:** Equipped with Quick Charge (QC) and USB Power Delivery (PD) technology for fast charging multiple devices simultaneously.
- **Portable Design:** Compact and lightweight, easy to carry in your bag or pocket for hassle-free travel.
- **Safety Assured:** Built-in protection mechanisms against overheating, overcharging, and short circuits.

## International Travel Adapter with Mini Card Holder



Image: The BUDI Universal Travel Adapter features four main plug types (USA/JP Type-A, UK Type-G, AUS Type-I, EU Type-C) for compatibility in over 150 countries.

## Mini Silicone Gel Card Holder



SIM Card Slot\*2

TF Card Slot\*2

**Silicone Material Soft Protection**

Image: The adapter includes an innovative built-in Micro SD card case for secure storage of memory cards.

## Small Size Lightweight Design



Image: The adapter provides 20W GaN fast charging, capable of powering multiple devices like laptops, tablets, and smartphones.

### 3. SETUP AND OPERATING INSTRUCTIONS

---

#### 3.1 Selecting the Correct Plug Type

The BUDI Universal Travel Adapter features retractable pins for various regions. To select the appropriate plug:

1. Locate the sliders on the side of the adapter.
2. Slide the lever corresponding to your desired region (USA/AUS, UK, EU) to extend the correct pins.
3. Ensure the pins are fully extended and locked into place before plugging into a wall outlet.
4. To retract, slide the lever back until the pins are fully recessed.

### 3.2 Using the Charging Ports

The adapter is equipped with multiple charging ports:

- **AC Socket:** Use the universal AC socket on the front to plug in your device's original power adapter.
- **USB-C Ports (PD):** For fast charging compatible devices like smartphones, tablets, and laptops.
- **USB-A Ports (QC):** For quick charging other USB-powered devices.
- **Retractable USB-C Cable:** A built-in retractable USB-C cable provides convenient direct charging without needing an extra cable. Pull gently to extend and retract.

### 3.3 Micro SD Card Storage

The adapter includes a hidden compartment for Micro SD cards and SIM cards. Gently open the side panel to access the storage slots. A SIM ejector tool is also included for convenience.

Your browser does not support the video tag.

Video: Demonstrates the features of the BUDI Universal Travel Adapter, including its various plug types, USB ports, and integrated Micro SD card case.

Your browser does not support the video tag.

Video: Highlights the 65W fast charging capabilities and universal compatibility of the adapter, showing its use with various devices.

## 4. SAFETY INFORMATION

The BUDI Universal Travel Adapter is designed with your safety in mind. Please observe the following:

- This adapter does **NOT** convert voltage. Ensure your devices are compatible with the local voltage.
- Do not use with appliances requiring a ground wire.
- Built-in 10A overload fuse provides protection against power surges.
- Features fireproof PC material and safety shutters.
- Protects against overcharging, overheating, and short circuits.
- For indoor use only.



Image: Comprehensive safety features include a 10A overload fuse, safety shutter, fireproof PC material, and short-circuit protection.

## 5. SPECIFICATIONS

---

Feature	Detail
Model Number	AC358B20
Input Voltage	110-250 Volts
Output Voltage	5 Volts (USB)
Max Power Output	70W (GaN Fast Charging)
Plug Formats	Type A, C, G, I (USA/JP, EU, UK, AUS)
USB Ports	Multiple USB-A (QC), USB-C (PD)
Total Power Outlets	2 (AC) + USB Ports
Item Weight	6.4 ounces
Package Dimensions	4.23 x 3 x 1.09 inches

## 6. TROUBLESHOOTING

---

- **No Power:** Ensure the adapter is fully plugged into the wall outlet. Check if the internal fuse needs replacement (refer to safety section for fuse details).
- **Device Not Charging:** Verify that the correct plug type is selected and fully extended. Ensure your device's charging cable is securely connected to the adapter's USB or AC port. Check if your device requires voltage conversion, as this adapter does not convert voltage.
- **Slow Charging:** Fast charging (QC/PD) requires compatible devices and cables. If charging is slow, ensure your device and cable support the fast charging protocols of the adapter.
- **Overheating:** If the adapter feels excessively hot, unplug it immediately. Ensure it is not overloaded with too many high-power devices.

## 7. WARRANTY AND SUPPORT

---

Specific warranty details are not provided in this manual. For warranty information, technical support, or any inquiries regarding your BUDI Universal Travel Plug Adapter AC358B20, please contact the manufacturer directly or visit the official BUDI website. Keep your purchase receipt for any warranty claims.