

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HollyHOME](#) /

› [HollyHOME TV Stand with Rattan, 140 cm Bamboo, 2 Shelves - Instruction Manual](#)

HollyHOME EU-TBTV-N01

HollyHOME TV Stand with Rattan, 140 cm Bamboo, 2 Shelves - Instruction Manual

Model: EU-TBTV-N01

1. PRODUCT OVERVIEW

The HollyHOME TV Stand is an elegant, functional, and durable media console crafted from high-quality bamboo with finely worked rattan side panels. Designed to complement various interior styles, it provides optimized storage and organization for your living room or bedroom.



Key Features:

- **Elegant Design:** Natural bamboo finish with rattan side panels.
- **Ample Storage:** Two open shelves for media devices, books, and decor.
- **Durable Construction:** Made from high-quality bamboo for strength and stability.
- **Versatile Use:** Can function as a TV console, coffee table, or display shelf.
- **Easy Maintenance:** Smooth surface for simple cleaning.

2. SAFETY WARNINGS

Please read and adhere to the following safety warnings to prevent injury or damage:

- **Stability:** This furniture may become unstable if heavy objects are placed on the upper shelves or if the weight distribution is uneven.
- **Assembly:** Ensure the unit is assembled correctly according to the provided instructions. Incorrect assembly can compromise stability.
- **Overloading:** Do not overload the shelves. Refer to the specifications for weight capacity guidelines (if available, otherwise exercise caution).
- **Rattan Edges:** Be careful of sharp rattan edges during assembly and use.
- **Children and Pets:** Keep children and pets away from the unit during assembly.

3. SETUP AND ASSEMBLY

The HollyHOME TV Stand requires assembly. Clear and concise instructions are included with your product to guide you through the installation process step-by-step. Please ensure all components are present before beginning assembly.

Assembly Steps:

1. Unpack all components and verify against the parts list in the included manual.
2. Follow the detailed graphical and textual instructions provided in the separate assembly guide.
3. Ensure all screws and fasteners are securely tightened to guarantee stability. Do not overtighten.
4. Place the assembled unit on a flat, stable surface.

Thoughtfully Curated Design



Natural Rattan Sides



Sturdy Bamboo Legs



2 Open Shelves



Image 3.1: Detailed view of the TV stand's construction, highlighting rattan sides, bamboo legs, and open shelves.

4. OPERATING INSTRUCTIONS (USAGE)

The HollyHOME TV Stand is designed to hold televisions and various media devices. Its open-shelf design facilitates easy access and efficient cable management.

Placement and Use:

- Position the TV stand on a level, stable floor surface to prevent wobbling.
- Place your television centrally on the top surface. Ensure the TV base fits within the stand's dimensions.
- Utilize the two open shelves for media players, gaming consoles, soundbars, or other accessories.
- Arrange cables neatly behind the unit to maintain a clean appearance and prevent tripping hazards.
- The versatile design allows it to be used as a low coffee table or a display shelf for decorative items in other rooms.

5. MAINTENANCE

To ensure the longevity and appearance of your HollyHOME TV Stand, follow these simple maintenance

guidelines:

- **Cleaning:** Wipe the bamboo surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Dusting:** Regularly dust the unit to prevent buildup.
- **Spills:** Clean up spills immediately to prevent staining or water damage to the bamboo.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood.



Image 5.1: Detail of the durable bamboo construction, highlighting its natural texture and thickness.

6. TROUBLESHOOTING

If you encounter any issues with your HollyHOME TV Stand, please refer to the following common solutions:

- **Wobbling/Instability:**
 - Ensure all screws and fasteners are securely tightened.
 - Verify the unit is placed on a completely flat and level surface.

- Check if the weight on the shelves is evenly distributed and not exceeding recommended limits.
- **Missing Parts/Damaged Components:**
 - Contact HollyHOME customer service immediately if any parts are missing or damaged upon arrival.
- **Difficulty with Assembly:**
 - Review the assembly instructions carefully.
 - If issues persist, contact HollyHOME customer service for assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	HollyHOME
Model Number	EU-TBTV-N01
Product Dimensions (L x W x H)	140 cm x 30 cm x 40 cm (55.1 in x 11.8 in x 15.7 in)
Material	Bamboo, Rattan
Color	Natural-b
Item Weight	9.78 Kilograms (21.56 lbs)
Assembly Required	Yes
Manufacturer	SOHO HOLLY CORPORATION

For TV up to 65"




Image 7.1: Dimensional diagram of the TV stand, indicating suitability for TVs up to 65 inches.

8. WARRANTY AND SUPPORT

HollyHOME is committed to customer satisfaction. While specific warranty details are not provided in this manual, a dedicated customer service team is available to assist with any difficulties encountered during assembly or use.

For support, please refer to the contact information provided with your purchase or visit the official HollyHOME website.