

[Manuals.plus](#) /

› [TAGRY](#) /

› TAGRY X88 Wireless Earbuds User Manual

TAGRY X88

TAGRY X88 Wireless Earbuds User Manual

Model: X88

Brand: TAGRY

INTRODUCTION

The TAGRY X88 Wireless Earbuds are designed to provide a superior audio experience with advanced features for active lifestyles. These Bluetooth headphones offer extended playtime, a convenient power display, IPX7 waterproofing, and deep bass, making them ideal for running, workouts, and daily use. This manual provides detailed instructions to help you get the most out of your new earbuds.



Image: TAGRY X88 Wireless Earbuds and Charging Case

WHAT'S IN THE BOX

- Bluetooth Headphones (TAGRY X88 Earbuds)
- Charging Case
- Type-C Charging Cable
- Eartips (S/M/L sizes)



Image: All components included with the TAGRY X88 Wireless Earbuds.

SETUP GUIDE

1. Initial Charging

Before first use, ensure the charging case and earbuds are fully charged. Connect the provided Type-C charging cable to the charging case and a power source. The dual LED display on the charging case will show the real-time battery level of the case and the charging status of each earbud. A full charge takes approximately 1.2 hours.

2. Pairing with Your Device

The TAGRY X88 earbuds are designed for effortless connectivity. Simply open the charging case, and the wireless

Bluetooth earbuds will automatically power on and enter pairing mode (after the first successful pairing, they will automatically connect to the last paired device).

1. Open the charging case. The earbuds will power on.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
3. Search for 'X88' in the list of available devices.
4. Select 'X88' to connect. Once connected, you will hear a confirmation sound.

Open.Connect.Go




Image: Automatic pairing process of TAGRY X88 earbuds with a smartphone.

Setup and Unboxing Video

Video: An overview of the TAGRY X88 wireless earbuds, including unboxing and initial setup steps. This video is provided by the seller, TAGRY Club.

OPERATING INSTRUCTIONS

Wearing the Earbuds

The X88 sports headphones feature soft and flexible ear hooks designed for all-day comfort and a secure fit. Choose the appropriate eartip size (S, M, L) for enhanced sound quality and noise isolation.

Design For Ultimate Comfort




Image: Proper fit and comfort design of the TAGRY X88 earbuds with interchangeable eartips.

Touch Controls

The earbuds come with a single physical button that simplifies your audio experience. Use simple taps on either earbud to control various functions:

- **Play/Pause Music:** Single tap.
- **Adjust Volume:** Tap and hold (specific earbud for up/down, refer to full manual for details).
- **Skip Tracks:** Double tap (specific earbud for next/previous, refer to full manual for details).

- **Activate Voice Assistant:** Triple tap.
- **Answer/End Calls:** Single tap.



Image: Visual guide to the one-button touch controls on the TAGRY X88 earbuds.

Sound Quality and Connectivity

Experience rich and immersive audio with 13mm drivers delivering crystal-clear highs, balanced mids, and powerful bass. The built-in microphone ensures clear voice transmission during calls, even in noisy environments.

Equipped with the latest Bluetooth 5.4 technology, the earbuds provide a stable and fast connection with reduced latency, allowing seamless audio streaming up to 33 feet from your device.

360° Sonic Immersion



Image: Representation of the 360-degree sonic immersion provided by the earbuds.

**Widely Compatible with
Bluetooth 5.4**




Image: The earbuds allow users to tune in and move freely during activities.

MAINTENANCE

Cleaning Instructions

To ensure optimal performance and charging, regularly clean the charging contacts on both the earbuds and inside the charging case. Use a dry cotton swab or a soft, lint-free cloth. For stubborn dirt, lightly dampen the swab with rubbing alcohol.

Trouble Shooting Guide and Maintenance

For Charging Issue: use cotton swabs or pads to clean the charging contacts on both the earbuds and the case




Image: Guide for cleaning the charging contacts of the earbuds and the charging pins in the case.

Water Resistance

The TAGRY X88 earbuds feature an IPX7 waterproof rating, meaning they can resist sweat, rain, and splashes. They are suitable for workouts and outdoor activities. However, they are not designed for swimming or prolonged submersion in water.

IPX7 Waterproof



Image: The IPX7 waterproof feature of the TAGRY X88 earbuds.

TROUBLESHOOTING GUIDE

If you encounter any issues with your TAGRY X88 earbuds, please refer to the common solutions below. For more detailed troubleshooting, consult the official [Troubleshooting Guide \(PDF\)](#).

Common Issues & Solutions:

- Earbuds not charging:

Ensure the charging cable is securely connected. Clean the charging contacts on both the earbuds and the charging case with a dry cotton swab to remove any dust or debris that might be obstructing the connection.

- **Earbuds not pairing/connecting:**
Make sure Bluetooth is enabled on your device. Place the earbuds back in the case, close the lid, wait a few seconds, then open it again to re-enter pairing mode. If the issue persists, try forgetting the device in your phone's Bluetooth settings and re-pairing.
- **Sound quality issues (low volume, distorted sound):**
Check the volume levels on both your device and the earbuds. Ensure the eartips are properly seated in your ears for optimal sound isolation. Clean any earwax buildup from the earbud nozzles.
- **One earbud not working:**
Ensure both earbuds are charged. Try placing both earbuds back in the case, closing the lid, and then reopening it. If one earbud is still not connecting, try resetting the earbuds (refer to the full user manual for specific reset instructions).

Charging Issue Guide Video

Video: A detailed guide from TAGRY Club on how to resolve common charging issues for the X88 headphones by cleaning the charging contacts.

SPECIFICATIONS

Feature	Detail
Model Name	X88
Brand	TAGRY
Connectivity Technology	Wireless (Bluetooth 5.4)
Wireless Range	Up to 33 feet
Playtime Per Charge	Up to 10 hours
Total Playtime with Charging Case	Up to 80 hours
Charging Time	1.2 hours (via USB-C)
Water Resistance Level	IPX7 Waterproof
Driver Size	13mm
Noise Control	Sound Isolation
Control Type	Push Button (Touch Control)
Ear Placement	In Ear with Over-Ear Hook
Material	Plastic, Acrylonitrile Butadiene Styrene (ABS)
Item Weight	2.85 Ounces
Product Dimensions	1.18 x 2.36 x 3.54 inches

WARRANTY INFORMATION

TAGRY offers a lifetime warranty for the X88 Wireless Earbuds, which includes replacement for any reason, including loss. Please retain your proof of purchase for warranty claims. For specific details and to initiate a warranty claim, please refer to the contact information provided in the support section or the official product documentation.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries regarding your TAGRY X88 Wireless Earbuds, please contact TAGRY customer service through their official website or the platform where you purchased the product. You may also refer to the comprehensive [User Manual \(PDF\)](#) for additional information.

Thank you for choosing TAGRY.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question