

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› **LANDOT /**

› LANDOT 2-in-1 Hair Straightener and Curler (Model HS168) User Manual

LANDOT HS168

LANDOT 2-in-1 Hair Straightener and Curler (Model HS168) User Manual

Your comprehensive guide to styling with precision and care.

1. INTRODUCTION

This manual provides instructions for the safe and effective use of your LANDOT 2-in-1 Hair Straightener and Curler, Model HS168. This versatile styling tool combines the functions of a flat iron and a curling iron, allowing you to achieve various hairstyles from sleek straight to bouncy curls.



Image 1.1: The LANDOT 2-in-1 Hair Straightener and Curler, accompanied by a heat-resistant mat and hair clips.

2. IMPORTANT SAFETY INFORMATION

Please read all safety warnings before use to prevent injury or damage.

- **Burn hazard:** Surfaces get extremely hot during use. Avoid direct contact with skin, especially the scalp, ears, and neck. Use the provided heat-resistant glove.
- **Electric shock risk:** Keep away from water. Do not use near bathtubs, sinks, showers, or any other water sources. If the appliance falls into water, unplug it immediately. Do not reach into the water.
- **Fire risk:** Unplug the appliance when not in use. Do not leave unattended when plugged in. Ensure the appliance is placed on a heat-resistant surface, such as the included silicone mat, during and after use until it has cooled completely.
- Keep out of reach of children.
- Do not use if the cord is damaged or if the appliance is malfunctioning. Contact customer support for assistance.

3. PRODUCT FEATURES

The LANDOT 2-in-1 Hair Straightener and Curler is engineered with advanced technology for versatile styling and hair protection.

- **Versatile Styling:** Combines a flat iron and curling iron in one tool, enabling straightening, curling, waving, or adding volume.
- **Ceramic Tourmaline Technology:** Equipped with ceramic tourmaline plates that emit negative ions, promoting smoother, frizz-free results and sealing in moisture.
- **Adjustable Temperature:** Offers a wide temperature range from 250°F to 450°F (120°C to 230°C), suitable for all hair types.
- **Dual Voltage:** Designed for worldwide travel, operating on dual voltage (110-240V) for seamless use internationally.
- **Ergonomic Design:** Features an easy-grip handle with a 360° swivel cord and cool tip for comfortable and effortless styling.
- **Included Accessories:** Comes with a silicone heat-resistant mat to protect surfaces, and hair clips for sectioning.

Unique Twisted Plates

1. New and improved smooth glide design
2. More control the hair on the heating plate
3. More evenly heating and straighten hair faster



Image 3.1: Close-up of the unique twisted plates designed for smooth glide and even heating.

4. SETUP

1. **Unpack:** Carefully remove the straightener and all accessories from the packaging.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Placement:** Place the heat-resistant silicone mat on a flat, stable surface where you intend to style your hair.
4. **Plug In:** Insert the power cord into a suitable electrical outlet. The appliance is dual voltage (110-240V) and will automatically adjust.



Image 4.1: The LANDOT 2-in-1 Hair Straightener and Curler shown with its heat-resistant mat, hair clips, and heat-resistant glove.

5. OPERATING INSTRUCTIONS

5.1 Power On and Temperature Adjustment

1. Press and hold the power button to turn on the appliance. The LCD display will illuminate.
2. Use the '+' and '-' buttons to adjust the temperature. The temperature will increase or decrease in increments.
3. Allow the appliance to heat up to your desired temperature. The display will show the current temperature and flash until the set temperature is reached.

Recommended Temperature Settings:

- 250°F - 310°F (120°C - 150°C): For thin, fine, damaged, or bleached hair.
- 320°F - 390°F (160°C - 190°C): For normal, healthy hair.
- 410°F - 450°F (200°C - 230°C): For thick, coarse, or difficult-to-style hair.

Multiple Temperatures Suitable For All Hair Types



Image 5.1: Visual guide for selecting appropriate temperature settings based on hair type.

5.2 Straightening Hair

1. Ensure hair is clean, dry, and detangled.
2. Section your hair using the provided clips. Start with a small section, about 1-2 inches wide.
3. Place the hair section between the heating plates, close to the roots.
4. Gently clamp the plates together and glide the straightener slowly and steadily down the hair section, from root to tip. Avoid stopping in one place to prevent heat damage.
5. Repeat on all sections until desired straightness is achieved.

STRAIGHTEN HAIR

Fast-heating **ceramic plates** glide through hair to leave it **silky-smooth** and **frizz-free** in a single stroke



Image 5.2: A user demonstrating the process of straightening hair with the LANDOT 2-in-1 tool.

5.3 Curling or Waving Hair

1. Ensure hair is clean, dry, and detangled.
2. Section your hair using the provided clips. Start with a small section, about 1-2 inches wide.
3. For curls, place the hair section between the heating plates, close to the roots.
4. Rotate the appliance 180 degrees away from your face, then slowly glide it down the hair section to the ends. The speed of gliding will affect the tightness of the curl (slower for tighter curls, faster for looser waves).

5. For waves, twist 180 degrees and glide down at a moderate pace.
6. Allow the curl to cool in your hand for a few seconds before releasing for better hold.
7. Repeat on all sections until desired style is achieved.

CURL CONFIDENCE

Twist 180° and glide down for waves
glide slower for curls
with light grip on the cool tip



Image 5.3: A user demonstrating how to create curls or waves using the LANDOT 2-in-1 tool.

5.4 Power Off

After styling, press and hold the power button until the display turns off. Unplug the appliance from the electrical outlet. Allow the appliance to cool completely on the heat-resistant mat before storing.

6. MAINTENANCE

6.1 Cleaning

1. Ensure the appliance is unplugged and completely cool before cleaning.
2. Wipe the exterior and heating plates with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
3. Ensure no moisture enters the appliance.

6.2 Storage

Store the appliance in a dry place, away from moisture and direct sunlight. The included velvet-like bag can be used for protection. Do not wrap the power cord tightly around the appliance, as this can cause damage.

7. TROUBLESHOOTING

If you encounter any issues with your LANDOT 2-in-1 Hair Straightener and Curler, please refer to the following common solutions:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a functional electrical outlet. Check if the outlet is receiving power.
- **Appliance not heating up:** Verify that the temperature setting is correctly selected. Allow sufficient time for the plates to reach the set temperature.
- **Hair not straightening/curling effectively:** Ensure hair is clean, dry, and free of styling products that may create a barrier. Use appropriate temperature for your hair type. Take smaller sections of hair. Glide the tool slower for more defined results.
- **Hair snagging:** Ensure hair is thoroughly detangled before use. Check the plates for any residue that might be causing friction.

If the problem persists after attempting these solutions, please contact LANDOT customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	HS168
Product Dimensions	12 x 1.25 x 1.25 inches
Weight	14.11 ounces
Brand	LANDOT
Material	Ceramic Tourmaline
Color	Black
Voltage	110-240V (Dual Voltage)
Wattage	45 watts
Temperature Range	250°F - 450°F (120°C - 230°C)

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please refer to the official LANDOT website or contact their customer service directly. Specific warranty terms and conditions may vary and are typically provided with your purchase documentation.

10. VIDEO RESOURCES

No official product videos from the seller were provided in the product data to embed in this manual.