Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OLIXIS AOLICK32

OLIXIS Criss Cross Legged Chair User Manual

Model: AOLICK32

Introduction

Thank you for choosing the OLIXIS Criss Cross Legged Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.



Image: The OLIXIS Criss Cross Legged Chair, Pu-beige, in a modern room.

Safety Information

Please observe the following safety guidelines to prevent injury or damage to the product:

- **Maximum Weight Limit:** This chair is designed to support a maximum weight of 300 lbs (136 kg). Do not exceed this limit.
- **Mechanism Caution:** The chair features a swivel and rocking mechanism. Use these functions with care to maintain stability.
- **Assembly:** Ensure all components are securely fastened before use. Periodically check and tighten all screws.
- **Placement:** Place the chair on a flat, stable surface. Avoid placing it on uneven ground.
- **Children:** Keep children away from the chair during assembly. Do not allow children to play on or around the chair unsupervised.

Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Criss Cross Leg Chair (Seat and Backrest)
- Chair Base (Cross Leg Design)
- Gas Lift Cylinder
- Mechanism Plate
- Hardware Pack (Screws, Washers, Allen Wrench)
- Instruction Manual (this document)

Setup and Assembly

Follow these steps to assemble your OLIXIS Criss Cross Legged Chair. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

1. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat. Secure it using the provided screws and the Allen wrench. Ensure the front of the mechanism plate faces the front of the seat.
2. **Insert Gas Lift into Base:** Place the cross-legged base on a flat surface. Insert the wider end of the gas lift cylinder into the center hole of the base.
3. **Attach Seat to Gas Lift:** Carefully place the assembled seat (with mechanism plate) onto the narrower end of the gas lift cylinder. Press down firmly to ensure a secure connection.
4. **Final Check:** Once assembled, sit on the chair to ensure all components are properly seated and stable. Test the height adjustment and rocking functions.



Image: Product dimensions diagram for assembly reference.

Operating Instructions

Your OLIXIS chair is designed for comfort and adjustability. Familiarize yourself with its functions:

- **Height Adjustment:** To raise the seat, lift the lever located under the right side of the seat while standing. To lower the seat, lift the lever while seated. The adjustable seat-to-floor height ranges from 15.94 inches to 19.69 inches.
- **Swivel Function:** The chair seat can rotate 360 degrees, allowing for easy movement and access within your workspace.
- **Rocking Function:** Pull out the lever located under the right side of the seat to enable the rocking motion. Push the lever in to lock the chair in an upright position. The chair offers a supportive rocking range of approximately 21 degrees. Adjust the rocking tension by turning the round knob located under the front of the seat. Turn clockwise to increase tension (stiffer rock) and counter-clockwise to decrease tension (looser rock).



Image: Visual guide for rocking function and height adjustment.

Maintenance

Proper care will extend the life and appearance of your chair:

- **Cleaning:** For PU leather surfaces, wipe with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Hardware:** Periodically check all screws and bolts to ensure they are tight. Re-tighten as necessary to maintain stability and safety.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the material to fade or crack.
- **Weight Distribution:** Distribute your weight evenly on the seat to prevent undue stress on the chair's components.

Troubleshooting

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the problem persists, the gas lift may need replacement. Contact customer support.
Chair is wobbly	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, even surface.
Rocking function not working	Rocking lever locked or tension knob too tight.	Pull out the rocking lever to enable the function. Turn the tension knob counter-clockwise to loosen the rocking mechanism.
Squeaking noises	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary, avoiding contact with upholstery.

Specifications

Feature	Detail
Brand	OLIXIS
Model Name	Criss Cross Legged Chairs
Item Model Number	AOLICK32
Color	Pu-beige
Product Dimensions	26.4"D x 26"W x 32.5"H
Seat Height Range	15.94" to 19.69"
Maximum Weight Recommendation	300 Pounds
Material	PU Leather, Sponge (Fill Material)
Special Features	Adjustable Height, Back Support, Ergonomic, No Wheels, Wide Seat, Swivel, Tilting
Arm Style	Armless
Leg Style	Cross Leg
Item Weight	29 pounds
UPC	792138543596

Warranty and Support

OLIXIS is committed to providing quality products. While specific warranty details are not provided in this manual, please

retain your proof of purchase for any warranty claims. For assistance with assembly, missing parts, or any product-related inquiries, please contact OLIXIS customer support through the retailer where the product was purchased or visit the official OLIXIS store online.

Online Store: Visit the OLIXIS Store on Amazon

© 2025 OLIXIS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DMSV66G7

More documents and user manuals: **https://manuals.plus/**