Silonn SLCDW01W-US

Silonn Portable Countertop Dishwasher User Manual

Model: SLCDW01W-US

1. Product Overview

The Silonn Portable Countertop Dishwasher is designed for compact living spaces such as apartments, RVs, and dorms, offering a convenient solution for dishwashing without the need for permanent installation. It features a 5L built-in water tank and multiple wash programs to ensure thorough cleaning and drying of your dishes.



Figure 1: Silonn Portable Countertop Dishwasher in a kitchen setting.

Key Features:

- **7 Wash Programs:** Intensive, Babycare, ECO, Rapid, Normal, Glass, and Fruit modes.
- **Compact Size, Large Capacity:** Measures 16.9 x 17.72 x 18.1 inches, holds up to 4 full place settings (54 pieces of tableware), and plates up to 10 inches.
- **3 Jet Cleaning System:** Provides 360° coverage with powerful water jets.
- **Two Water Supply Options:** Manual 5L water tank filling or automatic water supply connection.
- **Advanced Drying & Storage:** Efficient PTC hot drying system with air circulation for odor-free, dry dishes.

2. Setup and Installation

The Silonn Portable Countertop Dishwasher offers flexible setup options to suit your needs, whether you prefer manual water filling or a direct water connection.

Unboxing and Components:

Carefully unpack all components from the box. Ensure all listed items are present:



Figure 2: Included components: User Manual, Power Cord, Drain Hose, Inlet Hose, Cutlery Basket, Water Pitcher, Hose Clamp, Connector, Suction Cup.

Water Supply Options:

1. **Manual Water Filling:**
   For no hookup needed, simply use the included water pitcher to fill the 5L water tank through the port located on the top front of the unit. The dishwasher will beep to indicate when the tank is full.



Figure 3: Manual water filling via the front port.

2. **Automatic Water Supply:**
   Connect the included inlet hose and 3-way ball valve to a water source for a continuous water supply. This option requires a faucet connection.



Figure 4: Automatic water supply connection.

Drainage:

Ensure the drain hose is properly positioned to discharge water into a sink or bucket. The dishwasher will automatically drain used water after each cycle.

Your browser does not support the video tag.

Video 1: Official Silonn Dishwasher Countertop overview, demonstrating features including water filling and drainage. This video is provided by the seller.

3. Operating Instructions

This section guides you through the process of loading dishes, selecting wash programs, and starting a cycle.

Loading Dishes:

The dishwasher is designed to hold up to 4 full place settings. Arrange dishes to allow water to reach all surfaces. The basket features smooth sliding rollers and a 3-stage adjustable shelf for versatile loading.



COMPACT SIZE, LARGE CAPACITY

Holds up to 4 full place settings for 3-4 people

9x Plates
4x Cups
12x Spoons
4x Glasses
5x Bowls
12x Forks
4x Knives

Figure 5: Dishwasher interior with capacity details and dimensions (16.93"W x 17.72"D x 18.11"H).



Figure 6: Adjustable shelf and smooth sliding rollers for easy loading.

Adding Detergent:

Add the appropriate amount of dishwasher detergent to the designated dispenser. Refer to your detergent's instructions for dosage.

Selecting a Wash Program:

The dishwasher offers 7 distinct wash programs. Select the program that best suits the soil level and type of dishes.



Figure 7: Available wash programs and their typical durations/temperatures.

- **Intensive (167°F, 109min):** For heavily soiled dishes and baby items, ensuring thorough cleaning.
- **Babycare (167°F, 109min):** High-temperature wash for sterilizing baby bottles and accessories.
- **ECO (162°F, 60min):** Energy-efficient program for normally soiled dishes.
- **Rapid (162°F, 35min):** Quick wash for lightly soiled dishes.
- **Normal (131°F, 205min):** Standard program for daily dishwashing.
- **Glass (140°F, 70min):** Gentle wash for delicate glassware.

- **Fruit (25min):** Dedicated program for washing fruits and vegetables.

Starting a Cycle:

After loading dishes and selecting the program, press the Start button. The 3-jet cleaning system will provide 360° full coverage for effective cleaning.



Figure 8: The powerful 3-jet cleaning system in action.




Figure 9: Detailed view of the 3-jet cleaning system and its effectiveness on various items.

4. Maintenance and Drying

Proper maintenance and effective drying are crucial for the longevity and performance of your dishwasher.

Advanced Drying System:

The Silonn dishwasher features an efficient PTC hot drying system combined with powerful air circulation. This ensures dishes are completely dry, preventing moisture buildup and water spots, and allows for convenient dish storage inside the unit.



Figure 10: Illustration of the advanced PTC hot drying and air circulation system.

Cleaning the Dishwasher:

Regularly clean the filter and interior of the dishwasher to maintain optimal performance. Refer to the full user manual for detailed cleaning instructions.

5. Troubleshooting

If you encounter issues with your Silonn Portable Countertop Dishwasher, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dishwasher beeps to add water, but tank appears full.	Sensor misreading or air bubble.	Ensure the unit is on a level surface. Gently rock the unit to dislodge any air bubbles. If using manual fill, ensure water is added slowly until the beep.
Dishes are not completely dry.	Drying function not activated or insufficient air circulation.	Ensure the drying function is selected or activated after the wash cycle. For best results, slightly crack the door open after the cycle to allow steam to escape and enhance air drying.
Dishes are not clean.	Improper loading, insufficient detergent, or clogged spray arms/filter.	Review loading instructions to ensure proper water circulation. Use recommended detergent amount. Clean the spray arms and filter regularly. Select a more intensive wash program if needed.

For more detailed troubleshooting or persistent issues, please refer to the comprehensive user manual or contact Silonn customer support.

6. Specifications

Detailed technical specifications for the Silonn Portable Countertop Dishwasher:

Specification	Value
Brand	Silonn
Model Name	Dishwasher
Model Info	SLCDW01W-US
Form Factor	Countertop
Product Dimensions	17.72"D x 16.93"W x 18.11"H
Item Weight	28 pounds
Capacity	5 Liters (Water Tank)
Number of Place Settings	4
Voltage	120 Volts
Annual Energy Consumption	92 Kilowatt Hours Per Year
Noise Level	56.3 dB
Controls Type	Touch
Material	Polypropylene (PP)
Special Features	Adjustable Basket, Auto Program, Touch Panel, Built-In Water Tank

7. Warranty and Support

For warranty information, product registration, or technical assistance, please refer to the official Silonn website or contact their customer support directly.

- **Official User Manual:** Download PDF
- **Silonn Store:** Visit Silonn Store on Amazon
- **Contact Information:** Please refer to the contact details provided in your product packaging or on the official Silonn website for support.

© 2025 Silonn. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question