

B0DMTHHM19

Bubble Gun Bazooka User Manual

Model: B0DMTHHM19

Brand: Generic

INTRODUCTION

This manual provides essential information for the safe and effective operation and maintenance of your Bubble Gun Bazooka. Please read this manual thoroughly before first use and retain it for future reference.

The Bubble Gun Bazooka is an innovative automatic bubble machine designed to create a fun and magical atmosphere for various occasions. Equipped with 60 bubble outlets and LED lights, it produces a large quantity of vibrant bubbles. It is suitable for outdoor activities, parties, weddings, and general playtime for children aged 3 and above, as well as adults.



Image: The Bubble Gun Bazooka in blue, emitting numerous bubbles, displayed alongside its complete set of accessories including bubble liquid bottles, rechargeable batteries, a USB charging cable, a screwdriver, and safety goggles.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Bubble Gun × 1
- Dual 1200mAh Rechargeable Batteries × 2
- USB Charging Cable × 1
- Screwdriver × 1
- Bubble Liquid × 1 Bottle
- Goggles × 1

Product Parameters and Accessories



Two Bubble mixture
(4.73ounces)



Two 2100mAh
Batteries



Concentrated bubble
liquid×10 (0.34ounces)



USB charging
cable



Screwdriver



Goggles

Image: A detailed diagram illustrating the dimensions of the Bubble Gun Bazooka and a visual representation of all included accessories: two bottles of bubble mixture, two 2100mAh batteries, concentrated bubble liquid packets, a USB charging cable, a screwdriver, and safety goggles.

SETUP

Follow these steps to prepare your Bubble Gun Bazooka for use:

1. **Install Batteries:** Locate the battery compartment. Use the provided screwdriver to open the compartment. Insert the two 1200mAh rechargeable batteries, ensuring correct polarity. Close the compartment securely.
2. **Charge Batteries:** Before first use, ensure the batteries are fully charged. Connect the USB charging cable to the batteries and a suitable USB power source. Charging time is approximately 3-4 hours.
3. **Fill with Bubble Liquid:** Open the bubble chamber. Carefully pour the provided bubble liquid into the chamber. Do not overfill.

USER-FRIENDLY

Just three steps to start your dream bubble journey



Image: A visual guide showing three steps for setup: 1) Opening the battery compartment and connecting the battery, 2) Opening the bubble chamber and filling it with bubble liquid, and 3) Pressing the switch to activate the automatic foaming mode.

OPERATING INSTRUCTIONS

Once set up, operating the Bubble Gun Bazooka is straightforward:

1. **Power On:** Locate the power switch, typically a one-button start mechanism.
2. **Activate Bubbles:** Press and hold the switch while pushing the latch to activate the automatic foaming mode. The 60 bubble outlets will begin producing a continuous stream of bubbles, and the LED lights will illuminate.
3. **Power Off:** Release the switch to stop bubble production.

For optimal performance, ensure the bubble liquid reservoir is adequately filled during operation.

STRONG BATTERY LIFE

Two 2100 mAh rechargeable batteries, no need to wait for charging, play non-stop



2100mAh, can play for 30 minutes.



2 batteries, no need to wait for charging time.



Equipped with USB charging cable for quick charging.



Image: A graphic detailing the battery features, showing two 2100mAh rechargeable batteries, indicating 30 minutes of play time, and the inclusion of a USB charging cable for quick charging.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your bubble gun:

- **Cleaning Bubble Outlets:** After each use, clean the bubble outlets to prevent clogging caused by dried bubble liquid. A damp cloth can be used to gently wipe the surfaces.
- **Battery Care:** To prolong battery life, avoid overcharging for extended periods. Store batteries in a cool, dry place when not in use.
- **Storage:** When not in use, store the bubble gun in a clean, dry environment away from direct sunlight and extreme temperatures.

BUBBLE SOLUTION

OURS



VS

OTHERS



✓ Built-in bubble liquid, you can have fun



✓ 2 rechargeable batteries



✓ Large-capacity rechargeable battery, lasting battery life, can be recycled.



✗ It needs to be dipped in bubble liquid repeatedly, and the operation is cumbersome



✗ If there is no power, replace the battery and wait for charging.



✗ Disposable batteries need to be replaced repeatedly.

Image: A comparison showing the built-in bubble liquid chamber of this product versus a traditional method requiring repeated dipping, highlighting the convenience of the integrated design and rechargeable batteries.

TROUBLESHOOTING

If you encounter issues with your Bubble Gun Bazooka, refer to the following common problems and solutions:

• No Bubbles Produced:

- Check if the bubble liquid reservoir is empty or too low. Refill as needed.
- Ensure the batteries are fully charged and correctly installed.
- Inspect bubble outlets for any clogs from dried liquid. Clean thoroughly.

• Device Does Not Power On:

- Verify that the batteries are charged and properly connected.
- Ensure the power switch is fully engaged.

- **Reduced Bubble Output:**
 - Check bubble liquid level.
 - Clean bubble outlets for partial clogs.
 - Ensure batteries have sufficient charge.

If problems persist after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	6.2 x 6.2 x 13.7 inches
Item Weight	2.68 pounds
Recommended Age	3 years and up
Batteries	2 x 1200mAh Rechargeable (included)
Charging Time	3-4 hours
Continuous Use	Approximately 20 minutes
Material	Eco-friendly ABS plastic
Bubble Outlets	60
LED Lights	Yes (4 lights)

SAFETY INFORMATION

Please observe the following safety precautions:

- **Adult Supervision:** This product is suitable for children aged 2 and above. Adult supervision is strongly recommended during use, especially for younger children.
- **Bubble Liquid Contact:** Avoid contact of bubble liquid with eyes or other sensitive areas. In case of accidental contact, rinse thoroughly with water immediately.
- **Outdoor Use:** It is best used outdoors for an enhanced bubble experience and to prevent slippery surfaces indoors.
- **Material Safety:** The bubble gun is made from eco-friendly and non-toxic ABS plastic. It features a smooth surface with no sharp edges for child safety.

Great for children



Image: Children joyfully playing with the Bubble Gun Bazooka in an outdoor setting, surrounded by numerous bubbles, illustrating the product's appeal for kids.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not provided within this manual. Please refer to the product packaging or the retailer's website for details on warranty coverage and how to contact customer support for assistance.