

[Manuals.plus](#) /

> [Titan](#) /

> Titan G100 Mini 85 Inch Covered Patio Outdoor TV Instruction Manual

## Titan G100-QLED-85

# Titan G100 Mini 85 Inch Covered Patio Outdoor TV Instruction Manual

Model: G100-QLED-85

[Instructions](#)   [Safety Information](#)   [What's in the Box](#)   [Setup](#)   [Operating](#)  
[Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## INTRODUCTION

Thank you for choosing the Titan G100 Mini 85 Inch Covered Patio Outdoor TV. This manual provides essential information for the safe and efficient use of your new outdoor television. Please read these instructions thoroughly before installation and operation, and retain them for future reference.



*The Titan G100 Mini 85 Inch Outdoor TV seamlessly integrates into any covered patio environment, providing entertainment for family and friends.*

## IMPORTANT SAFETY INFORMATION

Always follow these basic safety precautions to reduce the risk of fire, electric shock, and injury:

- **Placement:** This TV is designed for covered outdoor areas (patios, decks, screened-in porches). Do not expose it to direct sunlight or extreme weather conditions beyond its IP65 rating.
- **Power:** Connect the TV to a grounded power outlet. Do not overload power outlets or extension cords.
- **Water Exposure:** While IP65 rated for water resistance, avoid direct high-pressure water jets or submersion. Ensure all port covers are securely closed.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block ventilation openings.
- **Cleaning:** Disconnect power before cleaning. Use a soft, damp cloth. Avoid harsh chemicals.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

## WHAT'S IN THE BOX

Verify that all components are present before proceeding with installation:

- Titan G100 Mini 85 Inch Outdoor TV
- Remote Control (with 2 AAA batteries)
- TV Stand (if applicable)
- Power Cable
- TV Cover
- User Manual (this document)

## TITAN ACCESSORIES

Upgrade your outdoor viewing experience with must-have TV accessories designed for convenience, durability, and all-weather use.

### OUTDOOR TV COVER

Our heavy-duty, waterproof cover, built with a PVC-coated interior, weather-resistant zipper, and a remote pocket for added convenience.



Front

Back

### OUTDOOR SPEAKER

The outdoor speaker sound bar, powered by Sonos, brings crisp dialogue and rich, dynamic sound outdoors. Your outdoor TV has never sounded this good.



*Included accessories for your Titan G100 Outdoor TV, such as the remote control, stand, and protective cover.*

## SETUP INSTRUCTIONS

### 1. Physical Installation

The Titan G100 TV can be mounted on a wall or placed on a stand. Ensure the chosen location is a covered outdoor area, protected from direct rain and prolonged direct sunlight.

- **Stand Installation:** Attach the provided stand according to the instructions in the separate stand assembly guide. Place the TV on a stable, level surface.
- **Wall Mounting:** Use a VESA-compatible wall mount (400 x 400 mm standard, sold separately). Follow the wall

mount manufacturer's instructions carefully. Ensure the wall structure can support the TV's weight (71.8 lbs without stand).



*The Titan G100 TV is designed for covered outdoor settings, providing a clear view for all.*

## 2. Connecting Power

Connect the power cable to the TV's power input and then to a grounded 120V AC outlet. Ensure the outlet is protected from moisture.

## 3. Initial Setup (Google TV)

Upon first power-on, the TV will guide you through the initial Google TV setup process. This includes:

- **Language Selection:** Choose your preferred language (English, French, Spanish).
- **Network Connection:** Connect to your Wi-Fi network. The TV supports Bluetooth and Ethernet for wired connections.
- **Google Account Login:** Sign in with your Google account to access Google TV features, apps, and personalized

recommendations.

- **Channel Scan:** If using an antenna, perform a channel scan for over-the-air broadcasts (ATSC signal format supported).

Your browser does not support the video tag.

*Video demonstrating the initial setup and interface of a Titan Outdoor TV, showing how it is converted for outdoor use and its smart features.*

Your browser does not support the video tag.

*An unboxing video for a Deck Pro 2.0 Series Outdoor TV, providing a general overview of what to expect during the initial setup of an outdoor television.*

## OPERATING INSTRUCTIONS

---

### 1. Remote Control


The included remote control uses infrared technology and features push buttons for navigation. Insert the two AAA batteries as indicated. The remote allows you to power on/off, adjust volume, change channels, access smart TV functions, and use voice control.

### 2. Google TV Interface

Navigate the Google TV interface to access your favorite streaming services like Netflix, Prime Video, YouTube, Disney+, Hulu, Apple TV+, and more. The home screen provides personalized content recommendations and easy access to installed apps.

# AIPQ PRO PROCESSOR POWERED BY GOOGLE TV

Enjoy a smarter way to watch with Google TV. All your streaming services, live TV, and on-demand content are organized on one intuitive screen, making it easy to jump into what you want.



Works with



Screen Mirroring



Voice Control




Hey Google

*The Google TV interface on the Titan G100 provides access to a wide range of streaming applications and content.*

### 3. Voice Control

Utilize the built-in voice control feature (compatible with Hey Google and Amazon Alexa) to search for content, control playback, and manage smart home devices hands-free. Press the voice assistant button on your remote and speak your command.



*Control your Titan G100 Outdoor TV hands-free using voice commands for a seamless entertainment experience.*

## 4. Connectivity

The TV offers multiple connectivity options:

- **HDMI:** 3 HDMI ports for connecting gaming consoles, laptops, and other devices.
- **USB:** 2 USB 3.0 ports for media playback or connecting peripherals.
- **Bluetooth 5.1:** Connect wireless speakers, headphones, or other Bluetooth-enabled devices.
- **Wi-Fi:** For internet access and streaming.
- **Ethernet:** For a stable wired internet connection.
- **Screen Mirroring:** Supports AirPlay 2 for casting content from mobile devices.



## HEAR EVERY DETAIL IN STUNNING CLARITY

Experience sound the way it was meant to be heard. Dolby Atmos creates a three-dimensional soundstage that flows above and around you, adding depth and realism to every scene.

Audio by Bang & Olufsen



*The Titan G100 offers versatile connectivity options including Wi-Fi, HDMI, and USB for all your entertainment needs.*

### 5. Audio Features

Experience immersive sound with Onkyo speakers and support for Dolby Atmos, Dolby Vision, DTS:X, and IMAX Enhanced audio formats. Adjust audio settings in the TV menu to optimize your listening experience.

Your browser does not support the video tag.

*Video showcasing the Titan Outdoor TV's performance during a rainy day, demonstrating its durability and picture quality in challenging outdoor conditions.*

## MAINTENANCE

### 1. Cleaning the TV

To clean the screen and frame, first unplug the TV from the power outlet. Use a soft, lint-free cloth lightly dampened with

water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen. Avoid using harsh chemicals, solvents, or abrasive materials.

## 2. Weather Resistance (IP65)

The Titan G100 TV has an IP65 rating, meaning it is protected against dust ingress and low-pressure water jets from any direction. This makes it suitable for covered outdoor environments. However, it is not designed for direct exposure to heavy rain, snow, or submersion. Always ensure all port covers are securely fastened to maintain water resistance.



*The IP65 rating ensures the Titan G100 Outdoor TV is weatherproof and water-resistant for reliable performance in covered outdoor areas.*

Your browser does not support the video tag.

*Video comparing a coated Titan TV circuit board with an uncoated one, highlighting the internal weatherproofing for enhanced durability.*

## 3. Using the TV Cover

For extended periods of non-use or during severe weather, use the provided TV cover to offer additional protection against dust, debris, and moisture. Ensure the TV is completely cool and dry before applying the cover.

## TROUBLESHOOTING

If you encounter issues with your Titan G100 TV, refer to the following common solutions:

Problem	Possible Cause	Solution
<b>No Power</b>	Power cable disconnected, power outlet issue, remote batteries dead.	Check power cable connection. Test the outlet with another device. Replace remote batteries.
<b>No Picture, but Sound</b>	Incorrect input source, external device issue.	Press the "Input" button on the remote to select the correct source. Check connections to external devices.
<b>No Sound, but Picture</b>	Volume muted or too low, external audio system issue.	Unmute volume or increase level. Check connections to soundbar/speakers.
<b>Wi-Fi Connection Issues</b>	Router too far, incorrect password, network interference.	Move router closer or use an extender. Re-enter Wi-Fi password. Restart router and TV.
<b>Remote Not Responding</b>	Dead batteries, obstruction, pairing issue.	Replace batteries. Remove obstructions. Re-pair Bluetooth remote if applicable (refer to Google TV settings).

If the problem persists after trying these solutions, please contact Titan customer support.

## SPECIFICATIONS

Detailed technical specifications for the Titan G100 Mini 85 Inch Outdoor TV:

Feature	Detail
<b>Model Name</b>	G100-QLED-85
<b>Screen Size</b>	85 Inches
<b>Display Technology</b>	QLED, Mini-LED, Full Array Local Dimming
<b>Resolution</b>	4K UHD (3840 x 2160)
<b>Refresh Rate</b>	144 Hz
<b>Maximum Brightness</b>	1000 Nits
<b>HDR Support</b>	Dolby Vision, HDR10, HDR10+, HLG
<b>Operating System</b>	Google TV
<b>Audio Output</b>	Onkyo Speakers, Dolby Atmos, DTS:X, Dolby Digital Plus, IMAX Enhanced
<b>Connectivity</b>	3x HDMI, 2x USB 3.0, Wi-Fi, Bluetooth 5.1, Ethernet
<b>Weather Resistance</b>	IP65 Rated

Feature	Detail
Product Dimensions (DxWxH)	2.3"D x 74.4"W x 42.8"H
Item Weight (without stand)	71.8 Pounds
VESA Mount Standard	400 x 400 mm
Power Input	120 Volts



*The Titan G100 series is available in multiple sizes, with the 85-inch model offering a large viewing experience.*

## WARRANTY AND SUPPORT

### Warranty Information

The Titan G100 Mini 85 Inch Covered Patio Outdoor TV comes with a **2-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or exposure to conditions beyond the product's specified IP65 rating (e.g., direct heavy rain, submersion, extreme temperatures).

### Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty service, please contact Titan customer support. Refer to the contact information provided with your purchase or visit the official Titan website for the most up-to-date support details.

**Online Resources:** [Visit the Titan Store on Amazon](#)

