

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Vente-unique](#) /
- › [Vente-unique CARMEO Complete Kitchen Unit Instruction Manual](#)

Vente-unique CARMEO

Vente-unique CARMEO Complete Kitchen Unit Instruction Manual

Model: CARMEO

1. INTRODUCTION

This manual provides essential information for the assembly, safe use, and maintenance of your Vente-unique CARMEO Complete Kitchen Unit. Please read these instructions carefully before beginning assembly or using the product. Retain this manual for future reference.



Image 1.1: Overview of the Vente-unique CARMEO Complete Kitchen Unit.

2. SAFETY WARNINGS

Important: Failure to follow these safety instructions may result in injury or damage to the product.

- Ensure the worktop's maximum load capacity of **15 kg** is not exceeded.
- Ensure the maximum load capacity of suspended wall cabinets is **10 kg**.
- Ensure the maximum load capacity of drawers is **5 kg**.
- Proper wall mounting is crucial for stability and safety. If unsure, seek professional assistance for installation.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Always use appropriate tools for assembly and follow all steps in the correct order.

3. PRODUCT COMPONENTS

The CARMEO Complete Kitchen Unit includes six storage elements and a worktop. No appliances are

included.

3.1. Upper Cabinets (Wall-mounted)

- **Left Upper Cabinet:** 2 doors, 1 interior shelf. Dimensions: L90 x D32 x H60 cm.
- **Middle Upper Cabinet:** 1 door, 1 interior shelf. Dimensions: L50 x D32 x H60 cm.
- **Right Upper Cabinet for Hood:** 1 door. Designed to accommodate an extractor hood. Dimensions: L60 x D32 x H40 cm.

3.2. Lower Cabinets (Base Units)

- **Left Lower Cabinet:** 2 doors. Dimensions: L90 x D56 x H82 cm.
- **Middle Lower Cabinet:** 1 drawer, 1 door, 1 interior shelf. Dimensions: L49.5 x D56 x H82 cm.
- **Right Lower Cabinet for Oven:** 1 niche. Designed to accommodate an oven. Dimensions: L60 x D56 x H82 cm. Oven niche dimensions: L60 x D56 x H60 cm.

3.3. Worktop

- Included with the unit. Material: HPL (High-Pressure Laminate), resistant to water and heat.



Image 3.1: Interior view of CARMEO kitchen cabinets.

4. SETUP AND ASSEMBLY

Assembly of the Vente-unique CARMEO kitchen unit requires basic tools and adherence to the provided assembly diagrams (not included in this manual, refer to packaging). It is recommended to assemble with

at least two people.

4.1. Preparation

- Unpack all components and verify against the parts list.
- Ensure you have all necessary tools (e.g., screwdriver, hammer, level, drill for wall mounting).
- Clear a spacious, clean area for assembly.

4.2. Base Unit Assembly

1. Assemble the frames for each lower cabinet according to the manufacturer's instructions.
2. Install shelves, drawers, and doors as specified for each unit.
3. Position the assembled lower cabinets in their desired location.
4. Place the worktop onto the lower cabinets, ensuring it is level and securely fastened.

4.3. Upper Cabinet Assembly and Mounting

1. Assemble the frames for each upper cabinet.
2. Install shelves and doors.
3. Mark the wall for mounting points, ensuring they are level and appropriate for the cabinet weight.
4. Drill pilot holes and install wall anchors suitable for your wall type.
5. Mount the upper cabinets securely to the wall. Verify stability before loading.



Image 4.1: Assembled CARMEO kitchen unit in a kitchen environment.

5. OPERATING AND USAGE

The CARMEO kitchen unit is designed for general kitchen storage and food preparation.

- Utilize the various cabinets and drawers for organized storage of kitchenware, groceries, and other items.
- The worktop provides a durable surface for food preparation. Avoid cutting directly on the surface; always use a cutting board.
- The designated niche in the right lower cabinet is for a standard-sized oven. Ensure proper ventilation as per oven manufacturer guidelines.
- The right upper cabinet is designed to accommodate an extractor hood. Ensure the hood is installed correctly and securely.
- Distribute weight evenly within cabinets and on the worktop to maintain stability and prevent damage.

6. MAINTENANCE

Regular cleaning and proper care will extend the life and appearance of your kitchen unit.

- **Cleaning Surfaces:** Wipe all surfaces with a soft, damp cloth and a mild, non-abrasive cleaner. Dry immediately with a clean cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemical agents, as these can damage the finish.
- **Spills:** Clean up spills immediately, especially on the worktop, to prevent staining or water damage.
- **Heat Protection:** Although the HPL worktop is heat-resistant, always use trivets or heat pads under hot pots and pans to prevent potential damage.
- **Hardware:** Periodically check all screws, hinges, and fittings to ensure they are tight. Tighten if necessary.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Cabinet doors do not align properly.	Hinges are loose or improperly adjusted.	Adjust the screws on the hinges to align the doors. Refer to hinge adjustment instructions (usually found with hinge hardware).
Drawers do not slide smoothly.	Drawer runners are misaligned or dirty.	Check that drawer runners are correctly installed and aligned. Clean any debris from the runners.
Unit feels unstable.	Wall mounting is not secure or base units are not level.	Re-check all wall fixings for upper cabinets. Ensure base units are level using adjustable feet (if present) or shims. Verify weight distribution.

8. SPECIFICATIONS

Feature	Detail
Brand	Vente-unique

Feature	Detail
Model	CARMEO
Color	Beige
Material	Particle board, HPL (worktop), Wood
Overall Dimensions (L x W x H)	200 x 60 x 82 cm (Lower units)
Upper Unit Dimensions (L x W x H)	200 x 32 x 60 cm (Total)
Weight	131.2 kg
Maximum Worktop Capacity	15 kg
Maximum Suspended Cabinet Capacity	10 kg
Maximum Drawer Capacity	5 kg
Oven Niche Dimensions (L x W x H)	60 x 56 x 60 cm
Origin	France

9. WARRANTY AND SUPPORT

For information regarding warranty coverage, spare parts availability, or customer support, please refer to the documentation provided with your purchase or contact Vente-unique customer service directly.

Note: Spare parts availability information is not provided in the product details.