

HotTopStar S6

HotTopStar 3-in-1 Wireless Charging Station S6 User Manual

Model: S6

1. INTRODUCTION

The HotTopStar S6 is a versatile 3-in-1 wireless charging station designed to efficiently charge your compatible iPhone (12-16 series), Apple Watch, and AirPods simultaneously. This device features a magnetic charging interface for iPhones, an aluminum unibody construction for enhanced durability and heat dissipation, and a foldable, adjustable design for convenience and portability.

2. PRODUCT OVERVIEW

The HotTopStar S6 charging station integrates multiple features to provide a streamlined charging experience:

- **3-in-1 Charging:** Simultaneously charges an iPhone, Apple Watch, and AirPods.
- **Aluminum Unibody Design:** Constructed from premium aluminum alloy for effective heat dissipation and a non-slip silicone base for stability.
- **Multi-View Adjustment:** Supports both vertical and horizontal phone charging. The phone holder offers adjustable angles and three adjustable heights for optimal viewing.
- **Foldable Design:** Allows for compact storage and easy portability, making it suitable for travel.
- **Magnetic Charging:** Provides secure and efficient magnetic alignment for compatible iPhones.
- **Fast Charging:** Delivers up to 15W for iPhone, 5W for AirPods, and 2.5W for Apple Watch.
- **Safety Protections:** Built-in safeguards against over-current, over-voltage, overcharge, and over-temperature to protect your devices.



Figure 2.1: The HotTopStar S6 charging station with an iPhone, Apple Watch, and AirPods placed on their respective charging areas.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x HotTopStar 3-in-1 Wireless Charging Station (Model S6)
- 1 x USB-C to USB-C Cable (3.3 ft / 1m)
- 1 x User Manual

4. SETUP INSTRUCTIONS

Follow these steps to set up your charging station:

1. **Unfold the Vertical Pole:** When you receive the charging station, the vertical pole may be folded. Gently unfold it to an upright position.
2. **Secure the Vertical Pole:** Locate the circular plastic spacer at the bottom of the vertical pole. Rotate this spacer clockwise until the pole is firmly fixed and stable.
3. **Connect Power:** Connect one end of the provided USB-C to USB-C cable to the charging port on the back of the station. Connect the other end to a compatible USB-C power adapter (not included). For optimal fast charging performance, a 25W or higher USB-C power adapter is recommended.



Figure 4.1: Illustration of the adjustable and foldable design of the charging stand.



Figure 4.2: Step-by-step visual guide for unfolding and extending the charging station.

5. OPERATING INSTRUCTIONS

Once the charging station is set up and connected to power, you can begin charging your devices:

1. **Charge iPhone:** Place your compatible iPhone onto the magnetic charging pad. The phone will magnetically snap into place, and charging will begin automatically. The charging indicator lights on the

base will illuminate.

2. **Charge Apple Watch:** Place your Apple Watch onto the dedicated charging puck. Ensure it is properly aligned for charging to initiate.
3. **Charge AirPods:** Place your AirPods case onto the designated wireless charging area on the base.
4. **Adjust Viewing Angle/Height:** The phone holder can be rotated 360 degrees and tilted up to 70 degrees. The vertical pole also offers three adjustable height levels. Adjust these to your preferred viewing angle and height.



Figure 5.1: The charging station in use, charging an iPhone, Apple Watch, and AirPods simultaneously.



Figure 5.2: The phone charging pad offers adjustable angles for comfortable viewing.

6. COMPATIBILITY

The HotTopStar S6 is compatible with the following devices:

- **iPhones:** iPhone 16 series, iPhone 15 series (including Plus/Pro/Pro Max), iPhone 14 series (including Plus/Pro/Pro Max), iPhone 13 series (including Pro/Pro Max/mini), iPhone 12 series (including Pro/Pro Max/mini).
- **Apple Watch:** Apple Watch Ultra, Series 9, Series 8, Series 7, Series 6, Series 5, Series 4, Series 3, Series 2, SE. *Note: Not compatible with Apple Watch Series 10.*
- **AirPods:** AirPods Pro, AirPods (3rd Generation), AirPods (2nd Generation).

Keeping the desk neat and tidy




Figure 6.1: Overview of device compatibility and corresponding charging speeds.

7. SAFETY INFORMATION

To ensure safe operation and prolong the life of your device, please observe the following safety guidelines:

- Use only the provided USB-C cable and a compatible power adapter (minimum 25W recommended for optimal performance).
- Do not expose the charging station to water, moisture, or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the device yourself. Contact customer support if service is required.
- Avoid placing metal objects or foreign materials on the charging surfaces, as this may interfere with charging or cause overheating.
- The charging station features built-in over-current, over-voltage, overcharge, and over-temperature protection mechanisms to safeguard your devices.

8. MAINTENANCE

Proper care will ensure the longevity of your charging station:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry, lint-free cloth to wipe the surfaces of the charging station.
- **Avoid Chemicals:** Do not use harsh chemicals, cleaning solvents, or strong detergents, as these may damage the device's finish or internal components.
- **Storage:** When not in use for extended periods, store the charging station in a cool, dry place, away from direct sunlight.

9. TROUBLESHOOTING

If you encounter issues with your charging station, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging	<ol style="list-style-type: none"> 1. Loose power connection 2. Device not properly aligned 3. Incompatible device 4. Foreign object on charging pad 	<ol style="list-style-type: none"> 1. Ensure USB-C cable is securely connected to both the station and power adapter. 2. Reposition the device on the charging pad to ensure proper alignment. 3. Verify device compatibility (refer to Section 6). 4. Remove any metal objects or foreign materials from the charging surface.
Slow charging	<ol style="list-style-type: none"> 1. Insufficient power adapter wattage 2. Using USB-A to USB-C cable with low-wattage adapter 	<ol style="list-style-type: none"> 1. Use a USB-C power adapter with a minimum output of 25W. 2. Ensure you are using a suitable USB-C to USB-C cable and a high-wattage USB-C power adapter.
Vertical pole is unstable	Plastic spacer not locked	Rotate the circular plastic spacer at the bottom of the vertical pole clockwise until it is firmly secured.
Charging indicator lights are off	<ol style="list-style-type: none"> 1. No power 2. Device not detected 	<ol style="list-style-type: none"> 1. Check power connection to the wall outlet and the charging station. 2. Re-place the device on the charging pad.

10. SPECIFICATIONS

Model Number	S6
Input Voltage	5 Volts
Input Amperage	3 Amps
Output Wattage (iPhone)	15W Max
Output Wattage (AirPods)	5W Max
Output Wattage (Apple Watch)	2.5W Max
Connector Type	USB Type C
Material	Aluminum
Item Weight	0.35 Kilograms
Parcel Dimensions	23 x 17 x 4.7 cm
Special Features	Charging Indicator, Fast Charging, Lightweight Design, Magnetic, Travel, Adjustable Stand
Manufacturer	Shenzhen Aodehong Electronic Technology Co., Ltd.

11. WARRANTY AND SUPPORT

Warranty: This HotTopStar S6 Wireless Charging Station comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. Please retain your proof of purchase for warranty claims.

Customer Support: For any questions, technical assistance, or warranty claims, please contact HotTopStar customer service. Refer to the contact information provided with your purchase or on the official HotTopStar website.