

Cosy Life YT-100w

Cosy Life Portable Shower User Manual

Model: YT-100w

1. INTRODUCTION

Thank you for choosing the Cosy Life Portable Shower. This device is designed to provide a convenient and efficient showering solution for various outdoor activities such as camping, hiking, and even pet bathing. Featuring a smart LED display, a powerful 6000mAh battery, and multiple spray patterns, this portable shower ensures a comfortable and reliable experience wherever you go.

Please read this manual thoroughly before using the product to ensure proper operation, maintenance, and to maximize its lifespan.

2. PRODUCT COMPONENTS

The Cosy Life Portable Shower kit includes the following items:

- Digital Shower Pump with Smart LED Display
- Shower Head with Multiple Spray Patterns
- Collapsible 5-Gallon Bucket
- Hose (5.9 ft)
- Type-C Charging Cable
- Mounting Accessories (Hook, Suction Cup)
- Camping Shower Bag



Image: All components of the Cosy Life Portable Shower kit, including the main pump unit, shower head, hose, and collapsible bucket.

3. FEATURES

- **Smart Digital Display:** The pump features an LED screen that shows real-time power percentage and water temperature. The temperature indicator changes color: green for 35-45°C, blue for below 35°C, and red for above 45°C. This allows for precise monitoring during use.



Image: Detailed view of the smart LED display on the shower pump, indicating digital battery level and precision temperature.

- **Multi-functional Performance:** Equipped with a PP filtration system to filter sediment and dust from water, ensuring cleaner water for skin. Four suction feet at the bottom of the pump provide stability when submerged in a bucket. The reliable motor operates with reduced noise for a quiet showering experience.
- **Large Capacity Rechargeable Battery:** A built-in 6000mAh Lithium-Ion battery provides 120-150 minutes of continuous use after a 3-4 hour charge. It supports Type-C charging via mobile phone chargers (5V 0.5-2A), laptops, or car USB outputs. The charging interface has a waterproof cover for safe outdoor use.

6000mAh

Duration of Continuous Use 120-150 Minutes



Image: An internal view of the shower pump highlighting the 6000mAh battery and indicating its long duration of continuous use.

- **Multiple Spray Patterns:** The shower head offers three distinct water dispensing modes: Soft Mode, Energy-Saving Mode, and Strong Mode. Additionally, a separate spray nozzle is included for tasks like car cleaning or pet washing.



Image: Visual representation of the four different water dispensing modes available with the portable shower.

- **Versatile Mounting Options:** The shower head can be fixed using a suction cup on flat surfaces for indoor showering or hung on a tree branch with the included hook for outdoor camping. This allows for hands-free operation.

Free your hands



Image: Demonstrations of how to use the hook and suction cup to free your hands while showering outdoors or indoors.

- **IPX7 Waterproof:** The pump unit is designed with IPX7 waterproofing, ensuring durability and safety in wet environments.



Image: An exploded view illustrating the IPX7 waterproof construction of the shower pump.

4. SETUP INSTRUCTIONS

1. **Charge the Pump:** Before first use, fully charge the shower pump using the provided Type-C charging cable. Connect the cable to the pump's charging port (ensure the waterproof cover is open during charging) and to a compatible USB power source (e.g., phone charger, laptop, power bank). The LED display will indicate charging status. Once fully charged, close the waterproof cover.
2. **Connect Components:** Attach the hose securely to the outlet on the top of the shower pump. Then, connect the shower head to the other end of the hose.
3. **Prepare Water Source:** Fill the collapsible 5-gallon bucket with fresh water. Ensure the water level is sufficient for your intended use.
4. **Submerge Pump:** Place the shower pump into the filled bucket, ensuring it is fully submerged. The four suction feet at the bottom of the pump will help stabilize it.



Cover the charging port when using



Connect pump and shower head to hose

Easy to operate and use



Long press the switch and attach it to the bucket



Press shower switch and adjust water level

Image: A visual guide demonstrating the easy steps to operate and use the portable shower.

5. OPERATING INSTRUCTIONS

1. **Power On:** Once the pump is submerged, long-press the power button on the top of the pump to turn it on. The LED display will illuminate, showing battery level and water temperature.
2. **Select Spray Mode:** Use the switch or button on the shower head to cycle through the available water dispensing modes (Soft, Energy-Saving, Strong).
3. **Adjust Water Flow:** Some shower heads may have an additional control to adjust the water flow intensity.
4. **Use Mounting Accessories:** For hands-free showering, attach the shower head to a flat surface using the suction cup or hang it from a tree branch with the hook.
5. **Utilize Spray Nozzle:** If cleaning a car or pet, detach the shower head and attach the dedicated spray nozzle for a more focused stream.
6. **Power Off:** After use, long-press the power button on the pump to turn it off.

Wide applications



Image: Examples of wide applications for the portable shower, including personal showering, pet bathing, gardening, and vehicle cleaning.

6. MAINTENANCE

- **Cleaning:** After each use, especially with dirty water, rinse the pump, hose, and shower head with clean water. Ensure no debris is lodged in the pump's intake or the shower head nozzles.
- **Filter Cleaning:** Periodically check and clean the PP filtration element in the pump to maintain optimal water flow and filtration efficiency.
- **Drying:** Allow all components to air dry completely before storing to prevent mold or mildew growth.
- **Storage:** Store the portable shower kit in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the collapsible bucket is clean and dry before folding for storage.
- **Battery Care:** For long-term storage, charge the battery to approximately 50-70% every 3-6 months to preserve battery health.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No water flow or weak flow	Low battery; Pump not fully submerged; Kinked hose; Clogged filter/nozzle.	Charge battery; Ensure pump is fully submerged; Straighten hose; Clean filter/nozzle.
Pump not turning on	Battery depleted; Power button not pressed long enough.	Charge battery; Long-press the power button (approx. 3 seconds).
LED display not working	Battery depleted; Unit malfunction.	Charge battery. If issue persists, contact customer support.
Water temperature reading inaccurate	Sensor obstruction or malfunction.	Ensure sensor area is clean. If issue persists, contact customer support.

8. SPECIFICATIONS

Attribute	Value
Brand	Cosy Life
Model Number	YT-100w
Power Source	Battery Powered
Battery Capacity	6000mAh Lithium Ion
Voltage	12 Volts (DC)
Hose Length	5.9 ft
Material	Plastic
Item Weight	2.77 pounds
Package Dimensions	12.17 x 6.89 x 4.33 inches
Waterproof Rating	IPX7

9. WARRANTY AND SUPPORT

The Cosy Life Portable Shower is backed by a manufacturer's warranty. Please refer to the product packaging or the seller's information for specific warranty terms and duration.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Cosy Life customer service through the retailer where you purchased the product. Keep your purchase receipt as proof of purchase.

