

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Tulbeys](#) /

› Tulbeys E62 Bluetooth 5.4 Clip-On Headphones User Manual

Tulbeys E62

Tulbeys E62 Bluetooth 5.4 Clip-On Headphones User Manual

Model: E62

1. INTRODUCTION

Thank you for choosing the Tulbeys E62 Bluetooth 5.4 Clip-On Headphones. This manual provides detailed instructions for the proper use, setup, and maintenance of your new wireless earbuds. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

- Tulbeys E62 Clip-On Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual

3. PRODUCT OVERVIEW

The Tulbeys E62 Clip-On Headphones feature an ergonomic design for secure placement and an open-ear listening experience. The compact charging case provides portable power for extended use.



Image: The Tulbeys E62 Clip-On Earbuds shown with their charging case. The earbuds are rosegold in color, with one earbud partially inserted into its charging slot and the other earbud positioned above the open case, highlighting its clip-on design and charging contacts.

Key Features:

- **Clip-On Design:** Ergonomically designed for a secure and comfortable fit.
- **Bluetooth 5.4:** Provides a stable and fast wireless connection.
- **Open Ear Design:** Allows awareness of surroundings while listening.
- **Touch Control:** Intuitive control for various functions.
- **IPX5 Water Resistance:** Suitable for sports and outdoor activities.

4. SETUP

4.1 Charging the Earbuds and Case

1. **Charging the Case:** Connect the provided USB-C cable to the charging port on the case and the other end to a USB power adapter (not included). The indicator lights on the case will show charging status.
2. **Charging the Earbuds:** Place the earbuds into their respective slots in the charging case. Ensure the

charging contacts align. The earbuds will begin charging automatically.

A full charge provides approximately 5 hours of playback for the earbuds, with the charging case extending total playback time up to 35 hours.

4.2 Bluetooth Pairing

1. **Power On:** Open the charging case, and the earbuds will automatically power on and enter pairing mode.
2. **Activate Bluetooth:** On your device (smartphone, tablet, etc.), enable Bluetooth.
3. **Select Device:** Search for "Tulbeys E62" in the list of available Bluetooth devices and select it to connect.
4. **Confirmation:** Once connected, a voice prompt will confirm successful pairing.

The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

5. OPERATING INSTRUCTIONS

5.1 Wearing the Earbuds

Gently clip the earbuds onto your earlobe, ensuring the speaker is positioned towards your ear canal. Adjust for a comfortable and secure fit. The ergonomic design helps the earbuds stay in place during various activities.

5.2 Basic Touch Controls

The E62 earbuds feature touch-sensitive controls. Specific functions may vary slightly by device, but common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Voice Assistant:** Triple tap on either earbud.

Refer to your device's audio settings for further customization of controls if available.

6. MAINTENANCE

6.1 Cleaning

Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals. Ensure charging contacts are free of dust and debris.

6.2 Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.

6.3 Water Resistance

The earbuds are rated IPX5 water-resistant, meaning they can withstand splashes and sweat. They are not designed for submersion in water. Do not use them while swimming or showering.

7. TROUBLESHOOTING

- **Earbuds not pairing:** Ensure earbuds are charged and within range of your device. Turn off and on your device's Bluetooth, then try pairing again.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again to re-sync.
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Charging issues:** Verify the USB-C cable is securely connected to both the case and the power source. Clean the charging contacts on the earbuds and inside the case.

If issues persist, refer to the support section or contact customer service.

8. SPECIFICATIONS

Model Name	E62
Brand	Tulbeys
Connectivity Technology	Wireless (Bluetooth 5.4)
Form Factor	On Ear / Clip-On
Control Method	Touch
Battery Type	Lithium Polymer
Earbud Playtime	Up to 5 hours
Total Playtime (with case)	Up to 35 hours
Wireless Range	Up to 33 feet (10 meters)
Water Resistance	IPX5
Product Dimensions	3.1 x 1 x 1.3 inches
Item Weight	1.41 ounces (40 Grams)

9. SAFETY INFORMATION

- Do not disassemble or modify the product.
- Keep away from extreme temperatures, direct sunlight, and moisture.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Dispose of batteries and electronic components responsibly according to local regulations.

10. WARRANTY AND SUPPORT

Tulbeys products are designed for reliability and performance. For warranty information or technical support, please refer to the purchase platform or contact Tulbeys customer service directly. Please have your model number (E62) and purchase details available when contacting support.

