TVON TV Stand with Mount

TVON Universal Floor TV Stand with Mount for 32-65 Inch TVs

Model: TV Stand with Mount

Introduction

Thank you for choosing the TVON Universal Floor TV Stand. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new TV stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

Important: Ensure your TV's weight and VESA pattern are within the specified limits before installation. Exceeding these limits can result in instability and potential injury or damage.

- Do not exceed the maximum weight capacity of 88 lbs (40 kg).
- Ensure the TV's VESA mounting pattern is between 100x100mm and 400x400mm.
- Always assemble the stand on a soft, clean surface to prevent scratches.
- Keep children and pets away during assembly.
- Regularly check all screws and connections to ensure they remain tight and secure.
- The stand features an innovative anti-tip design with reinforced base and 45-degree angled rear supports for enhanced stability.



This image illustrates the innovative safety base design, highlighting the supporting feet and non-slip pads for enhanced stability and drill-free assembly.

Package Contents

Please verify that all components are present and undamaged before proceeding with assembly. If any parts are missing or damaged, contact customer support.

- Wooden Base
- Main Support Pole
- TV Mounting Bracket
- Mounting Arms (2)
- Hardware Kit (various screws, washers, spacers)
- Cable Management Clips
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual

Setup and Assembly

The TVON Floor TV Stand is designed for straightforward, drill-free assembly. Follow the steps below for proper installation.

1. **Attach the Main Support Pole to the Base:** Securely fasten the main support pole to the wooden base using the provided screws and tools. Ensure the connection is firm.
2. **Install the TV Mounting Bracket:** Attach the TV mounting bracket to the main support pole at your desired initial height.
3. **Attach Mounting Arms to TV:** Carefully place your TV face down on a soft, clean surface. Attach the two mounting arms to the back of your TV using the appropriate VESA screws, washers, and spacers from the hardware kit. Ensure the arms are level and securely fastened.
4. **Mount TV to Stand:** With assistance, carefully lift the TV and hook the mounting arms onto the TV mounting bracket on the stand. Engage the safety locks to prevent accidental dislodgement.
5. **Cable Management:** Use the integrated cable management system and provided clips to route and organize your TV and device cables along the main support pole for a neat and tidy setup.



This image details the stand's features: a thick wooden base, non-slip feet to prevent noise and scratches, a compact footprint (13.3" x 9"), and integrated cable management for an organized setup.

Assembly Video Guide

Your browser does not support the video tag.

This official video demonstrates the assembly process and key features of the TVON Universal Floor TV Stand, including height adjustment, safety lock, and integrated cable management.

Operating Instructions

Your TVON Floor TV Stand offers flexible viewing options for an optimal experience.

Height Adjustment

The stand allows for 3 height adjustments, ranging from 51.7 inches to 54 inches. To adjust the height, loosen the securing bolts on the main support pole, carefully raise or lower the TV to the desired position, and then re-tighten the

bolts firmly. Ensure the TV is level after adjustment.



This image demonstrates the height adjustment feature, allowing the TV to be positioned between 51.7 and 54 inches for optimal eye-level viewing.

Swivel Function

The TV mount features a 70-degree swivel range (±35 degrees left or right). Gently push the sides of your TV to rotate it to your preferred viewing angle. This allows for glare reduction and improved viewing from various positions in the room.



This image illustrates the 70-degree swivel capability (±35 degrees), providing flexible viewing angles to reduce glare and enhance comfort.

Maintenance

To ensure the longevity and appearance of your TV stand, follow these maintenance guidelines:

- **Cleaning:** Wipe the stand with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Inspections:** Periodically check all bolts and connections to ensure they are tight. Loose connections can affect stability.
- **Avoid Overloading:** Do not place items on the base or mount that exceed the recommended weight capacity.

Troubleshooting

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Stand is Unstable:** Ensure all screws are tightened securely. Verify that the TV's weight and size are within the

specified limits. Check that the stand is placed on a flat, level surface.

- **TV Not Level:** Re-check the mounting arms and bracket installation. Adjust the height and ensure all connections are even before tightening.
- **Difficulty Swiveling:** Ensure no cables are obstructing the swivel mechanism. The swivel should move smoothly with gentle pressure.
- **Missing Parts:** If any parts were missing upon arrival, contact TVON customer support immediately for replacements.

Specifications

Feature	Detail
Mounting Type	Floor Mount
Movement Type	Swivel & Height Adjustable
Compatible TV Sizes	32-65 inches
Maximum Weight Capacity	88 lbs (40 kg)
VESA Mounting Patterns	100x100mm to 400x400mm
Height Adjustment Range	51.7 inches to 54 inches
Swivel Range	±35 degrees (70 degrees total)
Material	Alloy Steel, Wood
Color	WHITE
Base Dimensions	Approx. 16.7 inches x 12.2 inches (42.4 cm x 31 cm)


Wide Compatibility



This diagram illustrates the wide compatibility of the TV stand, detailing supported TV sizes (32-65 inches), maximum weight (88 lbs), and VESA mounting patterns from 100x100mm to 400x400mm.

WILL THIS TV STAND FIT MY TV?

Check: VESA
Min VESA -- 100(w)mm x 100(h)mm
Max VESA -- 400(w)mm x 400(h)mm




VESA= Width x Height

Check: TV Size



Size: 32"- 65"

Check: TV Weight



Weight: 88 lbs

VESA PATTERNS	W x H			
		100 x 100 MM	300 x 200 MM	400 x 300 MM
		200 x 100 MM	300 x 300 MM	400 x 400 MM
		200 x 200 MM	400 x 200 MM	

This chart provides a comprehensive guide to VESA compatibility, listing various VESA patterns and their corresponding width and height measurements to ensure a proper fit for your TV.

Warranty

This TVON Universal Floor TV Stand is covered by a**5-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty documentation included with your product or contact TVON customer support.

Customer Support

For any questions, assistance with assembly, troubleshooting, or warranty inquiries, please contact TVON customer support. Refer to the contact information provided in your product packaging or visit the official TVON website for support resources.
We are committed to providing excellent customer service and ensuring your satisfaction with our products.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question