

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Sportneer](#) /

› Sportneer Portable Air Pump User Manual

Sportneer B0DMVZGR6N

Sportneer Portable Air Pump User Manual

Model: B0DMVZGR6N

INTRODUCTION

This manual provides detailed instructions for the safe and effective operation, setup, and maintenance of your Sportneer Portable Air Pump. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The Sportneer Portable Air Pump is a compact, multi-functional device designed for inflating and deflating various items, as well as providing portable lighting. Its small size and magnetic design make it suitable for outdoor activities and everyday use.



Image: The Sportneer Portable Air Pump shown with its included accessories, including different nozzles and a USB-C charging cable.

Key Components

3 in 1 Portable Air Pump



Magnet Design

3000Gs

Air Pressure

4.5 kPa

Air Flow

180 L/min

Lightweight

3.6 oz

Image: A detailed diagram highlighting the deflation port, inflation port, Type-C charging port, switch button, and internal safe net of the air pump.

- **Deflation Port:** Located at the top, used for deflating items.
- **Inflation Port:** Located at the bottom, used for inflating items.
- **Type-C Charging Port:** For recharging the internal battery.
- **Switch Button:** Controls power for the pump and light. Double-click to activate the pump, long press to activate the light.
- **Safe Net:** Prevents foreign objects from entering the pump.
- **Magnetic Base:** Allows the pump to attach to ferromagnetic surfaces.
- **Camping Light:** Integrated LED light at the bottom.

SPECIFICATIONS

Feature	Detail
Air Pressure	4.5 kPa

Air Flow	180 L/min
Weight (Pump only)	3.6 oz (102g)
Dimensions	1.8" x 1.8" x 2.3" (approx. 4.5 x 4.5 x 5.8 cm)
Battery Capacity	1600mAh
Charging Port	Type-C
Light Brightness Levels	3 (60 lumens, 160 lumens, 300 lumens)
Nozzles Included	5 different nozzles for various inflatables

SETUP

Initial Charging

Before first use, fully charge the Sportneer Portable Air Pump. Connect the included Type-C charging cable to the pump's charging port and a suitable power source (e.g., power bank, laptop, car charger, or wall adapter).

Fast Charging

Long battery life in a compact size



0-99%



100%



Please don't open the pump while charging

Image: The pump's charging indicator lights: red for 0-99% charge, green for 100% charged. Do not operate the pump while charging.


- The indicator light will be **red** when charging (0-99% battery).
- The indicator light will turn **green** when fully charged.
- If the battery is below 5%, the light will turn red to remind you to charge.
- **Important:** Do not operate the pump continuously for more than 10 minutes. Do not open the pump while charging.

Attaching Nozzles


The pump comes with 5 different nozzles to fit various inflatable products. Select the appropriate nozzle for your item.

5 Different Nozzles


Sleeping Pad





Swimming Rings




Vacuum Bags



Air Mattress



Blowing Campfire



Not suitable
for these products



Image: A visual guide to the five included nozzles and their intended uses, such as for sleeping pads, swimming rings, vacuum bags, air mattresses, and assisting with campfires. Note: Not suitable for balloons, sports balls, tires, inflatable paddleboards, or kayaks.

To attach a nozzle, firmly insert it into the desired port (inflation or deflation) until secure.

OPERATING INSTRUCTIONS

Inflation

1. Select the correct nozzle for the item you wish to inflate.
2. Attach the chosen nozzle to the **inflation port** (bottom of the pump).
3. Insert the nozzle into the valve of the item to be inflated.
4. Double-click the switch button to turn on the pump.
5. Inflate the item to the desired firmness.
6. Double-click the switch button again to turn off the pump.



Image: A three-step visual guide demonstrating how to inflate an item: 1. Choose the right nozzle. 2. Attach the nozzle to the bottom air port. 3. Double-click to turn on the pump.

Deflation

1. Select the correct nozzle for the item you wish to deflate (often the same nozzles can be used).
2. Attach the chosen nozzle to the **deflation port** (top of the pump).
3. Insert the nozzle into the valve of the item to be deflated.
4. Double-click the switch button to turn on the pump.
5. Allow the pump to extract air until the item is sufficiently deflated.
6. Double-click the switch button again to turn off the pump.



Image: A three-step visual guide demonstrating how to deflate an item: 1. Choose the right nozzle. 2. Attach the nozzle to the top air port. 3. Double-click to turn on the pump.

Camping Light Function

The Sportneer Portable Air Pump features an integrated camping light with three adjustable brightness levels.

Light Up Your Night In The Wild



60 lumens
Last 14h



160 lumens
Last 6h



300 lumens
Last 4.5h



Image: The pump illuminating a tent, accompanied by graphics illustrating its three light levels: 60 lumens (lasts 14h), 160 lumens (lasts 6h), and 300 lumens (lasts 4.5h).

- To turn on the light, **long press** the switch button.
- To cycle through brightness levels (60, 160, 300 lumens), short press the switch button.
- To turn off the light, long press the switch button again.

Magnetic Design

The pump has a built-in magnetic base, allowing it to be adsorbed onto iron, steel, nickel, and other ferromagnetic materials. This is useful for hands-free lighting in various situations.



Magnetic Absorber Design

Can be adsorbed on metal when lighting



Adsorbed on the car



Other camping gears



On iron stand

Image: Examples of the pump's magnetic absorption: attached to a car hood for illumination, on other camping gear, and on an iron stand.

MAINTENANCE

- **Cleaning:** Wipe the exterior of the pump with a soft, dry cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** Store the pump and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before long-term storage to preserve battery health.
- **Nozzle Care:** Keep nozzles clean and free from debris to ensure proper function.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Pump does not turn on.	Low battery; incorrect operation.	Charge the pump fully. Ensure you double-click the switch button to activate the pump.
Light does not turn on.	Low battery; incorrect operation.	Charge the pump fully. Ensure you long press the switch button to activate the light.
Weak airflow/inflation.	Incorrect nozzle; nozzle not fully inserted; low battery; item type.	Ensure the correct nozzle is used and fully inserted. Charge the pump. Note: This pump is not suitable for high-pressure items like tires or sports balls.
Pump stops unexpectedly.	Overheating; low battery.	Allow the pump to cool down if used continuously for more than 10 minutes. Charge the pump.

SAFETY INFORMATION

- Do not use the pump continuously for more than 10 minutes to prevent overheating.
- Keep out of reach of children.
- Do not block the air intake or outlet during operation.
- Do not expose the pump to water or extreme temperatures.
- This pump is not suitable for inflating high-pressure items such as vehicle tires, basketballs, or balloons. Refer to the product specifications for compatible items.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support for assistance.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Sportneer customer service directly. Contact details can typically be found on the official Sportneer website or through your purchase platform.

For more information, visit the [Sportneer Store on Amazon](#).