

Acme OF02748

Acme Saida MDF Wood and Metal Rectangular Music Desk User Manual

Model: OF02748

1. PRODUCT OVERVIEW

The Acme Saida Music Desk is designed to provide a functional and organized workspace for music creation and enjoyment. It features a spacious desktop, an upper shelf with speaker risers, a keyboard tray, and integrated headphone holders. The desk combines MDF wood surfaces with a durable metal frame, finished in white and black with a carbon grain texture.

Key Features:

- **Spacious Rectangular Design:** Accommodates various equipment for an efficient setup.
- **Integrated Keyboard Tray:** Provides convenient storage and access for musical keyboards.
- **Two Speaker Shelves:** Elevated platforms for optimal speaker placement.
- **Two Headphone Holders:** Located on each side for organized storage.
- **Durable Construction:** Features MDF wood surfaces with a carbon grain finish and a sturdy metal frame.

2. SETUP AND ASSEMBLY

This desk requires proper assembly to ensure stability and functionality. Please follow the included assembly instructions carefully. It is recommended to have at least two people for assembly. Ensure all components are present before beginning.

Important Assembly Notes:

- Do not exceed the maximum weight limit of 160 pounds (72.5 kg) on the desktop.
- Always use the correct hardware for each step as indicated in the separate assembly guide.
- Tighten all fasteners securely, but do not overtighten to avoid damaging components.
- Place the desk on a soft, clean surface during assembly to prevent scratches.



Figure 2.1: Desk dimensions for planning your space.




Figure 2.2: Front view of the assembled music desk.

3. OPERATING INSTRUCTIONS

The Acme Saida Music Desk is designed for intuitive use, providing dedicated spaces for your musical equipment and accessories.

Using the Keyboard Tray:

The pull-out keyboard tray is located beneath the main desktop. Gently pull the tray forward to extend it for use, and push it back to store your keyboard when not in use. Ensure no cables are pinched during movement.



Figure 3.1: Keyboard tray in extended position.

Utilizing Speaker Shelves:

The upper shelf features two elevated platforms designed to position your studio monitors or speakers at an optimal listening height. Place speakers securely on these platforms, ensuring they are stable and centered.



Figure 3.2: Detail of the speaker riser.

Headphone Holders:

Two metal headphone holders are integrated on the sides of the main desktop. Use these to keep your headphones organized and easily accessible, preventing clutter on your workspace.



Figure 3.3: Headphone holder detail.

4. MAINTENANCE AND CARE

Proper care and maintenance will extend the life and appearance of your Acme Saida Music Desk.

Cleaning:

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes, as these can damage the finish.
- Promptly clean up spills to prevent staining.

General Care:

- Periodically check and tighten all fasteners to ensure the desk remains stable.
- Avoid placing extremely hot or cold items directly on the surface; use coasters or protective pads.
- Keep the desk away from direct sunlight and extreme temperature changes to prevent material warping or fading.

5. TROUBLESHOOTING

If you encounter any issues with your Acme Saida Music Desk, please refer to the following common troubleshooting tips.

Desk Instability:

- **Issue:** The desk feels wobbly or unstable.
- **Solution:** Check all assembly bolts and screws. Ensure they are fully tightened. Verify that the desk is placed on a level surface.

Keyboard Tray Sticking:

- **Issue:** The keyboard tray does not slide smoothly.
- **Solution:** Inspect the tray's runners for any obstructions or debris. Ensure the tray is correctly aligned within its tracks. Avoid overloading the tray.

Damaged Surface:

- **Issue:** Scratches or marks appear on the desk surface.
- **Solution:** For minor marks, a furniture repair kit suitable for MDF and paper veneer may be used. For deeper damage, contact customer support for advice. Always use protective mats for heavy or sharp objects.

6. SPECIFICATIONS

Feature	Detail
Model Number	OF02748
Brand	Acme
Product Dimensions (D x W x H)	32" x 71" x 37" (81.28 cm x 180.34 cm x 93.98 cm)
Item Weight	77.1 Pounds (34.97 kg)
Materials	Engineered Wood (MDF), Metal, Paper Veneer
Color	White; Black
Finish Type	Carbon Grain
Desk Design	Computer Desk / Music Desk
Number of Shelves	2 (Speaker Shelves)
Keyboard Tray	Included
Headphone Holders	2 (Integrated)
Maximum Weight Capacity	160 lbs (72.5 kg)
Assembly Required	Yes

7. WARRANTY INFORMATION

The Acme Saida Music Desk comes with a limited manufacturer's warranty. For specific details regarding coverage, duration, and terms, please refer to the product's original packaging or the official Acme Furniture store page where the product was purchased. Keep your proof of purchase for warranty claims.

8. CUSTOMER SUPPORT

Should you require assistance with assembly, parts, or have any questions regarding your Acme Saida Music Desk, please contact Acme Furniture customer support. Contact information can typically be found on the manufacturer's website or on your purchase documentation.

For online purchases, you may also refer to the customer support section of the retailer's website.