

BLACKSTONE 2350-5608

Blackstone 22 Inch Portable Griddle Instruction Manual

Model: 2350-5608

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Blackstone 22-inch Portable Griddle. Please read it thoroughly before assembly or use.

SAFETY INFORMATION

Always follow basic safety precautions when using this appliance to reduce the risk of fire, explosion, or injury.

- Read all instructions before operating the griddle.
- Use outdoors only. Do not operate indoors or in an enclosed area.
- Keep children and pets away from the griddle during operation.
- Ensure proper ventilation.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Always check for gas leaks before each use.

PRODUCT OVERVIEW




The Blackstone 22-inch Portable Griddle (Model 2350-5608) is designed for versatile outdoor cooking. It features a collapsible structure with a secure locking hood, smooth-rolling wheels, and foldable legs for easy transportation. This model includes a durable griddle cover for protection during travel and storage. The griddle is equipped with Omnivore

Griddle Plate Technology for consistent heat distribution and two independently controlled cooking zones.



The griddle's dimensions are approximately 17 inches deep, 22 inches wide, and 30 inches high when assembled. The compact design allows for easy setup and breakdown.



This griddle features two independently controlled cooking zones, allowing you to cook different foods at varying temperatures simultaneously. The Omnivore Griddle Plate Technology ensures even heat distribution across both zones, preventing hot spots and cold spots.

SETUP

Unpacking and Initial Inspection

1. Carefully remove all components from the packaging.
2. Check for any shipping damage or missing parts. Refer to the packing list.
3. Ensure all protective materials are removed from the griddle surface and components.

Assembly

The Blackstone 22-inch Portable Griddle is designed for minimal assembly. The legs are Flexfold, meaning they are integrated and fold out for use.

1. Place the griddle on a flat, stable surface.
2. Unfold the Flexfold legs until they lock securely into place.
3. Attach the side shelf if it is not pre-attached.
4. Connect the propane tank (not included) to the regulator hose. Ensure all connections are tight.

Seasoning the Griddle

Before first use, the griddle surface must be seasoned to create a non-stick cooking surface and protect against rust.

1. Clean the griddle surface with hot, soapy water and dry thoroughly.
2. Apply a thin, even layer of high-heat cooking oil (e.g., flaxseed, vegetable, or Blackstone seasoning blend) to the entire cooking surface.
3. Turn the griddle to medium-high heat. The oil will smoke and eventually burn off.
4. Once the smoke stops, turn off the griddle and let it cool.
5. Repeat this process 3-5 times, or until the griddle surface is dark brown/black and has a smooth, non-stick finish.

OPERATING INSTRUCTIONS

Ignition

1. Ensure the propane tank is connected and the gas supply is open.
2. Turn one of the control knobs to the HIGH position.
3. Press the igniter button (if equipped) or use a long lighter to ignite the burner.
4. Once ignited, adjust the flame to the desired cooking temperature.
5. Repeat for the second burner if needed.

Cooking



The griddle's two independent cooking zones allow for simultaneous preparation of different foods. Preheat the griddle to your desired temperature. Apply a small amount of cooking oil before placing food on the surface. The Omnivore Griddle Plate Technology ensures even heat distribution for consistent cooking results.

Grease Management System

The Blackstone griddle features a Rear Grease Management System. Excess grease and food debris can be pushed into the opening at the rear of the griddle, which directs it into a removable grease cup hooked onto the back. This system helps keep the cooking surface clean and simplifies cleanup.

MAINTENANCE

After Each Use

1. Allow the griddle to cool down.
2. Scrape off any food residue with a griddle scraper.

- 3. Wipe the surface clean with a paper towel. For stubborn residue, pour a small amount of water on the hot griddle and scrape.
- 4. Apply a thin layer of cooking oil to the griddle surface to maintain seasoning and prevent rust.
- 5. Empty and clean the grease cup.

Storage



When not in use, especially during transport or extended storage, cover the griddle with the included 22-inch On The Go Flexfold Griddle Cover. This cover is designed to protect the griddle from dust, debris, and weather conditions. The griddle's foldable legs and wheels allow for compact storage and easy movement.



The griddle's portable design, with its wheels and handle, allows it to be easily pulled like a suitcase when folded. This makes it convenient for transport to various outdoor locations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner not igniting	No gas flow; clogged burner; faulty igniter.	Check propane tank connection and level; clean burner ports; use a long lighter to ignite manually.
Uneven heating	Clogged burner ports; low gas pressure.	Clean burner ports; ensure propane tank is not low and regulator is functioning correctly.
Griddle surface rusting	Improper seasoning; not oiled after use; exposed to moisture.	Re-season the griddle; apply a thin layer of oil after each use; store in a dry place with the cover on.

Problem	Possible Cause	Solution
Grease not draining properly	Grease trap full or clogged.	Empty and clean the grease cup; ensure the drain opening is clear.

SPECIFICATIONS

- Brand:** BLACKSTONE
- Model Number:** 2350-5608
- Product Dimensions (Assembled):** 17"D x 22"W x 30"H
- Cooking Surface Area:** Approximately 361 square inches (22¼" x 16¼")
- Fuel Type:** Gas (Propane)
- Material:** Carbon Steel (griddle), Alloy Steel (frame)
- Color:** Black
- Special Feature:** Portable, Flexfold Legs, Omnivore Griddle Plate Technology, Rear Grease Management System, Two Independently Controlled Cooking Zones
- Included Components:** Griddle Cover
- Item Weight:** 84 Pounds
- UPC:** 850067184263

WARRANTY

This Blackstone griddle comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full warranty details, refer to the official Blackstone website or contact customer support.

SUPPORT

For further assistance, technical support, or to purchase replacement parts, please visit the official Blackstone website or contact their customer service department. Always provide your model number (2350-5608) when seeking support.

Blackstone Official Website: www.blackstoneproducts.com

