

[Manuals.plus](#) /

> [Daewoo](#) /

> Daewoo 32-inch Soundbeam Bluetooth HDMI Touch Panel Soundbar Instruction Manual

Daewoo DW Soundbeam

Daewoo 32-inch Soundbeam Bluetooth HDMI Touch Panel Soundbar Instruction Manual

Model: DW Soundbeam

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Daewoo 32-inch Soundbeam Bluetooth HDMI Touch Panel Soundbar. Please read this manual thoroughly before using the product and retain it for future reference.



Image 1: Daewoo Soundbar positioned below a television.

2. PRODUCT FEATURES

- **Enhanced Audio:** Experience stereo audio output with 30 Watts maximum speaker output.
- **Versatile Connectivity:** Features Bluetooth and HDMI (ARC) connectivity for various devices.
- **Intuitive Control:** Equipped with a responsive touch panel for easy operation.
- **Sleek Design:** A 32-inch soundbar in black, designed to complement any home entertainment setup.
- **Multi-purpose Use:** Ideal for gaming consoles, computers, televisions, home theater, TV viewing, and streaming.



Image 2: Soundbar enhancing audio experience with visual sound waves.

3. PACKAGE CONTENTS

Upon unpacking, ensure all items listed below are present and in good condition:

- Daewoo Soundbar (DW Soundbeam)
- Remote Control
- Power Cable
- User Manual (this document)

Note: Additional cables for specific connections (e.g., HDMI cable, AUX cable) may need to be purchased separately if not included.

4. SETUP

4.1 Placement

Place the soundbar on a stable, flat surface directly in front of your television. Ensure there are no obstructions in front of the soundbar to allow for optimal sound projection. The soundbar can also be wall-mounted using appropriate hardware (not included).



Image 3: Rear view of the soundbar, highlighting wall-mounting options.

4.2 Connections

The Daewoo Soundbeam offers multiple connectivity options:


- **HDMI (ARC):** For the best audio quality and control, connect an HDMI cable (not included) from the HDMI ARC port on your TV to the HDMI ARC port on the soundbar.
- **Optical:** Connect an optical audio cable (not included) from your TV's optical output to the soundbar's optical input.
- **AUX (3.5mm):** Use a 3.5mm audio cable (not included) to connect to devices with an AUX output.
- **USB:** Insert a USB drive (not included) to play audio files directly.
- **Bluetooth:** For wireless audio streaming, pair your device via Bluetooth.


Daewoo DW3292N

Barra De Sonido SoundBeam Touch



 Ponle play a tu USB
(no incluida).

 Entrada AUX
3.5 mm

 Diseñada para
colgar en pared

 Bluetooth hasta
10 metros

 Entrada
HDMI (ARC)

 Pantalla táctil

Image 4: Detailed view of the soundbar's rear connection panel.

4.3 Power Connection

Connect the power cable to the DC IN port on the soundbar and then plug it into a wall outlet.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button on the soundbar's touch panel or the remote control to turn the unit on or off.



Image 5: User interacting with the soundbar's touch controls.

5.2 Source Selection

Press the 'Source' button on the remote control or the 'Mode' button on the touch panel to cycle through input sources (HDMI, Optical, AUX, USB, Bluetooth).

5.3 Volume Control

Use the '+' and '-' buttons on the soundbar or remote control to adjust the volume. The soundbar features a touch panel for volume adjustment.



Image 6: Close-up of the soundbar's touch-sensitive control panel.

5.4 Bluetooth Pairing

1. Turn on the soundbar.
2. Select Bluetooth mode using the 'Source' or 'Mode' button. The soundbar will enter pairing mode, indicated by a flashing LED.
3. On your mobile device, enable Bluetooth and search for 'DW Soundbeam'.
4. Select 'DW Soundbeam' to pair. Once connected, the LED indicator will stop flashing.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the soundbar. Do not use liquid cleaners or aerosols.
- **Storage:** If not in use for an extended period, unplug the soundbar and store it in a cool, dry place.
- **Avoid Moisture:** Keep the soundbar away from water and high humidity to prevent damage.

7. TROUBLESHOOTING

- **No Power:** Ensure the power cable is securely connected to both the soundbar and the power outlet. Check if the outlet is functioning.
- **No Sound:**
 - Verify the correct input source is selected on the soundbar.
 - Check the volume level on both the soundbar and the connected device.
 - Ensure all audio cables are properly connected.
 - If using optical or HDMI ARC, check your TV's audio output settings to ensure it's set to the correct external audio output.
- **Bluetooth Pairing Issues:**
 - Make sure the soundbar is in Bluetooth pairing mode.
 - Ensure your device's Bluetooth is enabled and within range (up to 10 meters).
 - Try unpairing and re-pairing the device.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the soundbar.

8. SPECIFICATIONS

Feature	Specification
Brand	Daewoo
Model Name	DW Soundbeam
Speaker Size	32 Inches
Max Speaker Output Power	30 Watts
Frequency Response	10 GHz
Connectivity Technology	Bluetooth, HDMI
Wireless Technology	Bluetooth
Audio Output Mode	Stereo
Control Method	Touch
Power Source	Corded Electric
Color	Black
Recommended Uses	Gaming Consoles, Computers, Televisions, Home Theater, TV Viewing, Streaming
Compatible Devices	Laptop, Smartphone, Television, Video Game Console

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Daewoo website. Keep your purchase receipt as proof of purchase.

