

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JBL](#) /

> [JBL Flip 7 - Portable Waterproof and Drop-Proof Speaker, Bold Pro Sound with AI Sound Boost, 16Hrs of Playtime, and PushLock System with Interchangeable Accessories \(Blue\)](#)

JBL JBLFLIP7BLUAM

JBL Flip 7 Portable Speaker Instruction Manual

Brand: JBL | Model: JBLFLIP7BLUAM

1. SETUP

This section guides you through the initial setup of your JBL Flip 7 speaker.

Powering On/Off and Bluetooth Pairing

To power on your JBL Flip 7, press the power button located on the top surface of the speaker. The power indicator light will illuminate. To enter Bluetooth pairing mode, press the Bluetooth button next to the power button. The Bluetooth indicator will flash, indicating it's ready to pair with your device.





Image: Top view of the JBL Flip 7 highlighting the power and Bluetooth buttons.

Initial Charging

The JBL Flip 7 charges via a USB-C port. Connect the provided USB-C cable to the speaker and a compatible power source. The charging indicator light will show the charging status. A full charge takes approximately 2.5 hours.



Image: Side view of the JBL Flip 7 showing the USB-C charging port.

PushLock System with Interchangeable Accessories

The JBL Flip 7 features a new PushLock interchangeable accessory system. This allows you to easily attach and detach accessories like the included loop and carabiner. Simply press the button on the speaker to release the accessory and attach a new one. This system enhances portability and versatility.



Image: The JBL Flip 7 speaker displayed with its detachable loop and carabiner accessories.

2. OPERATING

Understand the various functions and features of your JBL Flip 7 for optimal use.

Bold JBL Pro Sound with AI Sound Boost

The JBL Flip 7 delivers powerful, clearer bass and crisp higher frequencies due to a new tweeter dome design. The AI Sound Boost technology analyzes your music in real-time to provide maximum acoustic performance with reduced distortion.

BOLD **JBL PRO SOUND** WITH AI SOUND BOOST



Image: A person holding the JBL Flip 7 speaker outdoors, illustrating its portability and sound capabilities.

Playtime and Playtime Boost

Enjoy up to 14 hours of playtime on a single charge. For an additional 2 hours of playtime, activate the Playtime Boost feature. This extends your listening experience when needed.

UP TO **16 HOURS**
OF PLAYTIME



14 hours playtime + extra 2 hours with Playtime Boost

Image: Three individuals relaxing outdoors with a JBL Flip 7 speaker, highlighting its long playtime.

Multi-speaker Connection by Auracast

With Auracast, you can effortlessly stereo pair two Flip 7 speakers for a wider sound stage or connect multiple Auracast-enabled JBL speakers to cover a larger area with the same playlist.



Image: Two individuals on bicycles, each with a JBL Flip 7 speaker, showcasing the multi-speaker connection feature for shared audio.

Lossless Audio Playback

For high-fidelity audio, connect your JBL Flip 7 to a laptop or other audio device via its USB-C port for lossless audio playback. A compatible lossless audio source from supported apps/services is required.

JBL Portable App

The JBL Portable app provides access to support, updates, and customizable audio controls, allowing you to fine-tune the sound to your preferences.

3. MAINTENANCE

Proper care ensures the longevity and performance of your JBL Flip 7.

Waterproof, Dustproof, and Drop-Proof

The JBL Flip 7 boasts an industry-leading IP68 rating, making it waterproof and dustproof. It is also designed to be drop-proof from 1 meter onto concrete. While durable, avoid intentionally subjecting the speaker to extreme conditions.



Image: The JBL Flip 7 speaker with a list of its key features, including its robust waterproof, dustproof, and drop-proof design.

Cleaning

For general cleaning, gently wipe the speaker with a damp cloth. Avoid using harsh chemicals or abrasive materials. If the USB-C port gets wet, ensure it is completely dry before attempting to charge the device to prevent damage.

4. TROUBLESHOOTING

Solutions for common issues you might encounter with your JBL Flip 7.

Charging Issues

If your speaker is not charging, ensure the USB-C port is dry and free of debris. The speaker will not charge if moisture is detected in the port. Allow it to air dry completely before attempting to charge again.

Note: A USB-C charging cable is not included with the product to minimize e-waste. You can use any standard USB-C cable to charge your JBL product.

How to fix EVERY PROBLEM with the JBL Flip 7

Watch this video for detailed steps on how to troubleshoot and fix common issues with your JBL Flip 7 speaker.

Video: A comprehensive guide on resolving various problems with the JBL Flip 7 speaker.

5. SPECIFICATIONS

Detailed technical specifications for the JBL Flip 7 speaker.

Feature	Specification
Model Name	JBL Flip 7
Speaker Type	Portable Speaker
Special Features	Waterproof, Lightweight, Stereo Pairing, Dustproof, Shockproof
Battery Life	16 Hours
Charging Time	2.5 Hours
Item Weight	1.23 Pounds
Product Dimensions	2.8"D x 7.19"W x 2.7"H
Connectivity Technology	Bluetooth, USB
Speaker Maximum Output Power	25 Watts

6. WARRANTY & SUPPORT

Information regarding your product's warranty and available support channels.

Warranty Information

The JBL Flip 7 comes with a Limited Warranty. A Warranty Card is included in the box for details on coverage and terms.

Product Support

For further assistance, updates, and customizable audio controls, download the JBL Portable app. The app provides comprehensive support for your device.

Video: A demonstration of connecting the JBL Flip 7 speaker to multiple devices and an audio demo, showcasing its multi-device capabilities.