

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Baotree](#) /
- › [Baotree 3-in-1 Baby Bouncer Adjustable Wooden Rocker Chair Instruction Manual \(Model WTTBA8001\)](#)

### Baotree WTTBA8001

# Baotree 3-in-1 Baby Bouncer Adjustable Wooden Rocker Chair Instruction Manual

Model: WTTBA8001 | Brand: Baotree

## 1. INTRODUCTION

---

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Baotree 3-in-1 Baby Bouncer Adjustable Wooden Rocker Chair. This versatile chair is designed to adapt to your child's growth, offering three distinct recline settings to function as a bouncer, recliner, or stationary seat for infants and toddlers.

Please read all instructions carefully before use and retain this manual for future reference.



*Figure 1: Baotree 3-in-1 Baby Bouncer Adjustable Wooden Rocker Chair.*

## **2. SAFETY INFORMATION**

---

- Always use the provided safety belt to secure your child in the chair. Ensure the adjustable buckle is properly fastened and snug for the child's age and size.
- Do not leave your child unattended in the bouncer.
- This product is designed for children weighing up to 33 pounds. Do not exceed this weight limit.
- Ensure the chair is placed on a stable, flat surface. When used on smooth floors (e.g., wood or tile), a little sliding may occur. It is recommended to use this product on carpets or mats to prevent unwanted movement.
- Regularly inspect all components for wear, damage, or loose parts. Discontinue use if any part is damaged.
- The chair features smooth, rounded edges designed to be baby-safe and meets stringent CPC safety standards for children's products.

## **3. PRODUCT FEATURES**

---

- **3-in-1 Convertible Design:** Easily transitions between a bouncer, recliner, and stationary seat with three distinct recline settings. This adaptability supports your child from infancy through toddlerhood, promoting comfort and balance development.
- **Durable Construction:** Crafted from sturdy natural birch wood, ensuring enhanced stability and longevity.
- **Ergonomic Comfort:** Designed to provide optimal support for your baby's spine, neck, and head. Features adjustable rocking and an anti-tip design for safety.
- **Removable & Washable Cushion:** The natural cotton cushion (17.7 x 28.3 inches) is removable and machine-washable for easy cleaning and hygiene.
- **Adjustable Safety Harness:** Equipped with a safety belt featuring an adjustable buckle, suitable for children of different ages, ensuring secure seating.



Figure 2: Seat cushion details with removable cotton fabric and adjustable safety belt.

## 4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Baotree 3-in-1 Baby Bouncer. All necessary hardware and tools are included. Refer to the included manual for detailed diagrams.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the parts list are present.
2. **Assemble the Base:** Connect the curved wooden base pieces using the provided screws and Allen key. Ensure screws are snug but do not overtighten to avoid damaging the wood.
3. **Attach Side Supports:** Secure the vertical side supports to the base.
4. **Install Seat Frame:** Assemble the slatted wooden seat frame and attach it to the side supports.
5. **Connect Recline Mechanism:** Attach the adjustable recline mechanism to the seat frame and side supports. This mechanism allows for the three recline positions.
6. **Install Cushion:** Place the natural cotton cushion onto the assembled wooden frame. Secure it using the integrated straps or Velcro attachments.
7. **Check Safety Harness:** Ensure the 5-point safety harness is correctly threaded and adjustable.

Your browser does not support the video tag.

*Video 1: Assembly and feature overview of the 3-in-1 Baby Bouncer Chair by FuWanBoUS.*

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Adjusting Recline Positions (3-in-1 Functionality)

The Baotree bouncer offers three recline positions to suit your child's needs:

- **Bouncer/Rocker Mode:** For gentle rocking and active play.
- **Recliner Mode:** A more relaxed position for resting or feeding.
- **Stationary Seat Mode:** For stable seating, ideal for feeding or when you need a fixed position.

To adjust the recline, locate the adjustment mechanism on the sides of the chair. Gently lift or push the seat back to engage the desired notch. Ensure both sides are securely locked into the same position.



Figure 3: Three adjustable recline positions.

## 5.2 Switching Between Rocking and Fixed Modes

The chair can be used as a gentle rocker or converted into a stationary seat:

- **Rocking Chair:** To enable rocking, ensure the stop-bar (located underneath the base) is rotated away from the floor.
- **Fixed Chair:** To make the chair stationary, rotate the stop-bar so it secures firmly against the floor, preventing rocking motion.

### How to use as a rocking chair

You can rotate the stop-bar (away from floor) to function as a rocking chair



### Use as a fixed chair

Rotate the stop-bar and secure it to the floor



Figure 4: Instructions for switching between rocking and fixed chair modes.

## 5.3 Using the Safety Harness

The 5-point safety harness ensures your child's security:

- Place your child in the seat.
- Bring the shoulder straps over your child's shoulders and the waist straps around their waist.
- Connect the shoulder and waist straps to the central buckle.
- Adjust the straps to ensure a snug fit without being too tight, allowing for comfortable movement while preventing your child from slipping out.

## 6. MAINTENANCE

- **Cushion Cleaning:** The natural cotton cushion is removable and machine-washable. Follow the care instructions on the cushion's label for best results. Typically, wash with cold water on a gentle cycle and air dry.
- **Wooden Frame Cleaning:** Wipe the wooden frame with a damp cloth and mild soap. Dry thoroughly immediately after cleaning. Avoid using abrasive cleaners or harsh chemicals.

- **Regular Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight and secure. Tighten if necessary.

## 7. TROUBLESHOOTING

---

- **Chair Slides on Smooth Floors:** If the chair slides excessively on wood or tile, place it on a carpet or mat to increase friction and stability.
- **Difficulty Adjusting Recline:** Ensure the adjustment mechanism is clear of obstructions. Apply gentle, even pressure when engaging the notches. If a screw was overtightened during assembly, it might affect the smooth operation of the recline mechanism.
- **Unstable or Wobbly:** Check all assembly points to ensure screws are properly tightened. Refer to the assembly instructions to confirm all parts are correctly installed.

## 8. SPECIFICATIONS

---

<b>Product Dimensions</b>	27.6 x 18.9 x 24.2 inches
<b>Item Model Number</b>	WTTBA8001
<b>Maximum Weight Recommendation</b>	33 Pounds
<b>Material Type</b>	Wood
<b>Material Composition</b>	Wood
<b>Batteries Required</b>	No
<b>Is Portable</b>	No
<b>Item Weight</b>	10 pounds
<b>Color</b>	Beige

## 9. WARRANTY AND SUPPORT

---

For warranty information or customer support, please refer to the product packaging or contact Baotree customer service directly. Keep your purchase receipt as proof of purchase.