

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Statik](#) /

› [Statik Aktive Open Ear Bluetooth Earbuds - Wireless Earphones Instruction Manual \(Model: PUP-0705-BLK\)](#)

Statik PUP-0705-BLK

Statik Aktive Open Ear Bluetooth Earbuds Instruction Manual

MODEL: PUP-0705-BLK

PRODUCT OVERVIEW

The Statik Aktive Open Ear Bluetooth Earbuds are designed to provide high-quality audio while maintaining situational awareness. Their open-ear design ensures comfort for all-day usage and allows you to hear your surroundings. These wireless earphones feature fast charging, a long-lasting battery, and an IPX5 waterproof rating, making them suitable for various activities.

- **Open-Ear Design:** Audio transmitted without blocking your ears, enhancing awareness.
- **Situational Awareness:** Safely hear your environment during activities like walking, jogging, or working out.
- **Fast Charging & Long-Lasting Battery:** Charging case rapidly recharges earbuds, providing extended audio playback.
- **IPX5 Water Resistant:** Designed to withstand sweat, rain, and dirt.
- **Comfortable Fit:** Engineered for all-day wear without discomfort.

Your music. Your awareness. Your freedom.



Figure 1: Statik Active Open Ear Bluetooth Earbuds and their charging case, highlighting key features like open-ear listening, water resistance, comfortable fit, and 100-hour max charge.

SETUP

1. Unboxing and Initial Charge

Upon unboxing, ensure all components are present: the Statik Active Earbuds, the charging case, and the USB-C charging cable. It is recommended to fully charge the earbuds and case before first use. Connect the charging case to a power source using the provided USB-C cable.

Freedom to Listen All Day

100 hrs



10 Hours on
a Single Charge



100 Hour Battery Life
with Charging Case



2 Hours After
10 Minute Charge

Figure 2: The Statik Active Earbuds resting in their charging case, which displays the battery level. The case provides up to 100 hours of battery life, with 10 hours on a single earbud charge and 2 hours after a 10-minute charge.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light.
2. On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Select "Statik Aktive" from the list of available devices to connect.
4. Once connected, a voice prompt will confirm successful pairing.

Your browser does not support the video tag.

Video 1: A brief overview of the STATIK Active Open Earbuds, demonstrating the product and its charging case. This video shows the earbuds being removed from the case and worn, highlighting their design and ease of use.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

The Statik Active Earbuds feature an open-ear design with ear hooks for a secure and comfortable fit. Gently place

the earbud over your ear, ensuring the speaker rests just outside your ear canal. Adjust the ear hook for optimal comfort and stability.




Figure 3: A person wearing the Statik Active Open Ear Bluetooth Earbuds, demonstrating the comfortable, no-pressure fit that avoids ear fatigue and a plugged feeling.

2. Touch Controls

The earbuds are equipped with touch-sensitive controls for easy management of audio and calls:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Volume Control:** Adjust volume directly from your connected device.

Secure Fit. Cleaner Listening.



Figure 4: A close-up of a person wearing the Statik Aktive Open Ear Bluetooth Earbuds, illustrating the secure fit and the hygienic benefit of no in-ear moisture or bacteria buildup.


MAINTENANCE

1. Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds. Use a soft, dry, lint-free cloth to wipe the earbuds and charging case. Avoid using abrasive materials or harsh chemicals. Do not submerge the charging case in water.

2. Water Resistance

The Statik Aktive Earbuds are IPX5 water-resistant, meaning they can withstand splashes, sweat, and light rain. They are not designed for submersion in water. Ensure the charging port cover is securely closed before exposing the earbuds to moisture.



Listen while staying aware of your surroundings

Figure 5: A woman wearing Statik Active Open Ear Bluetooth Earbuds while running outdoors, demonstrating the ability to listen to music while remaining aware of her surroundings.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure earbuds are charged and within range of your device. Turn off and on your device's Bluetooth, then try pairing again.
- **No sound:** Check the volume levels on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Charging issues:** Verify the USB-C cable is securely connected to both the case and the power source. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Unstable connection:** Move closer to your connected device and away from potential interference sources (e.g., other wireless devices, microwaves).

SPECIFICATIONS

Connectivity Technology	Wireless
Included Components	Charging Station
Item Weight	3.84 ounces
Item Model Number	PUP-0705-BLK
Batteries	3 Nonstandard Battery batteries required. (included)
Brand	Statik
Color	Black
Ear Placement	Open Ear
Form Factor	Open Ear
Model Name	Aktive Earbuds

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Statik website. Keep your proof of purchase for any warranty claims.