

Patoolio W6

Patoolio Pressure Washer W6 Instruction Manual

Model: W6

[Information](#) [Components](#) [Setup](#) [Operation](#) [Maintenance](#) [Introduction](#) [Safety](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Patoolio Pressure Washer, Model W6. This electric pressure washer is designed for efficient cleaning of various outdoor surfaces, including concrete, patios, decks, fences, cars, and more. It features an all-in-one adjustable nozzle, an external foam cannon, and a compact design for ease of use and storage.

2. IMPORTANT SAFETY INFORMATION

Read all safety warnings and instructions before operating this product.

- Always connect the water supply before turning on the machine. Operating the washer without water can cause the pump and motor to overheat, potentially leading to damage or smoke.
- Use only cold, clean tap water. Hot or dirty water can damage internal seals and cause excessive heat buildup inside the pump.
- Keep the nozzle and inlet filter clean. A clogged nozzle or filter restricts water flow, forcing the pump to work harder and potentially overheat.
- Use only non-flammable, pressure-washer-safe detergents. Never use gasoline, solvents, bleach, or corrosive chemicals, as these can react with electrical parts and cause smoke or fire.
- The handle is equipped with a child safety lock to prevent accidental operation. Always engage this lock when the unit is not in use.
- The Total Stop System (TSS) automatically stops the pump when the trigger is not activated, which conserves energy and extends the lifespan of the pump and motor.

3. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your Patoolio Pressure Washer:

- **Pressure Washer Unit:** Main body with motor, pump, wheels, and integrated storage for accessories.
- **Spray Gun:** Handheld unit for directing the high-pressure spray.
- **Adjustable Spray Wand:** Connects to the spray gun, allowing for variable spray patterns.
- **High-Pressure Hose:** Connects the pressure washer unit to the spray gun (23 feet long).
- **External Foam Pot:** For applying detergent foam.
- **Power Cord:** For electrical connection.

3 Length Adjustments



Image: Overview of the Patoolio Pressure Washer, highlighting its compact design, wheels, handle, and integrated storage for the power cord, gun, and foam cannon.

4. SETUP INSTRUCTIONS

Follow these steps to assemble and prepare your pressure washer for first use:

1. **Install Handle:** Secure the handle to the main unit using the provided screws.
2. **Assemble Spray Gun:** Attach the adjustable spray wand to the spray gun by pressing down and rotating until it locks securely.
3. **Connect High-Pressure Hose to Gun:** Align the connector of the high-pressure hose with the spray gun inlet and press down firmly until it clicks into place.
4. **Connect Water Outlet:** Connect the other end of the high-pressure hose to the water outlet on the pressure washer unit.
5. **Connect Water Inlet:** Attach your garden hose (not included) to the water inlet on the pressure washer. Ensure a tight connection to prevent leaks.



Image: Visual guide demonstrating the five key installation steps: installing handle screws, attaching the spray wand, connecting the high-pressure hose to the gun, and connecting water inlet and outlet.

5. OPERATING INSTRUCTIONS

Once assembled, follow these steps for safe and effective operation:

1. **Connect Water Supply:** Ensure your garden hose is connected to the pressure washer and the water tap is fully open.
2. **Power On:** Plug the power cord into a suitable electrical outlet and turn the ON/OFF switch on the unit to the "ON" position.
3. **Adjust Spray Angle:** The all-in-one nozzle allows you to easily switch spray angles by rotating the nozzle head. Choose the appropriate angle for your task:
 - **0° (Pin-point jet):** For concentrated power on stubborn stains on solid surfaces.
 - **15-25° (Fan spray):** Ideal for cleaning outdoor furniture or general dirt.
 - **25-60° (Wider fan spray):** Suitable for general surface clearing and rinsing.
 - **60-120° (Extensive spray):** For delicate tasks like car washing or broad rinsing.

PATOOOLIO Pressure Washer

Widely use in different scenerio



Image: Diagram showing the adjustable nozzle and its various spray patterns (0°, 15-25°, 25-60°, 60-120°) for different cleaning applications.

4. **Use the Foam Cannon:** Fill the external foam pot with a pressure-washer-safe detergent. Attach it to the spray gun for dense foam application. This design prevents detergent from passing through the pump, extending its life.

Electric Pressure Washer

4200 PSI
Max. Pressure

2.6 GPM
Max. Flow Rate



Image: A man applying thick foam to a car using the external foam sprayer, demonstrating its use for car cleaning.

5. **Adjust Wand Length:** The spray wand can be adjusted to three different lengths to provide optimal reach and comfort for various cleaning tasks.

Intensive Foam Sprayer

Detergent does not pass through the pump to extend pump life



Image: Three different configurations of the spray wand, illustrating its adjustable length for varied cleaning needs.

6. **Engage Child Safety Lock:** When not actively spraying, engage the child safety lock on the spray gun handle to prevent accidental discharge.
7. **Total Stop System (TSS):** The pressure washer is equipped with a TSS feature. The pump will automatically stop when the trigger is released and restart when the trigger is pressed, saving energy and reducing wear.

5.1. Operational Videos

Video: This video demonstrates the Patoolio Pressure Washer in action, showcasing its foam cannon feature, adjustable nozzle for various

surfaces, and overall cleaning effectiveness on cars, patios, and stairs.

Video: This video provides a detailed look at the Patoolio Portable Pressure Washer, including its assembly, features like the adjustable wand and external foam sprayer, and its application for cleaning various surfaces such as outdoor furniture and fences.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your pressure washer:

- **Flush After Use:** After each use, especially when using detergents, flush the system with clean water for a few minutes to remove any chemical residues.
- **Clean Nozzle and Filter:** Regularly inspect and clean the nozzle and water inlet filter to prevent blockages and maintain consistent pressure.
- **Storage:** Store the pressure washer in a dry, frost-free environment. Drain all water from the pump and hoses before storing to prevent freezing damage.
- **Inspect Hoses and Connections:** Periodically check hoses for kinks, cuts, or leaks, and ensure all connections are secure.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Unit does not start	No power supply; ON/OFF switch off	Check power connection; ensure switch is ON.
Low water pressure	Insufficient water supply; clogged nozzle/filter; air in pump	Ensure water tap is fully open; clean nozzle/filter; bleed air from pump by running with trigger open until steady stream.
Pump overheats	Running without water; clogged filter/nozzle	Always connect water before starting; clean filter/nozzle.
Water leaks from connections	Loose connections; worn O-rings	Tighten all connections; replace worn O-rings if necessary.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact Patoolio customer support.

8. SPECIFICATIONS

Brand: Patoolio

Model Number: W6

Power Source: AC

Color: Light Grey

Item Weight: 15 Pounds

Hose Length: 275 Inches (approx. 23 feet)

Product Dimensions: 15"L x 12"W x 7"H

UPC: 717956375532

Manufacturer: Shenzhen Patoolio Technology Co., Ltd.

9. WARRANTY AND CUSTOMER SUPPORT

Patoolio is committed to providing industry-leading standards and professional service. If you encounter any product issues or require assistance, please do not hesitate to contact our customer service team. We are dedicated to ensuring your satisfaction and will be happy to provide excellent support.

For support, please refer to the contact information provided with your product packaging or visit the official Patoolio website.

