

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BIEGEDY](#) /

› [BIEGEDY B29 Android 14 Tablet User Manual](#)

BIEGEDY B29

BIEGEDY B29 Android 14 Tablet User Manual

Model: B29

INTRODUCTION

This manual provides comprehensive instructions for the BIEGEDY B29 Android 14 Tablet. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. The BIEGEDY B29 is a versatile 10.1-inch tablet designed for various tasks, from entertainment to productivity, featuring an Octa-Core processor, ample memory, and an 8000mAh battery.

WHAT'S IN THE BOX

Upon opening the package, verify that all components are present:

- BIEGEDY B29 Android 14 Tablet
- Keyboard
- Mouse
- Power Adapter
- USB Cable
- User Manual (this document)
- Other accessories as specified on the product packaging.



Image: The BIEGEDY B29 tablet shown with its included keyboard, mouse, and charging accessories, illustrating the complete package contents.

PRODUCT OVERVIEW

Familiarize yourself with the physical features and components of your BIEGEDY B29 tablet.

Biegedy_{B29}



Image: An overview of the BIEGEDY B29 tablet highlighting its metal body, 10.1-inch display, Widevine L1 support, connectivity options (2.4G+5G Wi-Fi, Bluetooth 5.0), T606 Octa-Core processor, memory (22GB RAM, 128GB ROM), 8000mAh battery, facial recognition, and camera specifications (8MP rear, 5MP front).

Key Components:

- **10.1-inch HD IPS Touchscreen:** Main display for interaction.
- **Front Camera (5MP):** Located on the front bezel, used for video calls and selfies.
- **Rear Camera (8MP):** Located on the back, for taking photos and videos.
- **Power Button:** Located on the side, used to power on/off or wake/sleep the device.
- **Volume Buttons:** Located on the side, used to adjust audio volume.
- **USB-C Port:** For charging and data transfer.
- **MicroSD Card Slot:** For expanding storage up to 1TB.
- **Speakers:** For audio output.

SETUP

1. Initial Charging

Before first use, fully charge your tablet. Connect the provided USB cable to the tablet's USB-C port and the power adapter, then plug the adapter into a wall outlet. The charging indicator will show the charging status.

8000mAh Ultra Large Battery

 Music 8.5 Hours	 Games 20 Hours	 Phone 19 Hours	 Web 22 Hours	 Standby 560 Hours
---------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------



The tablet features an 8000mAh battery, ensuring a long standby time and reducing the stress of frequent charging.

 Type-c

Image: The BIEGEDY B29 tablet displaying its 8000mAh battery capacity and indicating the Type-C charging port, illustrating the charging process.

2. Powering On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button until a power menu appears, then select "Power off".
- **To Sleep/Wake:** Briefly press the Power button.

3. Initial Setup Wizard

Upon first power-on, the Android 14 setup wizard will guide you through essential configurations:

- **Language Selection:** Choose your preferred language.
- **Wi-Fi Connection:** Connect to a wireless network to access the internet.
- **Google Account:** Sign in with your Google account or create a new one to access the Play Store and other Google services.

- **Date & Time:** Set the correct date and time.
- **Security:** Set up a screen lock (PIN, pattern, password, or Face Unlock).

4. Inserting a MicroSD Card (Optional)

To expand storage up to 1TB, locate the MicroSD card slot on the side of the tablet. Gently insert the card until it clicks into place. Ensure the tablet is powered off before inserting or removing the card.

Super visual effect

Our 10.1-inch fully bonded IPS display provides you with an unparalleled visual experience. With a resolution of 1280x800 and an ultra wide viewing angle, it provides an impeccable visual experience.



10.1-inch
IPS Display



1280x800
Resolution



Eye protection



Extra large memory

Enables you to download applications with confidence



128GB ROM
Large storage



22GB RAM
6GB physic + 16GB virtual



1TB Expansion
More space, more fun

Image: A visual representation of the BIEGEDY B29 tablet's memory capabilities, showing 128GB ROM, 22GB RAM, and the option for 1TB TF (MicroSD) card expansion.

5. Connecting Keyboard and Mouse

The included keyboard and mouse connect via Bluetooth. Follow these steps:

1. Ensure the keyboard and mouse are charged and powered on.
2. On your tablet, go to **Settings > Connected devices > Bluetooth**.
3. Turn on Bluetooth and scan for available devices.
4. Select the keyboard and mouse from the list to pair them. Follow any on-screen prompts.

OPERATING INSTRUCTIONS

1. Basic Navigation

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through pages or lists.
- **Pinch-to-Zoom:** Zoom in or out on images or web pages.
- **Long Press:** Access contextual menus or move icons.

2. Wi-Fi and Bluetooth Connectivity

The tablet supports 2.4G and 5G Wi-Fi for fast internet and Bluetooth 5.0 for connecting peripherals.

- Access **Settings** > **Network & internet** for Wi-Fi.
- Access **Settings** > **Connected devices** for Bluetooth.



High-speed Internet Connection



2.4G +5G WIFI



Bluetooth 5.0

Widevine L1

Discover unparalleled clarity:
Unlock a new realm of FHD and UHD streaming with Certified Widevine L1.



Image: The BIEGEDY B29 tablet showcasing its high-speed internet capabilities with 2.4G + 5G Wi-Fi and Bluetooth 5.0 connectivity.

3. Face Unlock

Set up Face Unlock for convenient and secure access:

1. Go to **Settings > Security & privacy > Device unlock > Face Unlock**.
2. Follow the on-screen instructions to register your face.

4. Split Screen Functionality

To use two apps simultaneously:

1. Open the first app.
2. Swipe up from the bottom of the screen and hold to open the recent apps view.
3. Tap the app icon at the top of the first app's card, then select "Split top".
4. Choose the second app from the recent apps or app drawer to fill the other half of the screen.

5. App Management and Play Store

The tablet runs Android 14, providing access to the Google Play Store for downloading applications.

Android 14

The tablet comes with the latest Android 14 operating system with smoother and faster modes, offering more privacy and data control.

- Privacy Protection**
- Individualization**
- Play Store**

Powerful processor

It not only ensures fast performance for work and entertainment, but also makes it easy to use demanding applications, handle multiple tasks simultaneously, and easily enjoy high-quality content

- 2*A75+6*A55**
Energy Efficient
- Octa-core CPU**
Up to 2.0GHZ
- 12nm Process**
High Performance

Image: The BIEGEDY B29 tablet highlighting its Android 14 operating system and the powerful T606 2.0GHz Octa-Core processor, indicating smooth performance for applications.

- Open the **Play Store** app to browse and install apps.
- To uninstall an app, long-press its icon on the home screen or app drawer, then drag it to "Uninstall" or select "App info" and then "Uninstall".

6. Media Consumption (Widevine L1)

With Widevine L1 certification, the tablet supports high-definition streaming from popular services like Netflix, YouTube, Prime Video, and Disney+.

- Ensure a stable internet connection for optimal streaming quality.
- Download the respective streaming apps from the Play Store.

7. Camera Usage

The tablet features a 5MP front camera and an 8MP rear camera.

5MP

The 5 MP front camera takes excellent shots and sound and color effects to provide a better video call experience.



8MP





The 8 MP camera can capture more details and clarity, making it suitable for taking daily photos and videos, recording life clips, landscapes, and portraits

Image: The BIEGEDY B29 tablet highlighting its 5MP front camera for video calls and an 8MP HD rear camera for capturing photos and videos.

1. Open the **Camera** app.

2. Switch between front and rear cameras using the camera icon.
3. Tap the shutter button to take a photo or start/stop video recording.

MAINTENANCE

1. Battery Care

- Avoid extreme temperatures (hot or cold) as they can degrade battery life.
- Do not let the battery completely drain frequently.
- Use the original charger for optimal charging.
- For long-term storage, charge the tablet to about 50% and power it off.

2. Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid harsh chemicals, abrasive materials, or excessive moisture.

3. Software Updates

Regularly check for and install system updates to ensure your tablet has the latest features, security patches, and performance improvements.

- Go to **Settings > System > System update**.
- Follow the on-screen instructions to download and install updates.

4. Storage Management

To maintain optimal performance, regularly manage your tablet's storage.

- Go to **Settings > Storage** to view storage usage.
- Uninstall unused apps, delete old photos/videos, or move files to the MicroSD card or cloud storage.

TROUBLESHOOTING

This section addresses common issues you might encounter with your BIEGEDY B29 tablet.

Tablet Not Turning On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- Perform a forced restart: Press and hold the Power button for 10-15 seconds.

Slow Performance or Freezing

- Close unused background applications.
- Clear app caches (**Settings > Apps > select app > Storage & cache > Clear cache**).
- Free up storage space.
- Restart the tablet.

Wi-Fi Connectivity Issues

- Ensure Wi-Fi is enabled on the tablet.
- Restart your Wi-Fi router.
- Forget the network and reconnect (**Settings > Network & internet > Internet > tap gear icon next to network > Forget**).

Battery Drains Quickly

- Reduce screen brightness.
- Disable Wi-Fi, Bluetooth, and GPS when not in use.
- Close background apps.
- Check battery usage in **Settings > Battery** to identify power-hungry apps.

Factory Reset (Last Resort)

If issues persist, a factory reset can resolve software-related problems. **Warning: This will erase all data on your tablet. Back up important data before proceeding.**

1. Go to **Settings > System > Reset options**.
2. Select **Erase all data (factory reset)**.
3. Confirm your decision and follow the prompts.

SPECIFICATIONS

Feature	Specification
Model	B29
Operating System	Android 14
Screen Size	10.1 Inches
Screen Resolution	1280x720 pixels (Max 1920x1200 pixels)
Processor	ARM Octa-Core (T606, up to 2.0GHz)
RAM	22GB (6GB physical + 16GB virtual)
Internal Storage	128GB
Expandable Storage	Up to 1TB via MicroSD card
Battery Capacity	8000mAh
Wireless Connectivity	802.11ax (2.4G + 5G Wi-Fi), Bluetooth 5.0
Front Camera	5MP
Rear Camera	8MP
Dimensions (LxWxH)	9.4 x 0.3 x 6.3 inches
Item Weight	2.9 pounds
Special Features	GPS, Face Unlock, Widevine L1, Split Screen

WARRANTY AND SUPPORT

Your BIEGEDY B29 tablet comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

For technical support, service, or further inquiries, please contact BIEGEDY customer service through the contact information provided on the product packaging or the official BIEGEDY website. When contacting support, please have your product model

(B29) and purchase details ready.

© 2025 BIEGEDY. All rights reserved.