

[manuals.plus](#) /› [LOUTOC](#) /› [LOUTOC Replacement Remote Control for Apple TV 4K/HD \(Model: apletv\) - Instruction Manual](#)**LOUTOC apletv**

LOUTOC Replacement Remote Control for Apple TV 4K/HD (Model: apletv)

User Instruction Manual

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your LOUTOC Replacement Remote Control for Apple TV 4K/HD. Please read these instructions carefully before use to ensure optimal performance and longevity of your device.

2. SAFETY INFORMATION

- Keep the remote control away from water and other liquids.
- Avoid dropping or subjecting the remote to strong impacts.
- Do not expose the remote to extreme temperatures or direct sunlight.
- Dispose of used batteries responsibly according to local regulations.

3. PRODUCT OVERVIEW

The LOUTOC Replacement Remote Control is designed to provide seamless control over your Apple TV 4K/HD device. It features a user-friendly layout with clearly labeled buttons for easy navigation and media playback.



Image 3.1: LOUTOC Replacement Remote Control for Apple TV 4K/HD. This image displays the sleek, silver-colored remote control with its black buttons, designed to replace the original Apple TV remote.

Button Functions:



Image 3.2: Labeled buttons of the LOUTOC Replacement Remote Control. This image highlights the various buttons on the remote, including TV Power, Navigation Pad, OK/Enter, Menu, Return, Play/Pause, Mute, Volume (+/-), Rewind, Fast Forward, and Channel (+/-).

- **TV Power:** Turns the TV on/off.
- **Navigation Pad (Up, Down, Left, Right):** Navigates through menus and content.
- **OK / Enter:** Confirms selections.
- **Menu:** Accesses the main menu or goes back one step.
- **Return:** Returns to the previous screen.
- **Play/Pause:** Controls media playback.
- **Mute:** Mutes/unmutes TV audio.
- **Volume (+):** Increases TV volume.
- **Volume (-):** Decreases TV volume.
- **Rewind:** Rewinds media playback.
- **Fast Forward:** Fast forwards media playback.
- **CH+ / CH-:** Changes channels (if supported by TV).

Note: This remote is NOT a Siri Remote and does NOT have voice control functionality.



Image 3.3: Remote control indicating no Siri or Voice function. This image clearly shows a microphone icon with a cross through it, emphasizing that the remote does not support Siri or voice commands.

4. SETUP

4.1 Battery Installation

The remote requires two (2) AAA batteries (not included). To install:

1. Open the battery compartment cover on the back of the remote.
2. Insert two AAA batteries, ensuring correct polarity (+ and -).
3. Close the battery compartment cover securely.

Compatible Devices



For Apple TV 4K (1st/2nd/3rd Gen)



For Apple TV HD
(4th/5th Gen)



For Apple TV
(1st/2nd/3rd Gen)

Image 4.1: Diagram showing battery installation and remote dimensions. This image illustrates where to insert the AAA batteries and provides the physical dimensions of the remote control.

4.2 Initial Connection (Apple TV)

No pairing is required for the Apple TV. Once batteries are installed, the remote is ready for immediate use with compatible Apple TV models.

4.3 TV Control Setup (Power/Volume/Mute)

The Power, Volume, and Mute buttons on this remote are designed to work with specific TV brands. These buttons are compatible with Samsung, LG, Vizio, Hisense, Sony, Amazon Fire, Toshiba, and Insignia Fire TVs.



Image 4.2: Remote control highlighting TV brand compatibility for power, volume, and mute buttons. This image visually indicates which buttons control TV power, mute, and volume, and lists the TV brands they are compatible with.

Important: Before using this remote, you must "UNLOCK" your old device with its original remote. Failure to do so may prevent this remote from connecting to your device.

Compatible Remotes



Image 4.3: Instructions for unlocking Apple TV device. This image shows the 'unlocked' and 'locked' icons and provides a crucial notice about unlocking your old device for proper remote function.

5. OPERATING INSTRUCTIONS

Once set up, operate the remote by pointing it directly at your Apple TV device. Ensure there is a clear line of sight between the remote and the device for optimal performance.

High Quality IR Remotes



Image 5.1: Remote control in use with Apple TV, showing optimal distance. This image illustrates the recommended operating distance of 5 meters (maximum 10 meters) for the remote control.

5.1 Basic Navigation

Use the circular Navigation Pad to move through menus and content. Press the **OK / Enter** button in the center of the pad to select an item.

5.2 Media Playback

Use the **Play/Pause**, **Rewind**, and **Fast Forward** buttons for media control.

5.3 Volume and Mute

The **Volume (+)**, **Volume (-)**, and **Mute** buttons control your TV's audio, provided your TV brand is listed as compatible in Section 4.3.

5.4 Channel Control

The **CH+** and **CH-** buttons can be used to change channels if your TV supports this function via the remote.

6. COMPATIBILITY

6.1 Compatible Apple TV Models

This LOUTOC Replacement Remote Control is compatible with the following Apple TV models:

- Apple TV A1218 (1st Gen)
- Apple TV A1378 (2nd Gen)
- Apple TV A1427/A1469 (3rd Gen)
- Apple TV HD A1625 (4th Gen)
- Apple TV HD MHY93LL/A (5th Gen)
- Apple TV 4K A1842 (1st Gen)
- Apple TV 4K A2169 (2nd Gen)
- Apple TV 4K A2737/A2843 (3rd Gen)



Image 6.1: Diagram of compatible Apple TV devices. This image visually lists and shows various generations of Apple TV and Apple TV 4K devices that are compatible with the LOUTOC remote.

6.2 Compatible Original Apple Remotes

This replacement remote is compatible with the functionality of the following original Apple remotes:

- Apple TV Remote (white) A1156 MA128LL/A
- Apple TV Remote (aluminum) MM4T2AM/A
- Siri Remote (1st Gen) / Apple TV Remote (1st Gen) MQGD2LL/A
- Siri Remote (2nd Gen) / Apple TV Remote (2nd Gen) MJFM3LL/A
- Siri Remote (3rd Gen) / Apple TV Remote (3rd Gen) MNC73AM/A



Image 6.2: Diagram of compatible original Apple remotes. This image displays several older Apple TV remotes and indicates that the LOUTOC remote can serve as a replacement for them.

7. MAINTENANCE

7.1 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always use fresh AAA batteries and ensure correct polarity.

7.2 Cleaning

Wipe the remote with a soft, dry cloth. Do not use abrasive cleaners or solvents.

8. TROUBLESHOOTING

- Remote not responding:** Check if batteries are correctly installed and have sufficient charge. Ensure a clear line of sight to the Apple TV device.
- TV Power/Volume/Mute not working:** Verify your TV brand is listed as compatible in Section 4.3. Ensure your old device was "UNLOCKED" as per instructions in Section 4.3.
- No Siri or Voice Function:** This remote does not support Siri or voice commands. This is an infrared (IR) remote control.

9. SPECIFICATIONS

Product Dimensions	1.3 x 0.6 x 6.1 inches
Item Weight	1.44 ounces
Batteries Required	2 AAA batteries (not included)
Max Operating Distance	10 meters / 32 feet (optimal 5 meters)
Special Feature	Ergonomic, Lightweight

10. OFFICIAL PRODUCT VIDEOS

Replacement for Apple TV Remote, Remote for Apple TV 4K/HD

This video, provided by MIRACALS, demonstrates the LOUTOC Replacement Remote Control for Apple TV 4K/HD, highlighting its features and ease of use as a direct replacement.

Perfect replacement remote!

This video, provided by Faux Haus, showcases the LOUTOC Replacement Remote Control, emphasizing its effectiveness as a perfect replacement for the original Apple TV remote.

Universal Apple TV Remote Review

This video, provided by KM Reviews, offers a review of the LOUTOC Replacement Remote Control, highlighting its universal compatibility and functionality with Apple TV devices.

11. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the seller or contact LOUTOC customer service directly. This product includes a user manual within the package for additional guidance.

