



[Manuals.plus](#) /

› [WOVTE](#) /

› [WOVTE DAB Portable Digital Radio Model O1201F4585 User Manual](#)

## WOVTE O1201F4585

# WOVTE DAB Portable Digital Radio Model O1201F4585 User Manual

Your guide to setup, operation, and maintenance.

## INTRODUCTION

---

The WOYTE DAB Portable Digital Radio (Model O1201F4585) is a versatile audio device designed for clear reception of DAB/DAB+ and FM radio stations. It also features Bluetooth connectivity for streaming audio from external devices, an alarm clock, and a sleep timer. Its portable design allows for use with a built-in rechargeable battery or via a USB mains connection.

# Auto Scan & Store 40 Preset Stations

Customise your listening experience by easily storing 40 of your favourite stations, 20 DAB 20 FM



Image: Front view of the WOVTE DAB Portable Digital Radio, showcasing its display and control buttons.

## SETUP

---

### 1. Unpacking

Carefully remove all components from the packaging. Ensure the following items are present:

- WOVTE DAB Portable Digital Radio
- USB Type-C Cable
- Owner's Manual (this document)

### 2. Powering On and Charging

The radio can be powered in two ways:

- **USB Mains Power:** Connect the supplied USB Type-C cable to the radio's USB port and plug the other end into a

compatible USB power adapter (not included) or a powered USB port.

- **Rechargeable Battery:** The radio features a built-in 2200mAh rechargeable battery. For first use, fully charge the battery. A full charge provides up to 12 hours of playback. The battery charges automatically when connected to USB mains power.



Image: Close-up view of the USB Type-C charging port on the side of the radio.

### 3. Antenna Adjustment

Extend the telescopic antenna fully for optimal radio signal reception, especially in DAB/DAB+ and FM modes.



Image: The radio shown with its telescopic antenna fully extended.

### 4. Initial Station Scan

Upon first power-on, the radio will automatically perform a scan for available DAB/DAB+ and FM stations. This process may take a few minutes. Once complete, the radio will display the first available station.

# Store 40 Preset Stations

Customise your listening experience by easily storing 40 of your favourite stations

20  
DAB

20  
FM



Image: The radio display indicating the ability to store 40 preset stations for both DAB and FM.

## OPERATING INSTRUCTIONS

---

### General Controls

Familiarize yourself with the main controls:

- **Power/Mode Button:** Press to turn on/off, short press to cycle through modes (DAB, FM, Bluetooth).
- **Volume Knob:** Rotate to adjust audio volume.
- **OK Button:** Confirm selections.
- **Navigation Buttons (Left/Right/Up/Down):** Navigate menus and station lists.
- **FAV Button:** Access favorite presets.
- **Preset Buttons (1-4):** Directly access stored favorite stations.

### DAB/DAB+ Radio Mode

1. Press the **Power/Mode** button repeatedly until 'DAB' mode is displayed.
2. The radio will automatically scan for stations or use the last tuned station.
3. Use the **Navigation** buttons to browse the list of available DAB stations.
4. Press **OK** to select a station.
5. To store a preset: Tune to the desired station, then press and hold one of the **Preset Buttons (1-4)** or the **FAV** button until 'Preset Stored' appears. You can store up to 20 DAB presets.



Image: Close-up of the radio's display showing DAB+ mode and current station information.

## FM Radio Mode

1. Press the **Power/Mode** button repeatedly until 'FM' mode is displayed.
2. To auto-scan for stations, press and hold the **OK** button. The radio will scan and stop at the next strong station.
3. To manually tune, use the **Navigation** buttons to adjust the frequency.
4. To store a preset: Tune to the desired station, then press and hold one of the **Preset Buttons (1-4)** or the **FAV** button until 'Preset Stored' appears. You can store up to 20 FM presets.

## Bluetooth Mode

1. Press the **Power/Mode** button repeatedly until 'Bluetooth' mode is displayed. The radio will enter pairing mode, indicated by a flashing Bluetooth icon on the display.
2. On your external device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select 'WOVTE Radio' (or similar) from the list of devices to pair.
4. Once paired, the Bluetooth icon on the radio's display will become solid, and you can stream audio from your device.




Image: The radio's display showing the Bluetooth pairing interface.

## Alarm Clock

The radio supports dual alarms.

1. Access the alarm settings through the menu (usually by long-pressing the **Mode** button or navigating via **OK** and **Navigation** buttons).
2. Select 'Alarm 1' or 'Alarm 2'.

3. Set the desired alarm time, source (DAB, FM, or Buzzer), and volume.
4. Enable the alarm.



Image: The radio's display showing options for setting two separate alarms.

## Sleep Timer

The sleep timer allows the radio to turn off automatically after a set period.

1. Access the sleep timer settings through the menu.
2. Select the desired duration (e.g., 15, 30, 45, 60 minutes, etc.).
3. Confirm your selection. The radio will power off after the set time.




Image: The radio's display showing various sleep timer duration options.

## Headphone Use

Connect 3.5mm headphones to the headphone socket on the side of the radio for private listening. The internal speaker will automatically mute when headphones are connected.



Image: Close-up view of the 3.5mm headphone socket on the side of the radio.

## MAINTENANCE

---

### Cleaning

To clean the radio, use a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents, as these can damage the surface. Avoid exposing the radio to liquids.

### Battery Care

To prolong the life of the built-in rechargeable battery:

- Charge the battery regularly, even if the radio is not in frequent use.
- Avoid fully discharging the battery frequently.
- Do not expose the radio to extreme temperatures (hot or cold).

### Storage

When storing the radio for extended periods, ensure it is fully charged and stored in a cool, dry place away from direct sunlight and moisture.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Radio does not power on.	Battery is discharged or USB cable is not connected properly.	Connect the USB Type-C cable to a power source and allow the battery to charge. Ensure the cable is securely connected.
Poor radio reception (DAB/FM).	Antenna not fully extended or weak signal area.	Fully extend the telescopic antenna. Try repositioning the radio to a location with better signal reception. Perform a new station scan.
No sound from speaker.	Volume is too low, headphones are connected, or radio is muted.	Increase the volume using the volume knob. Disconnect any headphones. Check if the radio is muted.

Problem	Possible Cause	Solution
Bluetooth device cannot pair.	Radio not in pairing mode, device too far, or Bluetooth disabled on external device.	Ensure the radio is in Bluetooth pairing mode (flashing icon). Move the external device closer to the radio. Enable Bluetooth on your external device and search again.

## SPECIFICATIONS

---

**Brand:** WOVTE

**Model:** O1201F4585

**Dimensions (L x W x H):** 24 x 64 x 120 Millimeters

**Weight:** 292 Grams

**Power Source:** Built-in 2200mAh rechargeable battery, USB Type-C (Corded Electric)

**Battery Life:** Up to 12 hours playback

**Radio Modes:** DAB/DAB+, FM

**Connectivity:** Bluetooth 5.0, Auxiliary (3.5mm Audio)

**Display:** 2.4" TFT Color LED

**Features:** Alarm Clock (Dual), Sleep Timer, 40 Preset Stations (20 DAB, 20 FM)

**Material:** Plastic

**Water Resistance:** Not Water Resistant

**Box Contents:** WOVTE DAB Portable Digital Radio, USB Type-C cable, Owner's Manual

# Choice of DAB, DAB+ & FM

Crisp and clear audio quality, and automatically searches for all your available radio stations



Image: The radio shown with its physical dimensions labeled.

## WARRANTY INFORMATION

---

This WOVTE product comes with a standard manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging. Alternatively, you may visit the official WOVTE website or contact customer support for further information.

## CUSTOMER SUPPORT

---

Should you encounter any issues or require technical assistance with your WOVTE DAB Portable Digital Radio, please consult the troubleshooting section of this manual first. If the problem persists, or for any other inquiries, please refer to the contact information provided in your product packaging or visit the official WOVTE website for customer service and support resources.

