

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ekster](#) /
- › [Ekster Aluminum Cardholder Pro Wallet - Midnight Blue Instruction Manual](#)

Ekster EK4-ALU-GRY

Ekster Aluminum Cardholder Pro Wallet - Midnight Blue Instruction Manual

INTRODUCTION

The Ekster Aluminum Cardholder Pro Wallet is designed for efficient and secure card and cash management. Crafted from 100% recycled aluminum, it features a sleek, minimalist design with advanced RFID blocking technology. This manual provides essential information for setting up, operating, and maintaining your wallet.



The Ekster Cardholder Pro Wallet highlighting its slim design and capacity for multiple cards.

SETUP

To insert cards, gently slide them into the main compartment until they are securely seated. The wallet can hold 4-7 cards in the quick-access slot. For additional storage, up to 7 more cards can be placed under the expandable backplate. The silicone cash band can be used to secure folded bills.

Quick Card Access

No more struggles



Fast-eject
Trigger



A hand demonstrating the quick card access feature of the Ekster Cardholder Pro Wallet.


Product Overview and Setup Guide

Your browser does not support the video tag. Please update your browser to view this content.

This video provides a comprehensive overview of the Ekster Cardholder Pro, demonstrating its features and initial setup.

Perfect Pocket Fit

The Slimmest Smart Wallet



The Ekster Cardholder Pro Wallet shown with a smartphone, illustrating its compatibility with tracker cards to prevent loss.

The wallet is compatible with Ekster's solar-powered Tracker Card or Apple Find My Finder Card (sold separately) for location tracking. Insert the tracker card into one of the card slots for seamless integration.

OPERATING

To access your cards, simply push the bottom trigger. Cards will fan out in a staggered pattern for easy selection. For cards located in the middle, gently slide the outer cards down to reveal them, then retrieve the desired card. The silicone cash band can be used to secure folded bills on the exterior of the wallet.

Card Retention Demonstration

Your browser does not support the video tag. Please update your browser to view this content.

This video demonstrates the card retention mechanism of the Ekster Cardholder Pro, showing how cards are securely held and do not easily fall out during normal use.

Accessing Middle Cards

Your browser does not support the video tag. Please update your browser to view this content.

Learn the technique for easily accessing middle cards within the Ekster Cardholder Pro's fanned card stack.

MAINTENANCE

The Ekster Cardholder Pro is built from durable, 100% recycled 6063 T5 aluminum. To maintain its appearance, clean the wallet with a microfiber cloth. Avoid harsh chemicals. The aluminum construction is designed to resist wear, scratches, and weather, ensuring long-lasting performance.



The Ekster Cardholder Pro Wallet, emphasizing its construction from sustainable materials.

TROUBLESHOOTING

- **Cards Appearing Loose:** If cards appear loose or fall out, ensure the wallet is loaded with the recommended number of cards (4-7 in the main slot). The internal rubber nubs provide friction to secure cards.
- **Mechanism Issues:** For issues with the card ejection mechanism, refer to the warranty information.

- **Surface Wear:** Some users have noted that the black version may show scratches more easily over time; regular cleaning and careful handling can help preserve its finish.

SPECIFICATIONS

| Feature | Detail |
|--------------------|-----------------------------|
| Product Dimensions | 5.15 x 0.82 x 3.17 inches |
| Item Weight | 5.6 ounces (0.16 Kilograms) |
| Department | Unisex |
| Manufacturer | Ekster |
| Item Model Number | EK4-ALU-GRY |
| Brand | Ekster |
| Color | Midnight Blue |
| Material | Aluminum |
| Style | Cardholder Pro |
| Pattern | Solid |

WARRANTY AND SUPPORT

Your purchase includes a lifetime warranty from the date of delivery, covering manufacturing defects. This warranty ensures the longevity and quality of your Ekster Cardholder Pro Wallet. Additionally, a 100-day return policy is offered for your peace of mind.

For support, warranty claims, or any questions regarding your wallet, please visit the official Ekster website or contact their customer service directly. Keep your proof of purchase for all warranty-related inquiries.