

ZEBRONICS Zeb-Axon 100

ZEBRONICS AXON 100 Portable Party Bluetooth Speaker

USER MANUAL

1. INTRODUCTION

Thank you for purchasing the ZEBRONICS AXON 100 Portable Party Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.



Image: The ZEBRONICS AXON 100 Portable Party Bluetooth Speaker, showcasing its sleek design and integrated carry handle.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x ZEBRONICS AXON 100 Speaker Unit
- 1 x Charging Cable
- 1 x Audio Cable (AUX)
- 1 x QR Code Guide (for additional resources)


3. PRODUCT OVERVIEW

The ZEBRONICS AXON 100 is designed for powerful audio and portability. It features a durable fabric finish, a convenient carry handle, and vibrant RGB LED lights.

Built-in Rechargeable Battery

Carry Handle

Fabric Finish



UPTO
6h*
BACKUP

RAPID

CHARGE

*at 50% volume (LED off) - Default EQ

Image: The speaker highlighting its built-in rechargeable battery, carry handle, and fabric finish for easy portability and durability.

Controls and Ports

The speaker features intuitive controls and multiple connectivity ports for versatile use.



Image: A close-up view of the speaker's control buttons and connectivity ports, including Bluetooth v5.3, AUX, USB, and TWS functionality.

Familiarize yourself with the buttons for power, volume, media playback, EQ modes, and RGB light control. The rear panel houses the AUX, USB, and DC 5V charging ports.

4. SETUP

Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the DC 5V port on the speaker and the other end to a compatible USB power adapter (not included).

- The LED indicator will show charging status.
- A full charge provides up to 6 hours of playback at 50% volume with LEDs off and default EQ.
- The speaker supports rapid charging for minimal downtime.

Initial Connection

The AXON 100 offers multiple ways to connect your audio source.

5. OPERATING THE SPEAKER

Power On/Off

- To power on, press and hold the Power button.
- To power off, press and hold the Power button again.

Bluetooth Connectivity (BT v5.3)

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode.
2. Enable Bluetooth on your smartphone or other device.
3. Search for "ZEB-AXON 100" in the list of available devices and select it to pair.
4. A confirmation sound will indicate successful pairing.

AUX Input

Connect your audio device directly using the provided 3.5mm audio cable to the AUX port on the speaker.

USB Playback

Insert a USB flash drive containing MP3 audio files into the USB port. The speaker will automatically begin playback.

True Wireless Stereo (TWS) Function

Pair two ZEBRONICS AXON 100 speakers together for a true stereo sound experience.



Image: Two ZEBRONICS AXON 100 speakers demonstrating the True Wireless Stereo (TWS) function, providing a wider soundstage.

1. Ensure both AXON 100 speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary), press and hold the TWS button.
3. The speakers will automatically connect to each other. A confirmation tone will sound.
4. Once paired, connect your device to the primary speaker via Bluetooth. Audio will play through both speakers in stereo.

Audio Features and EQ Modes

The AXON 100 features quad drivers (2x 7.63cm full-range drivers, 2x 3.81cm tweeters) and dual passive radiators for powerful 90W RMS output and deep bass.

Speaker with 4 Drivers

7.62cm x 2
Full Range Driver

3.81cm x 2
Tweeter



Image: Diagram illustrating the speaker's internal configuration with two 7.62cm full-range drivers and two 3.81cm tweeters.

Dual Passive Radiators



Image: The speaker positioned to highlight its dual passive radiators, which contribute to enhanced deep bass.

Enhance your audio experience with 3 EQ modes:

3 EQ Modes

Sound Monster | Equalizer Mode | Vocal Enhance



Image: The speaker displaying its RGB lights, with text indicating the three available EQ modes: Sound Monster, Equalizer Mode, and Vocal Enhance.

- **Sound Monster Mode:** For deep, powerful bass.
- **Vocal Enhance Mode:** For clear and crisp vocals.
- **Balanced Mode:** For a balanced audio playback.

Cycle through these modes using the dedicated EQ button on the control panel.

RGB LED Lights

The speaker features dynamic RGB LED lights. Use the light control button to switch between various lighting modes or turn them off.

Call Function

When connected via Bluetooth to a smartphone, the speaker can be used for hands-free calls.



Image: The speaker next to a smartphone displaying an incoming call, illustrating its call function and highlighting its IPX5 water-resistance rating.

- Press the Play/Pause button to answer or end a call.
- Press and hold the Play/Pause button to reject an incoming call.

6. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your ZEBRONICS AXON 100 speaker, follow these care guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners, waxes, or solvents.
- **Water Resistance:** The speaker has an IPX5 water-resistance rating, meaning it can withstand splashes and light water exposure. Do not submerge the speaker in water or expose it to heavy rain. Ensure all port covers are securely closed when near water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

7. TROUBLESHOOTING

If you encounter issues with your ZEBRONICS AXON 100 speaker, refer to the following common solutions:

Problem	Possible Cause	Solution
Speaker does not power on	Low battery; Power button not pressed correctly	Charge the speaker fully; Press and hold the Power button for a few seconds.
No sound	Volume too low; Incorrect input mode; Device not paired (Bluetooth); Cable not connected (AUX/USB)	Increase speaker and device volume; Switch to correct input mode (BT/AUX/USB); Re-pair Bluetooth device; Ensure cables are securely connected.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference	Ensure speaker is in pairing mode; Move device closer to speaker; Avoid strong electromagnetic interference.
TWS connection fails	Speakers already connected to other devices; Incorrect pairing procedure	Disconnect speakers from other devices; Follow TWS pairing steps precisely.
Poor sound quality	Low battery; Source audio quality; Device too far (Bluetooth)	Charge speaker; Use high-quality audio files; Move device closer to speaker.

8. SPECIFICATIONS

Detailed technical specifications for the ZEBRONICS AXON 100 speaker:

Feature	Specification
Model Name	Zeb-Axon 100
Speaker Type	Portable Speaker
Output Power (RMS)	90W
Drivers	2 x 7.63cm Full-Range, 2 x 3.81cm Tweeters
Passive Radiators	Dual Passive Radiators
Connectivity	Bluetooth v5.3, AUX, USB, TWS
Battery Life	Up to 6 hours (at 50% volume, LED off, default EQ)
Charging	Rapid Charging (DC 5V)
Water Resistance	IPX5
RGB Lights	Yes

Feature	Specification
EQ Modes	3 (Sound Monster, Vocal Enhance, Balanced)
Product Dimensions	15D x 38.5W x 20H Centimeters
Item Weight	3.08 kg
Manufacturer	Zebronics India Private Limited
Country of Origin	China

9. WARRANTY AND SUPPORT

Your ZEBRONICS AXON 100 speaker is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official ZEBRONICS website. In case of any issues or for technical support, please contact ZEBRONICS customer service. You can find contact information and frequently asked questions on the official ZEBRONICS website or by scanning the QR Code Guide provided in the box.

Thank you for choosing ZEBRONICS.

