#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Leaf /
- > Leaf Bass Pro Bluetooth Wireless Over Ear Headphones User Manual

## Leaf Leaf\_Bass\_Pro

# Leaf Bass Pro Bluetooth Wireless Over Ear Headphones User Manual

#### 1. Introduction

Thank you for choosing the Leaf Bass Pro Bluetooth Wireless Over Ear Headphones. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your headphones to ensure an optimal audio experience. The Leaf Bass Pro headphones feature powerful 40mm drivers for high-definition sound and deep bass technology, minimizing distortion with a 32 Ohm impedance. They offer a comfortable fit with ultra-soft cushion ear cups and a headband, and are designed to be sweat-proof and gym-friendly.



Image 1.1: Front view of the Leaf Bass Pro Bluetooth Wireless Over Ear Headphones.

# 2. WHAT'S IN THE BOX

Upon opening your Leaf Bass Pro package, please ensure all the following items are present:

- Leaf Bass Pro Headphones
- USB Charging Cable
- User Manual (this document)
- · Warranty Card

# 3. PRODUCT FEATURES

- Extended Battery Life: Enjoy up to 50 hours of continuous wireless music playback on a single charge.
- Superior Comfort: Designed with ultra-soft cushion ear cups and a padded headband for

comfortable wear during prolonged use.

- **Dual Connectivity:** Connect wirelessly via Bluetooth v5.1 or use the included 3.5mm AUX cable for wired listening, even when the battery is depleted.
- **High-Definition Audio:** Equipped with 40mm dynamic drivers that deliver crisp sound and deep bass.
- Integrated Microphone: Features a Hi-Fi microphone for clear hands-free calling.
- Sweat Resistance: Suitable for gym use and active lifestyles.
- Dual Pairing: Connect to two devices simultaneously.
- **Multiple EQ Modes:** Customize your audio experience with various equalizer settings for Bass, Pop, and Vocals.



Image 3.1: Illustration of the soft over-ear cushions for enhanced comfort.

# Go wireless with Bass Pro

Bluetooth v5.1



Image 3.2: Visual representation of the headphones' multiple EQ modes for varied sound profiles.

#### 4. SETUP

## 4.1 Charging the Headphones

- 1. Connect the smaller end of the USB charging cable to the charging port on your Leaf Bass Pro headphones.
- 2. Connect the larger end of the USB cable to a compatible USB power source (e.g., computer USB port, wall adapter).
- 3. The LED indicator on the headphones will illuminate to show charging status.
- 4. A full charge takes approximately 2.5 hours. The LED indicator will change or turn off once charging is complete.

#### 4.2 Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator flashes.
- To Power Off: Press and hold the Power button for approximately 5 seconds until the LED indicator

turns off.

#### 4.3 Bluetooth Pairing

- 1. Ensure the headphones are fully charged and powered off.
- 2. Press and hold the Power button for about 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
- 3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
- 4. Select "Leaf Bass Pro" from the list of found devices.
- 5. Once connected, the LED indicator will typically show a solid blue light or flash blue slowly.
- 6. The headphones support Bluetooth v5.1 for stable and efficient wireless connection.



Image 4.1: The Leaf Bass Pro headphones demonstrating dual pairing capability with multiple devices.

# 4.4 Auxiliary Connection

For wired listening, use the 3.5mm audio jack:

- Insert one end of a 3.5mm audio cable (not always included, but compatible) into the AUX port on the headphones.
- Connect the other end to the 3.5mm audio output of your device.

• The headphones will automatically switch to wired mode. This mode works even if the headphone battery is depleted.

#### 5. OPERATING INSTRUCTIONS

#### **5.1 Controls Overview**

The control buttons are typically located on one of the earcups. Refer to the diagram below for common button functions:



Image 5.1: Side view illustrating the location of control buttons on the earcup.

- Power Button: Press and hold to power on/off, enter pairing mode.
- Volume Up (+): Short press to increase volume.
- Volume Down (-): Short press to decrease volume.
- Multi-function Button (often integrated with Power or a separate button):Play/Pause, Answer/End Call.
- Next Track: Long press Volume Up (+).

• Previous Track: Long press Volume Down (-).

#### 5.2 Music Playback

- Play/Pause: Press the Multi-function button once.
- Next Track: Long press the Volume Up (+) button.
- Previous Track: Long press the Volume Down (-) button.
- Volume Adjustment: Short press Volume Up (+) or Volume Down (-) buttons.

#### 5.3 Call Management

- Answer/End Call: Press the Multi-function button once during an incoming call or an active call.
- **Reject Call:** Press and hold the Multi-function button for approximately 2 seconds during an incoming call.
- Redial Last Number: Double-press the Multi-function button when no call is active.

#### 5.4 EQ Mode Selection

The Leaf Bass Pro headphones offer multiple EQ modes to tailor your listening experience. Consult your device's audio settings or the headphone's specific controls (if available, often a dedicated EQ button or a combination press) to switch between Bass, Pop, and Vocal modes.

#### 6. MAINTENANCE

#### 6.1 Cleaning

- Gently wipe the headphones with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- · Avoid getting moisture into any openings.

#### 6.2 Storage

- · Store the headphones in a cool, dry place away from extreme temperatures and direct sunlight.
- When not in use for extended periods, it is recommended to charge the headphones at least once
  every three months to maintain battery health.
- The headphones feature a foldable design for convenient storage and portability.

#### 6.3 Water Resistance

The Leaf Bass Pro headphones are designed to be sweat-resistant, making them suitable for workouts and light exposure to moisture. However, they are not waterproof. Avoid submerging them in water or exposing them to heavy rain.

#### 7. TROUBLESHOOTING

Problem Possible Cause Solution
---------------------------------

Problem	Possible Cause	Solution
Headphones do not power on	Low battery	Charge the headphones fully (approx. 2.5 hours).
Cannot pair with device	Headphones not in pairing mode; Bluetooth off on device; device too far	Ensure headphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Keep devices within 10 meters. Try restarting both devices.
No sound or low volume	Volume too low; incorrect audio source; loose AUX cable	Increase volume on both headphones and connected device. Ensure correct audio output is selected on your device. Check AUX cable connection if using wired mode.
Poor sound quality	Interference; low battery; device too far	Move closer to the connected device. Charge headphones. Avoid environments with strong Wi-Fi or other Bluetooth signals.
Microphone not working	Incorrect input device selected; software issue	Ensure Leaf Bass Pro is selected as the input device in your computer/phone settings. Restart the device.

# 8. SPECIFICATIONS

Feature	Specification
Model Name	Leaf Bass Pro
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm Jack)
Wireless Communication Technology	Bluetooth v5.1
Audio Driver Type	Dynamic Driver
Driver Size	40mm
Impedance	32 Ohm
Frequency Response	20 Hz - 20,000 Hz
Battery Life	Up to 50 Hours
Charging Time	Approx. 2.5 Hours
Earpiece Shape	Over-ear
Material	Plastic
Item Weight	175 Grams

Feature	Specification
Water Resistance Level	Water Resistant (Sweat-proof)
Control Type	Call Control, Push Button
Compatible Devices	Cellphones, Laptops
Product Dimensions	15.9 x 8.6 x 18.5 cm

#### 9. WARRANTY AND SUPPORT

Your Leaf Bass Pro headphones come with a 1-year warranty. Please refer to the included Warranty Card for detailed terms and conditions. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Leaf customer service through their official website or the contact information provided on your warranty card.

**Manufacturer:** Leaf Studios Pvt. Ltd., G3 2nd Floor, Sector 63 Noida Gautam Buddha Nagar Uttar Pradesh India-201301

© 2024 Leaf Studios Pvt. Ltd. All rights reserved.

#### Related Documents - Leaf\_Bass\_Pro



#### A013 Air Hockey Table Assembly Instructions

Detailed assembly instructions for the Leaf A013 Air Hockey Table, including a parts list and step-by-step guidance for safe and efficient installation.



#### Leaf WYJSP08 & WYJSP07 Slate Pool Table Assembly Instructions

Detailed assembly instructions for the Leaf WYJSP08 and WYJSP07 Slate Pool Table, including a comprehensive parts list and step-by-step guidance for setup.



#### Purple Leaf Furniture Warranty and Safety Information

This document outlines the warranty terms and safety precautions for Purple Leaf furniture, including warnings about choking hazards and care instructions.



#### COMCHOI Cordless Leaf Blower: 180° Rotary Adjustment and Dual Mode Operation

Learn how to assemble and operate the COMCHOI cordless leaf blower, featuring a 180° adjustable handle for versatile cleaning in tight spaces and crevices. Easy tool-free assembly.



#### AIVOLT YA66012 40V Cordless Leaf Blower User Manual

Comprehensive user manual for the AIVOLT YA66012 40V Cordless Leaf Blower. This guide covers product features, safety instructions, assembly, operation, maintenance, troubleshooting, and warranty information.



#### Leisch Life 20V Cordless Leaf Blower HL-BS01 User Manual

Instruction manual for the Leisch Life 20V Cordless Leaf Blower, Model # HL-BS01. Includes safety notices, product description, operation instructions, troubleshooting, and warranty information.