

Trust 25548

Trust Tanor 1080p Webcam User Manual

Model: 25548

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Trust Tanor 1080p Webcam. Designed for clear video calls, this Full HD webcam offers a resolution of 1080p, ensuring high-quality visual communication for various applications including online meetings and streaming.

PRODUCT OVERVIEW AND FEATURES

The Trust Tanor webcam is engineered for optimal performance in various communication scenarios. Key features include:

- **Ultimate Clarity:** Full HD resolution of 1980 x 1080 at 30 frames per second for incredibly clear videos.
- **Integrated Microphone:** Built-in microphone ensures clear audio capture for your communications.
- **Wide Field of View:** A 75° field of view provides an optimal viewing angle for video calls.
- **Privacy Filter:** Equipped with a physical closure to protect your privacy when the webcam is not in use.
- **Universal Stand:** Features a versatile stand for secure placement on monitors or tripods.
- **Instant Connection:** Plug and play USB connectivity for immediate use without driver installation.
- **Sustainably Designed:** Constructed with 85% recycled plastic.

Full HD webcam

INTEGRATED
MICROPHONE

ACTIVITY
INDICATOR
LIGHT

PRIVACY
FILTER

USB-A
POWERED

MOUNT
TRIPOD TO THE
1/4" THREAD




Figure 1: Overview of the Trust Tanor Webcam highlighting its integrated microphone, activity indicator light, USB-A power, privacy filter, and tripod mount thread.

SETUP

Follow these steps to set up your Trust Tanor webcam:

1. **Connect the Webcam:** Plug the USB cable of the Trust Tanor webcam into an available USB port on your computer (desktop or laptop). The webcam is designed for plug-and-play functionality, requiring no additional driver installation for most operating systems (Windows, macOS, Linux).
2. **Position the Webcam:** Utilize the universal stand to securely place the webcam. It can be placed directly on top of your monitor or laptop screen. Ensure the stand is stable and the webcam is facing the desired direction.
3. **Optional Tripod Mounting:** The universal stand also features a 1/4" thread at the bottom, allowing it to be mounted on a compatible tripod for alternative positioning.

Privacy filter




Figure 2: The Trust Tanor Webcam securely placed on top of a computer monitor, demonstrating easy placement.

OPERATING INSTRUCTIONS

Once the webcam is set up, you can begin using it for your communication needs:

- **Initiating Video Calls:** Open your preferred video conferencing application (e.g., Zoom, Microsoft Teams, Skype). The webcam should be automatically detected as a video and audio input device. Select "Trust Tanor Webcam" as your camera and microphone in the application's settings.
- **Using the Microphone:** The integrated microphone will capture your voice clearly. Ensure it is selected as the default microphone in your system's sound settings and your video conferencing application.
- **Privacy Filter:** To ensure privacy when the webcam is not in use, slide the physical privacy filter over the lens. This physically blocks the camera view.

Easy placement



Figure 3: The Trust Tanor Webcam with its physical privacy filter closed, demonstrating how to ensure privacy.

MAINTENANCE

To ensure the longevity and optimal performance of your Trust Tanor webcam, follow these simple maintenance guidelines:

- **Cleaning the Lens:** Gently wipe the webcam lens with a soft, lint-free cloth. For stubborn smudges, a small amount of lens cleaning solution can be applied to the cloth (not directly to the lens). Avoid abrasive materials or harsh chemicals.
- **Cleaning the Body:** Use a dry or slightly damp soft cloth to clean the body of the webcam. Do not immerse the device in water or use excessive moisture.
- **Storage:** When not in use for extended periods, store the webcam in a clean, dry place away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

If you encounter issues with your Trust Tanor webcam, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Webcam not detected	Loose USB connection, faulty USB port, driver conflict.	Ensure the USB cable is securely plugged in. Try a different USB port. Restart your computer. Check Device Manager (Windows) or System Information (macOS) to see if the webcam is listed.
No video output	Privacy filter closed, incorrect camera selection in software, application permissions.	Slide the privacy filter open. Verify that "Trust Tanor Webcam" is selected as the video input in your conferencing application's settings. Check your operating system's privacy settings to ensure applications have permission to access the camera.
No audio from microphone	Incorrect microphone selection, microphone muted, application permissions.	Ensure "Trust Tanor Webcam" is selected as the microphone input in your application and system sound settings. Check if the microphone is muted in the application or system. Verify application permissions for microphone access.
Poor video quality	Insufficient lighting, dirty lens, network bandwidth issues.	Ensure adequate lighting in your environment. Clean the webcam lens gently. Check your internet connection speed and stability. Close other bandwidth-intensive applications.

SPECIFICATIONS

Detailed technical specifications for the Trust Tanor 1080p Webcam:

Feature	Detail
Brand	Trust
Model Number	25548
Video Capture Resolution	1080p (Full HD)
Frame Rate	30 FPS
Field of View	75°
Focus Type	Fixed Focus
Microphone	Integrated
Connectivity Technology	USB (Plug & Play)
Privacy Feature	Physical Privacy Filter
Mounting Type	Universal Stand (Monitor/Tripod)
Material	85% Recycled Plastic
Item Weight	4.2 ounces (120 Grams)
Product Dimensions	2.09 x 3.66 x 2.13 inches







Feature	Detail
Compatible Devices	Desktops, Laptops, Personal Computers

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Trust website or contact Trust customer service. Keep your purchase receipt as proof of purchase. Additional protection plans may be available for purchase separately to extend coverage beyond the standard warranty period. Please check with your retailer for details on available protection plans.

© 2025 Trust. All rights reserved.

Related Documents - 25548

	Trust Tanor Full HD Webcam User Guide User guide for the Trust Tanor Full HD webcam, providing setup instructions and product information. Learn how to connect and position your webcam for optimal use.
	Trust TW-200 Full HD Webcam with Privacy Filter - User Guide Concise guide for the Trust TW-200 Full HD webcam, detailing setup, privacy filter usage, and support resources. Optimized for accessibility and search engines.
	Trust TW-250 2K Webcam with Privacy Filter User Guide User guide for the Trust TW-250 2K Webcam, providing setup instructions and product information for optimal use.
	Trust MaDell Desk Microphone for PC & Laptop: Installation Guide and FAQ Comprehensive installation guide and frequently asked questions for the Trust MaDell Desk Microphone (model 21672). Learn how to set up, connect, and configure your PC or laptop microphone for optimal performance. Features step-by-step Windows 10/8/7 instructions.
	Trust Primo Webcam: Quick Installation & Setup Guide Get your Trust Primo Webcam up and running with this easy-to-follow installation guide. Covers connection, focus, and audio settings for Windows 8, 7, Vista, and 10.
	Trust PRIMO Microphone for PC & Laptop Quick Installation Guide Quick installation guide for the Trust PRIMO microphone, detailing setup, connection options (USB and audio jacks), and Windows installation steps.