

[manuals.plus](#) /

› [Marley](#) /

› [House of Marley Liberate Open-Ear True Wireless Earbuds Instruction Manual \(Model EM-JE104-CE\)](#)

**Marley EM-JE104-CE**

# House of Marley Liberate Open-Ear True Wireless Earbuds Instruction Manual

Model: EM-JE104-CE

Brand: Marley

## 1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your House of Marley Liberate Open-Ear True Wireless Earbuds. These earbuds are designed for comfort and superior audio quality, featuring a 12mm driver and built-in microphones for clear communication.



Figure 1: House of Marley Liberate Open-Ear True Wireless Earbuds and Charging Case.

### Key Features:

- **Extended Playtime:** Up to 6 hours on a single charge, with an additional 14 hours provided by the charging case, totaling 20 hours.
- **Quick Charge:** A 15-minute charge provides approximately 1 hour of playback.
- **Enhanced Audio:** Equipped with 12mm drivers for powerful sound.
- **Clear Calls:** Built-in microphones ensure crystal-clear call quality.
- **Comfortable Open-Ear Fit:** Ergonomically designed for extended wear without discomfort.
- **Eco-Friendly Design:** Constructed from recycled plastics and sustainable bamboo, with fully recyclable packaging.

## 2. WHAT'S IN THE Box

Verify that all items are present in the packaging:

- House of Marley Liberate Open-Ear True Wireless Earbuds (Left and Right)
- Charging Case
- USB-A to USB-C Charging Cable
- Quick Start Guide



Figure 2: Package contents, including earbuds, charging case, and charging cable.

## 3. SETUP

### 3.1 Charging the Earbuds and Case

Before first use, fully charge your Liberate earbuds and charging case. The charging case provides additional power for on-the-go use.

1. Place the earbuds into the charging case, ensuring they are seated correctly.
2. Connect the USB-A to USB-C charging cable to the charging port on the case and a compatible USB power source.
3. The LED indicator on the case will show charging status. Refer to the Quick Start Guide for specific LED behaviors.
4. A full charge provides up to 6 hours of playtime for the earbuds and an additional 14 hours with the charging case. A quick 15-minute charge can provide approximately 1 hour of playtime.

### **3.2 Bluetooth Pairing**

Pair your Liberate earbuds with your device via Bluetooth for wireless audio.

1. Ensure the earbuds are charged and in the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode (indicated by flashing LED lights on the earbuds).
3. On your device (smartphone, tablet, computer), navigate to the Bluetooth settings.
4. Select "Liberate" from the list of available devices.
5. Once connected, the earbuds' LED indicators will stop flashing or change to a solid color (refer to the Quick Start Guide for exact indications).

## **4. OPERATING THE EARBUDS**

### **4.1 Wearing the Earbuds**

The Liberate earbuds feature an open-ear design for comfort and situational awareness.

1. Identify the Left (L) and Right (R) earbuds.
2. Gently place each earbud over your ear, ensuring the speaker portion is positioned to direct sound into your ear canal without fully sealing it.
3. Adjust the earbud for a secure and comfortable fit. The open-ear design allows for ambient sound to be heard.



Figure 3: Proper placement of the Liberate earbuds for an open-ear fit.

## 4.2 Touch Controls

The Liberate earbuds utilize touch controls for various functions:

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.
- **Answer/End Call:** Tap once on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple-tap either earbud.



Figure 4: Touch control area on the earbud.

## 5. MAINTENANCE

To ensure the longevity and optimal performance of your Liberate earbuds, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or liquids.

## 6. TROUBLESHOOTING

If you encounter issues with your Liberate earbuds, try the following solutions:

- **No Sound:** Ensure the earbuds are charged, properly paired, and the volume on your device is turned up.
- **Pairing Issues:** Turn off Bluetooth on your device, then turn it back on. Remove "Liberate" from your device's paired list and attempt to re-pair.
- **Earbuds Not Charging:** Ensure the charging cable is securely connected and the power source is active. Check for any debris in the charging port of the case or on the earbud contacts.
- **Uncomfortable Fit:** Adjust the earbuds' position on your ear until a comfortable and secure fit is achieved.

## 7. SPECIFICATIONS

Feature	Detail
Model Name	Liberate
Model Number	EM-JE104-CE
Connectivity Technology	Wireless (Bluetooth 5.0)
Audio Driver Type	Dynamic Driver (12mm)
Battery Life (Earbuds)	6 Hours
Total Playtime (with Case)	20 Hours
Quick Charge	15 min charge = 1 hour playtime
Control Method	Touch
Ear Placement	Open Ear
Material	Recycled Plastics, Sustainable Bamboo
Item Weight	0.06 Kilograms (2.11 ounces)
UPC	846885011515

## 8. WARRANTY AND SUPPORT

House of Marley products are backed by a manufacturer's warranty. For detailed warranty information, product registration, or technical support, please visit the official House of Marley website or contact their customer service. Keep your proof of purchase for warranty claims.

© 2024 House of Marley. All rights reserved.