

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Best Choice Products](#) /

› [Best Choice Products 5ft Lighted Pop-Up Santa \(Model SKY8602\) Instruction Manual](#)

## Best Choice Products SKY8602

# Best Choice Products 5ft Lighted Pop-Up Santa Instruction Manual

Model: SKY8602

## 1. INTRODUCTION

Thank you for choosing the Best Choice Products 5ft Lighted Pop-Up Santa. This outdoor Christmas decoration is designed to add a festive touch to your holiday display with its vibrant LED lights and classic design. This manual provides essential information for safe assembly, operation, and maintenance of your product.





Image: The 5ft Lighted Pop-Up Santa, showcasing its illuminated design with a candy cane and gift box.

# Weather-Friendly Design

Shimmering polyester over a durable metal frame provides lasting quality



Durable Fabric



Weather Resistant



Plush Material



Image: Close-up of the Santa's classic details, including wire-frame glasses and a holly leaf accent.

## 2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- For Outdoor Use Only:** This product is designed for outdoor use. Do not use indoors.
- Assembly:** Follow assembly instructions carefully. Ensure all connections are secure before plugging in.
- Flammable Materials:** Keep the decoration away from flammable materials.
- Weather Conditions:** Unplug the product during severe weather conditions such as strong winds, heavy rain, or snow to prevent damage or electrical hazards.
- Children:** Keep out of reach of children and pets to prevent entanglement or injury.
- Power Source:** Use only with a 110-volt (DC) power source. Do not overload electrical outlets.
- Inspection:** Regularly inspect the product for any damage to the cord, lights, or frame. Discontinue use if damage is found.

### 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer service.

- Pop-Up Santa Body (Fabric and Frame)
- Central Support Pole
- Boot Ring/Base
- Candy Cane Accessory
- Gift Box Accessory
- Wire-Frame Glasses
- Power Adapter
- Ground Stakes (for securing)

### 4. ASSEMBLY INSTRUCTIONS

---

Assembly typically takes up to 30 minutes. Follow these steps for proper setup.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Expand Body:** Gently expand the pop-up Santa body to its full shape.
3. **Insert Central Pole:** Thread the central support pole into the designated opening within the Santa's body.
4. **Attach to Boot Ring:** Securely attach the bottom of the central pole to the boot ring/base. Ensure it is stable.
5. **Attach Accessories:** Attach the candy cane, gift box, and wire-frame glasses to their respective positions on the Santa figure.
6. **Secure to Ground:** Use the provided ground stakes to secure the Santa to the ground, especially in outdoor settings, to prevent tipping.
7. **Connect Power:** Plug the power adapter into the Santa's power port, then into a suitable outdoor electrical outlet.

# Easy Assembly

1

Thread the central pole  
into the pop-up body

2

Attach the pole  
to the boot ring

3

Attach the candy cane,  
giftbox, and glasses



Image: Visual guide for the assembly process, illustrating the three main steps.

## 5. OPERATING INSTRUCTIONS

The Best Choice Products 5ft Lighted Pop-Up Santa is designed for simple operation.

- **Placement:** Position the Santa on a flat, stable surface in your desired outdoor location. Ensure it is secured with ground stakes.
- **Power On:** Once assembled and plugged into a working outdoor outlet, the 250 LED lights will illuminate. The candy cane and gift box feature twinkling lights.
- **Power Off:** To turn off the lights, simply unplug the power adapter from the electrical outlet.

# Large Pop-Up Santa Claus

These jolly gentlemen, available in 3ft, 5ft, or 8ft sizes, will brighten your holiday home




Image: Details on the 250 LED lights, including twinkling features on the candy cane and gift.

## 6. MAINTENANCE


Proper maintenance will extend the life of your lighted Santa decoration.

- **Cleaning:** To clean, gently wipe the fabric with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** The decoration is collapsible for easy storage. After the holiday season, unplug, disassemble, and store in a cool, dry place away from direct sunlight.
- **Weather Resistance:** The shimmering polyester fabric over a powder-coated wire frame is designed to withstand outdoor elements. However, for prolonged durability, consider bringing the decoration indoors during extreme weather conditions.

# 250 LED Lights



Bright White  
Fairy LEDs



Cool to the Touch



Environmentally  
Friendly



Image: Information on the weather-friendly design and durable materials.

## 7. TROUBLESHOOTING

If you encounter issues with your lighted Santa, refer to the following common problems and solutions.

- **Lights Not Illuminating:**

- Ensure the power adapter is securely plugged into both the Santa and a working electrical outlet.
- Check the outlet by plugging in another device.
- Inspect the power cord and light strands for any visible damage.

- **Santa is Unstable/Tipping:**

- Ensure the central pole is fully inserted and secured to the boot ring/base.
- Verify the Santa is placed on a flat, level surface.
- Use all provided ground stakes to firmly anchor the decoration to the ground.

- **Accessories (e.g., Glasses) Fall Off:**

- Some accessories may require minor adjustments or additional securing (e.g., with a small piece of clear tape or fishing line) to remain in place, especially in windy conditions.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	SKY8602
Overall Dimensions (L x W x H)	25" x 38" x 60"
Item Weight	13 lbs
Frame Material	Metal
Fabric Material	Polyester
Number of LED Lights	250
Voltage	110 Volts (DC)
Color	Red
UPC	842957152421

# Product Dimensions



Image: Visual representation of the Santa's dimensions.

## 9. WARRANTY AND SUPPORT

For information regarding warranty coverage or customer support, please refer to the product packaging or contact Best Choice Products directly through their official website or the retailer where the product was purchased. Keep your purchase receipt for warranty claims.

---

© 2025 Best Choice Products. All rights reserved.