



[Manuals.plus](#) /

› [COVOZAMA](#) /

› COVOZAMA N8 Plus FC Game Cartridge User Manual

## COVOZAMA N8 Plus FC

# COVOZAMA N8 Plus FC Game Cartridge User Manual

Model: N8 Plus FC

## 1. INTRODUCTION

---

The COVOZAMA N8 Plus FC Game Cartridge is designed to provide an extensive retro gaming experience. This cartridge is compatible with original FC (Family Computer) consoles and most compatible FC consoles, offering 3000 classic games. It features high-speed loading, automatic save/load functionality, and supports FC/NES game cheat codes. An 8GB SD card is included for game saves and data management.

## 2. PRODUCT FEATURES

---

- **Wide Compatibility:** Designed for original FC consoles and compatible with most third-party FC consoles.
- **Extensive Game Library:** Includes 3000 built-in classic FC games.
- **High-Speed Loading:** Games load quickly, typically within 4-8 seconds.
- **Automatic Save/Load:** Supports automatic saving and loading of game progress.
- **Cheat Code Support:** Compatible with FC/NES game cheat codes.
- **SD Card Support:** Supports FAT/FAT16/FAT32 format memory cards up to 32GB.
- **Included Accessory:** Comes with an 8GB SD card.

## 3. SETUP INSTRUCTIONS

---

### 3.1 Unpacking and Inspection

Carefully remove the N8 Plus FC Game Cartridge and the included 8GB SD card from its packaging. Inspect both items for any visible damage.

### 3.2 Inserting the SD Card




Image: SD card slot on the side of the N8 Plus FC Game Cartridge.

Locate the SD card slot on the side of the N8 Plus FC Game Cartridge. Insert the provided 8GB SD card into the slot until it clicks into place. Ensure the card is inserted correctly with the metal contacts facing down (or as indicated by the cartridge design).

### **3.3 Inserting the Game Cartridge into the Console**




Image: Connector pins of the N8 Plus FC Game Cartridge.

With your FC or compatible console powered off, carefully insert the N8 Plus FC Game Cartridge into the console's cartridge slot. Apply gentle, even pressure until the cartridge is fully seated. Do not force the cartridge.

**Important Compatibility Note:** This cartridge is designed for original FC consoles. It is not compatible with counterfeit assembled game consoles. Using an original FC console is recommended for optimal performance.

### 3.4 Powering On

Once the cartridge is securely inserted, power on your FC console. The cartridge's main menu should appear on your screen.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Navigating the Game Menu

Use your console's directional pad (D-pad) to navigate through the list of 3000 built-in games. Press the 'A' button (or equivalent) to select a game and the 'B' button (or equivalent) to go back or cancel.

### 4.2 Starting a Game

Select your desired game from the menu and press the 'A' button. The game will begin loading, typically within 4-8 seconds.

### **4.3 Saving and Loading Game Progress**

The N8 Plus FC Game Cartridge supports automatic saving and loading. Specific instructions for in-game saving will depend on the individual game. Refer to the game's original instructions if available. The cartridge's system will manage save states on the inserted SD card.

### **4.4 Using Cheat Codes**

The cartridge supports FC/NES game cheat codes. The method for entering and activating cheat codes may vary. Consult the cartridge's on-screen menu or any included digital documentation for specific instructions on how to input and manage cheat codes.

### **4.5 Managing SD Card Content**

The included 8GB SD card is pre-formatted and contains the game library. If you need to manage files or add additional content (e.g., ROMs, save files), ensure your SD card is formatted to FAT, FAT16, or FAT32. The cartridge supports SD cards up to 32GB.

## **5. MAINTENANCE**

---

### **5.1 Cleaning the Cartridge**



Image: Back of the N8 Plus FC Game Cartridge with caution text.

To clean the cartridge, gently wipe the exterior with a soft, dry cloth. For the connector pins, use a cotton swab lightly dampened with isopropyl alcohol, then allow to dry completely before reinserting into the console.

**Caution:** DO NOT CLEAN WITH BENZENE, THINNER, ALCOHOL, OR OTHER SUCH SOLVENTS, as these can damage the cartridge materials.

## 5.2 Storage

Store the N8 Plus FC Game Cartridge in a cool, dry place away from direct sunlight and extreme temperatures. DO NOT IMMERSE IN WATER or expose to high humidity.

## 6. TROUBLESHOOTING

---

### • Cartridge Not Recognized:

- Ensure the cartridge is fully and correctly inserted into the console slot.
- Clean the cartridge's connector pins and the console's slot with isopropyl alcohol if dust or debris is suspected.
- Verify that your console is an original FC or a compatible model, as counterfeit consoles may not work.

- **Games Not Loading or Freezing:**
  - Check if the SD card is properly inserted.
  - Ensure the SD card is formatted to FAT, FAT16, or FAT32.
  - If issues persist, try removing and reinserting the SD card.
- **General Performance Issues:**
  - Ensure your console's power supply is stable.
  - If problems continue, refer to the customer support section.

## 7. SPECIFICATIONS

---

- **Model:** N8 Plus FC Game Cartridge
- **Manufacturer:** COVOZAMA
- **Compatibility:** Original FC consoles, most compatible FC consoles
- **Built-in Games:** 3000 classic FC games
- **Loading Speed:** Approximately 4-8 seconds per game
- **SD Card Support:** Up to 32GB (FAT/FAT16/FAT32 format)
- **Included SD Card:** 8GB
- **Language:** English
- **ASIN:** B0DN5G61PB
- **Release Date:** November 14, 2024

## 8. WARRANTY INFORMATION

---

Specific warranty details are not provided in the product information. Please refer to the retailer or manufacturer's official website for current warranty terms and conditions.

## 9. CUSTOMER SUPPORT

---

If you have any questions, encounter issues, or require further assistance with your COVOZAMA N8 Plus FC Game Cartridge, please contact COVOZAMA customer service. Refer to your purchase documentation or the COVOZAMA store page on Amazon for contact information.