

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Mikado](#) /

› [Mikado MD-W8 Bluetooth Speaker with Wireless Charging, Alarm Clock, and RGB Night Light User Manual](#)

Mikado MD-W8

Mikado MD-W8 Bluetooth Speaker User Manual

MODEL: MD-W8

Introduction

This manual provides detailed instructions for the Mikado MD-W8 Bluetooth Speaker, a versatile device combining a high-quality Bluetooth speaker, wireless charging pad, alarm clock, and RGB night light. Please read this manual carefully before use to ensure proper operation and to maximize your product experience.

Safety Information

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the specified charging cable and adapter to prevent damage.
- Ensure proper ventilation when using the wireless charging function.

Product Overview

The Mikado MD-W8 integrates multiple functionalities into a compact design. Familiarize yourself with the device's components:



Image 1: Front View. This image displays the front of the Mikado MD-W8, highlighting its digital LED clock display and the row of control buttons located below it. The RGB light strip is visible along the top edge.



Image 2: Top Angled View. This image shows the Mikado MD-W8 from an elevated angle, clearly featuring the wireless charging pad on its top surface. The RGB lighting is active, and the digital clock display is visible on the front.



Image 3: Rear View with Ports. This image provides a clear view of the rear panel of the Mikado MD-W8, detailing the various input ports available for connectivity and power.

Setup

1. Initial Charging

Before first use, fully charge the Mikado MD-W8. Connect the provided USB charging cable to the device's charging port (refer to Image 3 for port location) and plug the other end into a compatible USB power adapter (not included). The device features a 1200mAh battery for portable use.

2. Power On/Off

- To power on, press and hold the Power button (usually indicated by a power symbol) until the display lights up.
- To power off, press and hold the Power button again until the display turns off.

3. Bluetooth Pairing

1. Ensure the MD-W8 is powered on.
2. The device will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth icon on the display.
3. On your smartphone, tablet, or computer, navigate to the Bluetooth settings.
4. Select "MD-W8" from the list of available devices.
5. Once paired, the Bluetooth icon will stop flashing and remain solid. You can now play audio wirelessly.

Operating Instructions

1. Bluetooth Speaker Function

After successful Bluetooth pairing, you can stream audio from your connected device. Use the control buttons on the MD-W8 (refer to Image 1) or your connected device to adjust volume, skip tracks, or pause/play music.

- **Play/Pause:** Press the Play/Pause button.
- **Volume Up/Down:** Use the volume control buttons.
- **Next/Previous Track:** Use the track skip buttons.

2. Wireless Charging

The MD-W8 features a Qi-compatible wireless charging pad on its top surface.

1. Place your Qi-compatible smartphone or other device directly onto the wireless charging pad (refer to Image 2 and Image 4).
2. Ensure the device is centered on the charging pad for optimal charging.
3. A charging indicator (e.g., an icon on the MD-W8 display or on your phone) will confirm that charging has begun.



Image 4: Wireless Charging in Use. This image shows a smartphone positioned on the wireless charging pad of the Mikado MD-W8, demonstrating the charging functionality.

3. Alarm Clock

The MD-W8 includes an integrated alarm clock with an LED display.

- **Setting Time:** Use the dedicated time setting buttons (refer to Image 1) to adjust the current time.
- **Setting Alarm:** Press the Alarm button to enter alarm setting mode. Use the navigation buttons to set

the desired alarm time. Confirm your selection.

- **Snooze:** When the alarm sounds, press the Snooze button (if available) to temporarily silence it.
- **Alarm Off:** To turn off the alarm, press the Alarm button again or the Power button.

4. RGB Night Light

The device features an integrated RGB night light with various color options and effects.

- **Activating Light:** Press the Light button (refer to Image 1) to turn on the RGB night light.
- **Changing Colors/Modes:** Repeatedly press the Light button to cycle through different colors and lighting effects.
- **Turning Off Light:** Continue pressing the Light button until the light turns off, or press and hold the button.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the device. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery; power cable not connected.	Charge the device fully. Ensure the power cable is securely connected.
Cannot pair via Bluetooth.	Device not in pairing mode; too far from source; interference.	Ensure MD-W8 is in pairing mode. Move closer to the source device. Restart both devices.
Wireless charging not working.	Device not Qi-compatible; not centered; foreign objects; thick phone case.	Verify device is Qi-compatible. Reposition device on the pad. Remove any foreign objects or thick cases.
Alarm does not sound.	Alarm not set; volume too low; device powered off.	Check alarm settings. Increase volume. Ensure device is powered on.

Specifications

Brand	Mikado
Model Name	MD-W8
Product Dimensions	10 x 3.81 x 8 cm; 880 grams
Power Output	10 Watt (Speaker)
Color	Grey

Display Type	Digital LED
Power Source	Battery Powered (1200mAh)
Connectivity	Bluetooth
Special Features	Wireless Charging, Alarm Clock, RGB Night Light

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Mikado customer service. Keep your proof of purchase for warranty claims.

Related Documents - MD-W8

 <p>Mikado MD-50BT Harmony Portable Speaker User Manual and Warranty</p> <p>User manual and warranty certificate for the Mikado MD-50BT Harmony portable speaker, including product specifications, key functions, Bluetooth connection, safety instructions, and care guidelines.</p>
 <p>Mikado MD-51BT Cyclone IPX6 Wireless Speaker User Manual & Warranty</p> <p>Comprehensive user manual and warranty information for the Mikado MD-51BT Cyclone IPX6 wireless speaker. Includes specifications, operating instructions, safety guidelines, and warranty terms.</p>
 <p>Mikado MD-SBT25 USB Soundbar Speaker: User Manual, Specifications, and Warranty</p> <p>Detailed user manual for the Mikado MD-SBT25 USB Soundbar Speaker, covering technical specifications, setup, safety guidelines, warranty terms, and EC Declaration of Conformity.</p>
 <p>Mikado MD-672BT 5+1 Wireless Home Speaker User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for the Mikado MD-672BT 5+1 Wireless Home Speaker, including safety instructions, package contents, remote control guide, features, specifications, unit operation, and warranty information.</p>
 <p>Mikado LOGO 600 SE RC Helicopter Assembly and Operation Manual</p> <p>Comprehensive assembly and operational guidance for the Mikado LOGO 600 SE radio-controlled helicopter. This manual details construction steps, safety instructions, and operational procedures for users.</p>

Manual **Mikado**
RC HELICOPTERS
www.mikado-heli.de[Mikado LOGO 10 RC Helicopter Assembly and Operation Manual](#)

Comprehensive guide for the Mikado LOGO 10 remote-controlled helicopter, detailing assembly, setup, safety, and operation. Includes parts list, RC programming, and pre-flight checks.