Beyblade G0842

Beyblade X Drop Attack Battle Set Instruction Manual

Introduction

The Beyblade X Drop Attack Battle Set provides all necessary components for Beyblade battles, including a Beystadium, two tops, and two launchers. This manual details the setup, operation, and features of the set, ensuring a clear understanding of its use and functionality.

What's in the Box

- Battle Set Beystadium
- 2 Beyblade X tops (Impact Drake 9-60LR and Hover Wyvern 3-85N)
- 2 Beyblade X launchers



Figure 1: Beyblade X Drop Attack Battle Set components, including the Beystadium, two tops, and two launchers, shown with the product packaging.

Setup

1. Assemble the Beystadium

The Beystadium is designed for easy assembly. Ensure all parts are securely connected before use. Refer to the packaging for specific assembly diagrams if needed.




Figure 2: The fully assembled Beyblade X Drop Attack Beystadium, ready for play, with the two Beyblade tops and launchers positioned nearby.

2. Prepare Beyblade Tops

The Beyblade X tops consist of interchangeable blade, ratchet, and bit layers. Assemble each top by twisting and clicking the layers together until they are securely fastened.



Figure 3: A close-up view of the Impact Drake 9-60LR Beyblade X top, held in a hand, showcasing its design.



Figure 4: A close-up view of the Hover Wyvern 3-85N Beyblade X top, held in a hand, highlighting its green and silver components.

3. Attach Launchers

Attach a Beyblade top to each ripcord launcher by aligning the top with the launcher's mechanism and twisting until it locks into place.



Figure 5: Two individuals holding Beyblade X launchers with tops attached, poised to launch them into the Beystadium.

Operating Instructions

1. Launching a Beyblade

Place the assembled Beyblade and launcher into the Beystadium's launching slots. Pull the ripcord firmly to launch the Beyblade into the arena, initiating the battle.



Figure 6: An action shot of two individuals simultaneously launching their Beyblade X tops into the Beystadium, with tops spinning in the arena.

Video 1: Official demonstration of the Beyblade X Impact Drake 9-60LR and Hover Wyvern 3-85N tops in action within the Beystadium, showcasing their movement and interaction.

2. X-Celerator Rail System

The Beystadium features an X-Celerator Rail along its perimeter. When the gears of the Beyblade's bit and the X-Celerator Rail align, tops accelerate rapidly, creating powerful collisions and increasing the chance of an 'Xtreme Dash' for breathtaking bursts.

3. Drop Attack Feature

The Drop Attack Beystadium is uniquely designed with an elevated X-Celerator Rail. This allows Beyblade tops to reach a higher elevation and then drop down onto an opponent's top below, enabling a strategic downward attack.



Figure 7: A detailed view of the Beyblade X Drop Attack Beystadium, highlighting the elevated X-Celerator Rail system.

4. Scoring

Bladers launch their tops against opponents, scoring points based on battle outcomes. The first player to accumulate 4 points wins the battle. Refer to the official Beyblade X rules for detailed scoring criteria.

Beyblade Components

The Beyblade X tops are modular, composed of three main parts: the blade, the ratchet, and the bit. These parts are interchangeable with other Beyblade X tops (sold separately), allowing for extensive customization and strategic adjustments.

Impact Drake 9-60LR (Attack Type)

This top is specifically designed for aggressive attacks. Its construction and weight distribution facilitate strong impacts and rapid movement across the Beystadium, aiming to burst opponent tops.



Figure 8: A close-up of the Impact Drake 9-60LR Beyblade X top, showcasing its attack-oriented design.

Hover Wyvern 3-85N (Defense Type)

This top is engineered for defense, providing enhanced stability and resistance against opponent attacks. Its design focuses on endurance and maintaining spin, making it difficult for opponents to dislodge or burst.




Figure 9: A close-up of the Hover Wyvern 3-85N Beyblade X top, highlighting its defense-oriented structure.

Safety Information

WARNING: Small parts may be generated. Not for children under 3 years.
Always use the Beyblade X Drop Attack Battle Set on a flat, stable surface to prevent movement during play. Keep hands and face clear of the Beystadium during active play to avoid injury from rapidly spinning tops. Do not modify Beyblade components or launchers, as this may compromise safety and performance.

Specifications

- **Product Dimensions:** 3.56 x 18.19 x 14.5 inches
- **Item Weight:** 1.75 pounds
- **Item Model Number:** G0842
- **Manufacturer Recommended Age:** 8 years and up
- **Language:** English
- **Manufacturer:** Hasbro

Troubleshooting

No specific troubleshooting information is provided within the product details. For common issues such as tops not spinning correctly or launchers malfunctioning, ensure that all Beyblade top components are correctly assembled and securely attached to the launcher. Verify that the ripcord is inserted fully and pulled with sufficient force. If problems persist, refer to the manufacturer's support channels.

Warranty and Support

For warranty information or product support, please contact Hasbro customer service directly. Refer to the product packaging for specific contact details or visit the official Beyblade website for the most up-to-date support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question