



611247000000

K-Duo Essentials Hot & Iced Coffee Maker User Manual

Model: 611247000000 | Brand: Generic

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your K-Duo Essentials Hot & Iced Coffee Maker. Please read this manual thoroughly before first use and retain it for future reference.



Figure 1: The K-Duo Essentials Hot & Iced Coffee Maker, a versatile appliance for both single-serve and carafe brewing.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

COMPONENTS

Familiarize yourself with the parts of your K-Duo Essentials Coffee Maker:

- **Water Reservoir:** Large 72 oz capacity, shared for both single-serve and carafe brewing.
- **K-Cup Pod Holder:** For single-serve brewing.
- **Ground Coffee Filter Basket:** For carafe brewing with ground coffee.
- **12-Cup Glass Carafe:** Included for multi-cup brewing.
- **Heating Plate:** Keeps brewed carafe coffee warm.
- **Control Panel:** Features buttons for brew size, strong brew, brew over ice, and power.
- **Drip Tray:** Removable for easy cleaning and to accommodate taller mugs.

K·Duo

ESSENTIALS®

SINGLE SERVE & CARAFE
COFFEE MAKER



12-CUP GLASS CARAFE
and heating plate included



Figure 2: Overview of the K-Duo Essentials Coffee Maker's key features and components.

SETUP

Initial Setup and First Brew

1. **Unpack:** Remove all packaging materials and tape from the coffee maker.
2. **Clean:** Wash the carafe, carafe lid, and K-Cup pod holder in warm, soapy water. Rinse thoroughly and dry.
3. **Fill Reservoir:** Fill the water reservoir with fresh, filtered water up to the MAX fill line.

K•Duo

ESSENTIALS®

SINGLE SERVE & CARAFE
COFFEE MAKER



Figure 3: The 72oz removable water reservoir being filled, located on the side of the coffee maker.

4. **Plug In:** Plug the coffee maker into a grounded outlet. The power button will illuminate.

5. **Cleansing Brew (Single Serve):**

- Place a large mug on the drip tray.
- Lift the handle and lower it without inserting a K-Cup pod.
- Select the 8 oz brew size.
- Press the BREW button.
- Once complete, discard the hot water.

6. **Cleansing Brew (Carafe):**

- Place the empty carafe on the heating plate.
- Open the carafe brew lid and insert an empty paper filter into the filter basket. Close the lid.
- Select the 12-cup brew size.
- Press the BREW button.
- Once complete, discard the hot water.

Brewing a Single-Serve Cup

1. Ensure the water reservoir is filled.
2. Place a mug on the drip tray.
3. Lift the handle and insert a K-Cup pod into the K-Cup pod holder. Close the handle firmly.



Figure 4: A K-Cup pod being inserted into the single-serve side of the K-Duo Essentials Coffee Maker.

4. Select your desired brew size (8, 10, or 12 oz).
5. (Optional) Press the **STRONG** button for a bolder cup or the **BREW OVER ICE** button for iced coffee.
6. Press the illuminated **BREW** button. The coffee maker will begin brewing.
7. Once brewing is complete, carefully remove the K-Cup pod.

K·Duo

ESSENTIALS®
SINGLE SERVE & CARAFE
COFFEE MAKER



Figure 5: The K·Duo Essentials Coffee Maker preparing an iced coffee, demonstrating its versatility.

Brewing a Carafe

1. Ensure the water reservoir is filled.
2. Place the 12-cup glass carafe on the heating plate.

K·Duo

ESSENTIALS®

SINGLE SERVE & CARAFE
COFFEE MAKER



**USE GROUND COFFEE
OR K-CUP® PODS**
to brew a carafe
or single cup



Figure 6: The included 12-cup glass carafe positioned on the heating plate, designed to keep coffee warm.

3. Open the carafe brew lid. Insert a paper filter (basket style) into the filter basket.
4. Add desired amount of ground coffee to the filter. For best results, use 1 tablespoon of ground coffee per cup. Do not exceed 15 tablespoons. Close the carafe brew lid firmly.
5. Select your desired carafe brew size (8, 10, or 12 cups).
6. Press the illuminated **BREW** button. The coffee maker will begin brewing.
7. The heating plate will remain on for 2 hours after brewing is complete.
8. The Pause & Pour feature allows you to pour a cup mid-brew without waiting for the full carafe to finish.

K·Duo

ESSENTIALS®

SINGLE SERVE & CARAFE
COFFEE MAKER



**USE GROUND COFFEE
OR K-CUP® PODS**
to brew a carafe or single cup



BREW OVER ICE
for single serve cups,
automatically adjusts
brew temperature for
full flavor and less ice
melt for single cup



STRONG BREW
brew a stronger, more
intense single cup



MULTIPLE BREW SIZES
Carafe: 8, 10 and 12 cups
Single Cup: 8, 10 and 12oz



72oz REMOVABLE RESERVOIR



12-CUP GLASS CARAFE
and heating plate included



*Do not brew over ice into glass

Figure 7: The K-Duo Essentials Coffee Maker brewing a full carafe of coffee, ideal for multiple servings.

Official Product Video

Your browser does not support the video tag.

Video 1: A short demonstration of the K-Duo Essentials Coffee Maker's dual brewing capabilities for both hot and iced coffee.

MAINTENANCE

Cleaning

- Always unplug the coffee maker before cleaning.
- **External Cleaning:** Wipe the exterior with a damp, soapy cloth. Do not immerse the coffee maker in water.
- **Drip Tray:** The drip tray can hold up to 8 oz of overflow. It should be emptied and cleaned regularly. Remove the drip tray and wash with warm, soapy water.
- **K-Cup Pod Holder:** The K-Cup pod holder can be removed for cleaning. Separate the funnel from the holder and wash both parts.
- **Carafe and Filter Basket:** Wash the glass carafe, carafe lid, and reusable filter basket (if applicable) with warm, soapy water.

Descaling

Minerals in water can build up in your coffee maker over time, affecting performance. The DESCAL indicator light will illuminate when descaling is recommended.

1. **Prepare:** Turn off the coffee maker. Empty the water reservoir and remove any K-Cup pods or ground coffee.
2. **Solution:** Pour a full bottle of Keurig Descaling Solution into the water reservoir. If using a homemade solution (e.g., white vinegar), use 10 oz of white vinegar and 10 oz of water.
3. **First Rinse Brew (Carafe):** Place the empty carafe on the heating plate. Select the 12-cup brew size and press BREW. Discard the solution once complete.
4. **First Rinse Brew (Single Serve):** Place a large mug on the drip tray. Lift and lower the handle without a K-Cup. Select the 12 oz brew size and press BREW. Discard the solution once complete.
5. **Soak:** Let the coffee maker stand for at least 30 minutes.
6. **Second Rinse Brews:** After soaking, perform several rinse brews using only fresh water until the reservoir is empty. Repeat this process at least 3 times for both single-serve and carafe sides to ensure all descaling solution is flushed out.
7. The DESCAL light should turn off. If it remains on, repeat the descaling process.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee maker not brewing.	No water in reservoir; K-Cup pod not properly seated; Carafe lid not closed.	Fill reservoir; Ensure K-Cup pod is firmly seated; Close carafe lid completely.
Coffee tastes weak or watery.	Incorrect brew size selected; Insufficient coffee grounds; Need for descaling.	Select smaller brew size; Add more coffee grounds; Perform descaling.
DESCALE light remains on after descaling.	Descaling process not fully completed.	Repeat the descaling process.
Coffee maker leaks.	Water reservoir not seated correctly; K-Cup pod punctured incorrectly.	Ensure reservoir is firmly in place; Check K-Cup pod for proper insertion.

SPECIFICATIONS

Feature	Detail
Brand	Generic
Model Name	K-Duo Essentials Coffee Maker
Color	Black
Product Dimensions	11.02"D x 12.91"W x 12.71"H
Item Weight	10 pounds
Special Features	Brew Over Ice, Strong Brew, Pause & Pour
Coffee Maker Type	Drip Coffee Machine

Feature	Detail
Filter Type	Cup Pod Filter
Water Reservoir Capacity	72 Oz
Included Components	Coffee Maker, 12-cup glass carafe, K-Cup pod compatibility
Operation Mode	Fully Automatic
Coffee Input Type	Ground, Cup



Figure 8: Detailed dimensions of the K-Duo Essentials Coffee Maker for proper placement.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.

For additional assistance, you may visit the manufacturer's official website or contact their customer service line. Contact details are typically provided in the product's original packaging.

