

[Manuals.plus](#) /

› [EASTROCK](#) /

› EASTROCK Guitar Stool with Backrest - Instruction Manual JDGS-01BK

EASTROCK JDGS-01BK

EASTROCK Guitar Stool with Backrest - Instruction Manual JDGS-01BK

Model: JDGS-01BK

INTRODUCTION

Thank you for choosing the EASTROCK Guitar Stool with Backrest. This manual provides essential information for the safe assembly, operation, and maintenance of your new guitar stool. Please read it thoroughly before use and retain it for future reference.





Image: The EASTROCK Guitar Stool with Backrest, featuring a black padded seat and backrest, a circular footrest, and sturdy metal legs.

SAFETY INSTRUCTIONS

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity (not specified, use with caution).
- Keep children away during assembly.
- Use on a flat, stable surface to prevent tipping.
- Avoid standing on the stool.
- Regularly check all screws and connections for tightness.

PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Padded Seat Cushion
- Backrest
- Stool Frame (legs with integrated footrest)
- Swivel Mechanism
- Backrest Support Bar
- Hardware Kit (screws, washers, nuts, Allen wrench)
- Anti-Slip Foot Caps (may be pre-installed)

ASSEMBLY INSTRUCTIONS

Assembly is required. Please follow these steps carefully. It is recommended to assemble on a soft, clean surface to prevent scratches.



Image: A visual guide showing six steps for assembling the guitar stool, including attaching the steel ring, fixing contact points, placing the rotating frame, fixing corners, tightening screws, and installing the backrest.

1. **Step 1: Attach the Steel Ring to the Supporting Foot.** Secure the circular footrest to the main leg structure using the provided screws and tools.
2. **Step 2: Fix Contact Points with Four Screws.** Identify the contact points on the stool frame where the swivel mechanism will attach. Use four screws to secure these points.
3. **Step 3: Place the Rotating Frame.** Position the rotating frame (swivel mechanism) onto the top of the stool's leg structure.
4. **Step 4: Fix Four Corners to the Legs of the Stool.** Align the four corners of the rotating frame with the

corresponding attachment points on the stool legs and secure them.

- Step 5: Place Stool Legs Upside Down on the Cushion, Tighten the Four Screws.** Invert the assembled leg and swivel base. Place it onto the underside of the padded seat cushion. Align the screw holes and tighten the four screws to firmly attach the seat.
- Step 6: Installing the Seat Back.** Attach the backrest support bar to the back of the seat cushion. Then, slide the backrest onto the support bar and secure it with the adjustment knob.

OPERATING INSTRUCTIONS

360° Swivel Function

The seat is equipped with a 360-degree swivel mechanism, allowing for smooth and effortless rotation. This feature enables musicians to adjust their playing angle without repositioning the entire stool, enhancing flexibility during practice or performance.

ADJUSTABLE BACKREST

Up & Down Adjustment
Comfortable Large Backrest



Image: The EASTROCK Guitar Stool demonstrating its 360-degree swivel capability, with arrows indicating rotation.

Adjustable Backrest

The backrest is designed to support your spine and promote correct playing posture. It can be adjusted vertically to accommodate different user heights and preferred seating positions. To adjust, loosen the knob on the backrest support, slide the backrest to the desired height, and then tighten the knob securely.



STRONG APPLICABILITY

Suitable for Most Instruments That Can Be Played While Sitting



Guitar Electric Guitar Bass Ukulele Banjo

Image: Close-up views of the adjustable backrest mechanism on the EASTROCK Guitar Stool, showing the knob for height adjustment.

Integrated Footrest

The stool includes a built-in circular footrest. This footrest provides support for your legs, helping to maintain proper playing posture and reduce fatigue during extended sessions. It is suitable for both traditional and classical guitar playing positions.

MAINTENANCE

- **Cleaning:** Wipe the padded seat and backrest with a damp cloth and mild soap. Avoid harsh chemicals. For the metal frame, use a dry or slightly damp cloth.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Storage:** Store the stool in a dry environment, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stool is wobbly/unstable.	Loose screws or uneven assembly.	Ensure all screws are fully tightened. Check that the stool is on a flat, even surface.
Difficulty assembling.	Incorrect part alignment or unclear instructions.	Refer to the detailed assembly instructions in this manual. Ensure correct hardware is used for each step. Contact customer support if parts are missing.
Backrest does not stay in position.	Adjustment knob is not tightened sufficiently.	Tighten the backrest adjustment knob firmly after setting the desired height.

SPECIFICATIONS

Model: JDGS-01BK

Brand: EASTROCK

Product Dimensions: 16"D x 16"W x 32"H

Color: Black

Seat Height: 32.6 Inches

Seat Width: 14.1 Inches

Item Weight: 13 pounds

Assembly Required: Yes

Material: Padded cushion (sponges), Metal frame

PRODUCT SIZE



Image: Diagram showing the product dimensions of the EASTROCK Guitar Stool, including height, width, and depth measurements.

WARRANTY AND SUPPORT

Specific warranty details are not provided in this manual. For information regarding warranty coverage or to obtain customer support, please refer to the product's purchase documentation or contact the retailer directly. You may also visit the official EASTROCK website for further assistance.

EASTROCK Store: [Visit the EASTROCK Store on Amazon](#)

