

[Manuals.plus](#) /

> [Coleshome](#) /

> Coleshome L-Shaped Desk with Drawers, 195x100cm Gaming Desk with Power Outlet, LED & Monitor Stand, Reversible Corner Desk with Storage, Computer Desk with Shelf for Office, Black 195x100 cm

Coleshome B02022401008

Coleshome L-Shaped Desk User Manual

Model: B02022401008

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your Coleshome L-Shaped Desk. Designed for both office and gaming environments, this desk features ample storage, integrated power solutions, and customizable LED lighting. Please read this manual carefully before assembly and use to ensure proper function and longevity of your product.

SETUP AND ASSEMBLY

The Coleshome L-Shaped Desk is designed for flexible installation, allowing for a reversible configuration to best suit your space. Follow the steps below for proper assembly.

Unpacking and Component Check

- Carefully unpack all components from the packaging.
- Verify all parts are present against the included parts list (not provided in this manual, refer to your product packaging).
- Inspect all components for any damage. If any parts are missing or damaged, contact customer support immediately.

Assembly Steps

1. Begin by assembling the main desk frame according to the diagram. Ensure all screws are tightened securely.
2. Attach the L-shaped extension. Note that the desk features a reversible design, allowing the extension to be placed on either the left or right side.
3. Install the monitor stand onto the main desk surface.
4. Assemble the fabric drawers and insert them into their designated compartments.
5. Place the movable CPU stand in your desired location under the desk.
6. Connect the power strip with USB ports to a wall outlet.
7. Affix the LED light strip to the underside of the monitor stand or main desk surface as desired.



Figure 1: Desk dimensions and reversible design. This diagram illustrates the overall measurements of the desk and how the L-shaped section can be configured on either side to fit your room layout.

[illegible]

OPERATING INSTRUCTIONS

Integrated Power Outlets and USB Ports

The desk includes a built-in power strip with 2 standard AC outlets and 2 USB charging ports (5V/2.1A). Simply plug the desk's power cord into a wall outlet to activate these features. Use the AC outlets for devices like monitors or laptops, and the USB ports for charging smartphones, tablets, or other USB-powered accessories.



Langer Monitorständer

Beweglicher CPU-Ständer

Versenkte Steckdose

Figure 3: Integrated power and USB charging station. This image highlights the convenient placement of the power outlets and USB ports, along with the monitor stand and the movable CPU stand.


RGB LED Lighting System

The desk features an RGB LED light strip to create an immersive ambiance. The LED strip includes a control panel for various settings:

- **Static Colors:** Choose from 10 static color options.
- **Brightness Levels:** Adjust brightness with 6 available levels.
- **Dynamic Modes:** Select from 10 dynamic lighting modes.
- **Memory Function:** The system remembers your last setting.
- **Music Synchronization:** The lights can synchronize with your music for an enhanced experience.



Unserer



VS

Andere



Figure 4: RGB LED lighting features. This image demonstrates the range of colors and dynamic modes available with the integrated LED strip, enhancing the desk's aesthetic and user experience.

Storage Drawers and Shelving

The desk provides ample storage with four fabric drawers and a large file drawer. The fabric drawers are suitable for office supplies, small electronics, and personal items. The large file drawer is designed to accommodate standard file folders (Legal/A4 format) to keep your documents organized. The integrated shelving unit offers additional space for books, decorative items, or other equipment.

Große Aktschublade und Stauraum



Figure 5: Desk drawers with ample storage capacity. This image illustrates the practical use of the desk's drawers for organizing office supplies and personal belongings.



RGB-LED-Lichter

10 Farbvariationen 10 Beleuchtungsmodi




Figure 6: Large file drawer and dedicated printer stand. This image demonstrates the functionality of the file drawer for documents and the convenient space for a printer or scanner.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your Coleshome L-Shaped Desk.

Cleaning

- For daily cleaning, wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes as they may damage the finish.
- For spills, wipe immediately with a dry cloth to prevent staining.
- The fabric drawers can be spot cleaned with a mild detergent and water, then air-dried.

Structural Care

- Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- The desk features adjustable footpads. Adjust these to ensure the desk is level on uneven floors, preventing wobbling.
- Avoid placing excessively heavy items on the desk or shelves to prevent structural damage.




Figure 7: Desk construction details. This image highlights the durable desk surface, reinforced X-clamps for stability, and adjustable footpads for leveling, all contributing to the desk's longevity and ease of maintenance.

TROUBLESHOOTING

If you encounter any issues with your Coleshome L-Shaped Desk, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Uneven floor; loose fasteners.	Adjust the footpads at the bottom of the desk legs to level the desk. Check and tighten all assembly screws.
LED lights are not working.	Power cord not plugged in; loose LED connection; faulty LED strip.	Ensure the desk's main power cord is securely plugged into a working wall outlet. Check the connection of the LED strip to the power source. If issues persist, contact customer support.
USB ports or AC outlets are not providing power.	Desk's main power cord not plugged in; power surge; internal wiring issue.	Verify the desk's main power cord is fully inserted into a live wall outlet. Test the outlet with another device. If the issue continues, avoid using the power strip and contact customer support.
Drawers do not slide smoothly.	Overloaded drawer; obstruction; fabric creased.	Reduce the weight in the drawer. Check for any items obstructing the drawer's path. Ensure the fabric is not creased or caught.

If the problem persists after attempting these solutions, please contact Coleshome customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	Coleshome
Model Number	B02022401008

Feature	Detail
Color	Black
Product Dimensions	100D x 195W x 87H cm (39.4D x 76.8W x 34.3H inches)
Item Weight	30 Kilograms (66.1 lbs)
Special Features	Integrated USB Port, Reversible Design, LED Lighting, Monitor Stand, Movable CPU Stand
Power Outlets	2 AC Outlets (220-250V/15A)
USB Ports	2 USB Ports (5V/2.1A)
Number of Shelves	3 (including monitor stand and side shelves)
Assembly Required	Yes

WARRANTY AND SUPPORT

Coleshome is committed to providing high-quality products. For information regarding warranty coverage, please refer to the warranty card included with your product packaging or visit the official Coleshome website. For any questions, technical support, or assistance with parts, please contact Coleshome customer service.

Customer Support: Please refer to the contact information provided on your purchase receipt or the Coleshome official website for the most up-to-date support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question