Catitru

Catitru Wireless Earbuds Instruction Manual

Model: BX17

Product Overview

The Catitru BX17 Wireless Earbuds are designed for comfort and performance, especially during sports and workouts. They feature long battery life, noise-canceling microphones, and intuitive touch controls.

What's in the Box

- Wireless Earbuds (Left and Right)
- Charging Case
- User Manual
- USB Type-C Charging Cable
- Multiple Sizes of Ear Tips (Small, Medium, Large)



Image: Overview of the Catitru BX17 Wireless Earbuds and their key features, including the charging case.

Setup

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB Type-C cable to the charging port on the case and to a compatible USB power source.



Image: The charging case with earbuds, highlighting the 80-hour total playtime and LED power display.

The dual digital LED power display on the case will show the real-time battery percentage. Ensure both earbuds are properly seated in the charging case.

2. Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for "BX17" in the list of available Bluetooth devices.
5. Select "BX17" to connect. Once connected, you will hear a confirmation tone.

The earbuds feature a built-in hall switch, allowing them to auto-power on and connect to the last paired device simply by opening the charging case after the initial connection.

Your browser does not support the video tag.

Video: A demonstration of the BX17 Wireless Earbuds, showing their design, pairing process, and use. This video highlights the ease of connection and overall user experience.

3. Fitting the Earbuds

The BX17 earbuds are designed with elastic and soft ear hooks for a secure and comfortable fit, especially during physical activity. They come with three different sizes of ear tips (S, M, L) to ensure a perfect seal and optimal sound quality.

1. Choose the ear tip size that provides the best seal and comfort for your ear canal.
2. Gently insert the earbud into your ear.
3. Adjust the ear hook over the top of your ear until it feels secure and comfortable.



Image: Visual guide on selecting the correct ear tip size and properly fitting the earbud with its secure ear hook for sports activities.

Operating Instructions

Touch Controls

The earbuds feature intuitive button touch controls for easy management of music playback, volume, and calls.

Action	Control
Answer/End Call	One Tap (Left or Right earbud)
Reject Call	Long Press (Left or Right earbud)
Play/Pause Music	One Tap (Left or Right earbud)
Previous Track	Long Press (Left earbud)
Next Track	Long Press (Right earbud)
Volume Up	One Tap (Right earbud)
Volume Down	One Tap (Left earbud)
Activate Voice Assistant	Long Press (Left or Right earbud)



Image: Detailed illustration of the touch control functions on the earbuds for various operations.

Sound Quality and Noise Cancelling

The BX17 earbuds are equipped with strong 14.3mm speaker driving units and an in-ear acoustic structure, delivering powerful bass and clear treble. The unique acoustic design minimizes sound loss and ensures stable, penetrating audio. The integrated ENC (Environmental Noise Cancelling) microphone provides clear voice detection, even in noisy environments, making them ideal for calls.



Image: An exploded view of the earbud's internal components, highlighting the 14.2mm three-layer diaphragm drivers responsible for

high-quality stereo sound.



Image: The earbud design emphasizing the ENC Noise Cancelling Microphone, which eliminates background noise for clear communication.

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Avoid using abrasive materials or harsh chemicals.

Storage

Always store the earbuds in their charging case when not in use to protect them and ensure they remain charged.

Water Resistance (IPX7)

The BX17 earbuds have an IPX7 waterproof rating, meaning they can withstand splashes, sweat, and rain. They are ideal for sports and workouts. However, they are not designed for swimming or submersion in water for extended periods. Ensure the charging port is dry before charging.



Image: The earbuds demonstrating their IPX7 waterproof rating, showing resistance to water splashes and sweat.

Troubleshooting

Common Issues and Solutions

- **Earbuds not pairing:**
  - Ensure both earbuds are fully charged.
  - Turn off Bluetooth on your device and turn it back on.
  - Forget "BX17" from your device's Bluetooth list and try pairing again.
  - Place both earbuds back in the charging case, close the lid, wait a few seconds, then open the lid to re-initiate pairing mode.
- **No sound or low volume:**
  - Check the volume level on both your device and the earbuds.
  - Ensure the earbuds are properly connected to your device.
  - Clean the ear tips and speaker mesh to remove any debris.
- **Charging case not charging:**
  - Ensure the USB Type-C cable is securely connected to both the case and the power source.
  - Try a different USB cable or power adapter.
- **Earbuds not charging in case:**
  - Ensure the earbuds are correctly seated in their charging slots.
  - Check the charging pins on both the earbuds and the case for any obstructions or damage.

Specifications

Feature	Detail
Model Name	BX17
Brand	Catitru
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.3
Playtime (Earbuds)	Up to 15 hours on one charge
Total Playtime (with Charging Case)	Up to 80 hours
Charging Port	Type-C
Water Resistance Level	IPX7 (Waterproof & Sweat Resistant)
Noise Control	ENC Noise Cancelling Mic
Control Type	Touch Control
Audio Driver Size	14.3 Millimeters
Earpiece Shape	In-ear and Over-ear (with ear hooks)
Material	Plastic
Product Dimensions	1.54 x 2.76 x 1.1 inches
Item Weight	4.6 ounces
Batteries	1 Lithium Ion battery required (included)

Warranty and Support

Catitru products are manufactured with high-quality standards. For any issues or inquiries regarding your BX17 Wireless Earbuds, please refer to the following:

Warranty Information

While specific warranty details are not provided in this manual, most electronic products come with a standard manufacturer's warranty covering defects in materials and workmanship for a period of 12 months from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty service, please contact Catitru customer support through the retailer's platform where you purchased the product, or visit the official Catitru website for contact information. When contacting support, please have your product model (BX17) and purchase details ready.

For more information, visit the Catitru Brand Store on Amazon.

© 2025 Catitru. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question