



Manuals.plus /

› PocBuds /

› PocBuds V30 Open-Ear Headphones User Manual

PocBuds V30

PocBuds V30 Open-Ear Headphones User Manual

Model: V30

INTRODUCTION

Thank you for choosing PocBuds V30 Open-Ear Headphones. These wireless earbuds are designed to provide a comfortable listening experience with an open-ear design, ensuring awareness of your surroundings while enjoying high-quality audio. This manual provides detailed instructions for setup, operation, and maintenance to help you get the most out of your device.

WHAT'S IN THE BOX

- PocBuds V30 Open-Ear Headphones (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

PRODUCT OVERVIEW

The PocBuds V30 headphones feature an innovative design focused on comfort and sound quality.

Design and Comfort

The V30 earbuds are inspired by a clamshell design, featuring an electroplated finish for a refined look. The charging case is compact and lightweight, weighing only 56g (2 ounces), making it highly portable.

Clam Shell Magnetic Design



Image: The PocBuds V30 charging case, open to reveal the earbuds, highlighting its clamshell design and magnetic closure. Each V30 earbud weighs only 6g (0.2 oz), providing an ultralight experience for extended wear. The ear hooks are crafted from soft, flexible silicone, designed to ensure comfort even when wearing glasses or cycling goggles.

Weightless Wear Secure Comfort



Skin-Friendly Silicone
Material



Flexible Memory Wire



Electroplated Finish



Image: A person wearing the PocBuds V30 headphones, illustrating their secure and comfortable fit around the ear.

Audio Quality and Calls

Equipped with 11*15mm dynamic drivers, the V30 Bluetooth earbuds deliver rich audio details and clear vocals. The built-in HD microphone ensures accurate voice capture for clear, noise-free calls.

Open Case Auto-Connect




Image: A visual representation of the earbuds' internal sound unit, emphasizing the 11x15mm dynamic drivers for enhanced audio.

SETUP INSTRUCTIONS

Initial Pairing

1. Ensure your PocBuds V30 earbuds are charged.

2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
4. Search for available devices and select "V30" from the list.
5. Once connected, you will hear an audio prompt, and the device will show "Connected."



Image: A smartphone displaying its Bluetooth settings, showing the 'V30' earbuds successfully connected, illustrating the auto-connect feature.

Automatic Reconnection

After the initial pairing, simply open the charging case, and the earbuds will automatically connect to the last paired device, provided Bluetooth is enabled on your device and it is within range.

OPERATING INSTRUCTIONS

The PocBuds V30 earbuds utilize touch controls for various functions.

Touch Controls

- **Play/Pause:** Single tap on either earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Volume Up:** Press and hold the right earbud.
- **Volume Down:** Press and hold the left earbud.

CHARGING

The PocBuds V30 offers extended playtime with its charging case.

Battery Life

- Up to 6 hours of playtime on a single charge.
- Up to 60 hours of total playtime with the charging case.



Image: The earbuds and their charging case, visually representing the impressive battery life of 6 hours per single charge and 60 hours total with the case.

Charging the Earbuds and Case

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the charging case to a power source using the provided USB charging cable.
3. The LED indicator on the charging case will show the charging status.
4. Once fully charged, disconnect the charging cable.

MAINTENANCE

Proper care will extend the lifespan of your PocBuds V30 headphones.

Water Resistance

The headphones have an IPX7 waterproof rating, making them resistant to sweat and rain. They are suitable for sports and outdoor activities. However, they are not designed for swimming or prolonged submersion in water.

Cleaning and Storage

- Wipe the earbuds and charging case with a soft, dry cloth regularly.
- Avoid using abrasive cleaners or solvents.
- Store the headphones in their charging case when not in use to protect them from dust and damage.
- Keep the charging contacts clean and dry.

TROUBLESHOOTING

If you encounter issues with your PocBuds V30 headphones, try the following steps:

- **No Sound:** Ensure the earbuds are connected to your device and the volume is turned up. Check if the earbuds are charged.
- **Connection Issues:** Turn off and on your device's Bluetooth. Re-pair the earbuds by following the initial pairing steps. Ensure the earbuds are within the 33-foot Bluetooth range.
- **Charging Problems:** Verify the charging cable is securely connected to both the case and the power source. Clean the charging contacts on the earbuds and case.
- **Uncomfortable Fit:** Experiment with the different ear tip sizes provided to find the most comfortable and secure fit for your ears.

SPECIFICATIONS

Feature	Detail
Model Name	V30
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth 5.4
Ear Placement	Open Ear
Water Resistance Level	IPX7 Waterproof
Control Method	Touch
Single Earbud Weight	6 g (0.2 oz)
Charging Case Weight	56 g (2 oz)
Playtime (Single Charge)	Up to 6 hours
Total Playtime (with Charging Case)	Up to 60 hours
Driver Size	11*15mm Dynamic Drivers
Manufacturer	PocBuds
Item Model Number	V30
ASIN	B0DNBHMKWN

WARRANTY AND SUPPORT

PocBuds products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official PocBuds website. Please retain your proof of purchase for warranty claims.