

yobola T9

yobola T9 Wireless Earbuds User Manual

Model: T9 | Brand: yobola

INTRODUCTION

This manual provides instructions for the yobola T9 Wireless Earbuds. These lightweight, mini wireless headphones are designed for various activities, offering deep bass, 25 hours of playtime, a built-in microphone, touch control, and IPX5 waterproof rating.

WHAT'S IN THE BOX

The yobola T9 Wireless Earbuds package includes:

- Wireless Earbuds
- Charging Case
- USB-C Cable
- User Manual



Image: yobola T9 Wireless Earbuds in their charging case.

SETUP AND FIRST USE

The yobola T9 Wireless Earbuds feature full-automatic pairing for an easy setup experience.

Initial Pairing

1. Ensure the charging case is sufficiently charged.
2. Open the charging case. The earbuds will automatically power on.
3. On your device (smartphone, laptop, etc.), enable Bluetooth.
4. Search for "T9" in the list of available Bluetooth devices.
5. Select "T9" to connect. Once connected, you will hear an audio prompt, and the earbuds are ready for use.



Image: Illustration of the automatic pairing process with a smartphone.

SUPER LIGHT WEIGHT DESIGN

Mini concealed, only 4g smaller than coin



Image: Visual guide demonstrating the simple pairing process by picking up earbuds from the case.

OPERATING INSTRUCTIONS

The yobola T9 Earbuds feature intuitive touch controls for managing your audio and calls.

Touch Controls

- **Volume Control:** Tap the left or right earbud to adjust volume (specific tap pattern not detailed in input, common is single tap for volume up/down on different earbuds or long press).
- **Play/Pause:** Single tap on either earbud.
- **Auto Power On/Off:** Earbuds automatically power on when removed from the case and off when placed back in.
- **Previous/Next Track:** Double tap or triple tap on either earbud (specific tap pattern not detailed in input).
- **Activate Voice Assistant (Siri, Google Assistant):** Long press on either earbud (specific tap pattern not detailed in input).
- **Answer/Hang Up Phone Call:** Single tap on either earbud during an incoming call.



Have it all

For volume, music tracks and phone call

Image: Diagram illustrating various touch control functions including volume, music playback, and call management.



Image: Detailed graphic showing touch control actions for volume, play/pause, power, track skipping, voice assistant, and call handling.

Battery Life and Charging

The earbuds provide 5 hours of playtime per charge, with the charging case extending total playtime to 25 hours.

To charge the earbuds, place them back into the charging case. To charge the case, connect the provided USB-C cable to the charging port on the bottom of the case and a power source.



Image: Visual representation of the earbuds' battery life and extended playtime with the charging case.

MAINTENANCE AND CARE

Water Resistance

The yobola T9 Earbuds are IPX5 water-resistant, meaning they can withstand light rain, accidental splashes, and sweat. They are not designed for submersion in water.

IPX5 WATERPROOF

WITHSTAND



Light rain



Accident splashes



Sweat



Image: Illustration of IPX5 water resistance, indicating protection from light rain, accidental splashes, and sweat.

Cleaning

Wipe the earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals.

TROUBLESHOOTING

Common Issues and Solutions

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then remove them. Check your device's Bluetooth settings to ensure "T9" is selected. If issues persist, try forgetting the device on your phone and re-pairing.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open and remove them. This often re-syncs them. Ensure both earbuds are charged.
- **No sound or low volume:** Check the volume level on both your connected device and the earbuds. Ensure the earbuds are properly seated in your ears.
- **Charging issues:** Ensure the USB-C cable is securely connected to both the case and the power source. Check

the charging indicator light on the case.

SPECIFICATIONS

Feature	Detail
Model Name	T9
Brand	yobola
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Battery Life	5 Hours (earbuds), 25 Hours (with charging case)
Water Resistance Level	IPX5 Waterproof
Control Method	Touch
Headphones Jack	USB-C
Compatible Devices	iOS/Android/Windows/Smartphone/Laptops and all devices with Bluetooth connectivity.
Item Weight	2.46 ounces
Product Dimensions	0.67 x 0.67 x 1.57 inches
Color	Pink
Noise Control	Sound Isolation
Frequency Range	20-20000hz
Impedance	32 Ohm

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please refer to the official yobola website or contact their customer service directly. Details are typically provided in the packaging or on the manufacturer's official product page.