Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOFII B0DNDVDZSR

MOFII Wireless Keyboard and Mouse User Manual

Model: B0DNDVDZSR | Brand: MOFII

Product Overview

The MOFII Wireless Keyboard and Mouse Combo offers a full-size 104-key keyboard with floating round keys and an optical mouse with adjustable sensitivity. Designed for comfort and efficiency, this combo utilizes 2.4GHz wireless technology for a stable connection. It features a number pad, 13 multimedia shortcuts, and an auto-sleep mode to conserve battery life. This set is compatible with a wide range of operating systems and devices, making it suitable for various computing needs.



Image: The MOFII Wireless Keyboard and Mouse Combo in Violet, showcasing the full-size keyboard with round keys and the compact mouse, along with the USB receiver.

Package Contents

- 1 x MOFII Wireless Keyboard
- 1 x MOFII Wireless Mouse
- 1 x USB Receiver (located inside the mouse battery compartment)
- 1 x User Manual
- *Note: AA batteries for both keyboard and mouse are not included.*

Setup Guide

1. Install Batteries

1. Open the battery compartment on the underside of the keyboard. Insert 1 AA battery (not included), ensuring correct polarity.
2. Open the battery compartment on the underside of the mouse. Insert 1 AA battery (not included), ensuring correct polarity.
3. Locate and remove the USB receiver from its storage slot within the mouse battery compartment.



Image: Close-up view of the mouse's underside, showing the battery compartment and the storage slot for the USB receiver.

2. Connect to Your Device

1. Plug the USB receiver into an available USB port on your computer (Laptop, PC, Desktop, Chromebook).
2. Turn on the keyboard and mouse using the ON/OFF switches located on their undersides.
3. Your computer should automatically detect and install the necessary drivers. No additional software is required.



Image: Diagram illustrating the 2.4G wireless connection, showing the USB receiver plugged into a laptop and the keyboard and mouse in use, highlighting the 10m/33ft working range.

Operating Instructions

Keyboard Features

- **Full-Size Layout:** 104-key design including a numeric keypad for comprehensive input.
- **Multimedia Shortcuts:** Access 13 multimedia hotkeys (F1-F12, Esc) for quick control of media playback, volume, web browsing, and email. These functions are typically accessed by pressing the **Fn** key simultaneously with the desired F-key.
- **Ergonomic Design:** The keyboard features a fixed tilt angle for comfortable typing.
- **Removable Keycaps:** The round keycaps can be removed for cleaning or customization.



Image: A user demonstrating the removable keycaps of the keyboard, with several keycaps detached, and an icon indicating ergonomic design.



Image: An overhead view of the keyboard highlighting the 13 multimedia hotkeys (F1-F12, Esc) and their respective functions for enhanced productivity.

Mouse Features

- **Adjustable DPI:** The optical mouse offers 3 sensitivity levels (800/1200/1600 DPI) for precise control. Adjust DPI by pressing the button behind the scroll wheel.
- **Silent Click:** Designed for quiet operation, reducing click noise.
- **Ergonomic Design:** Shaped to fit comfortably in your hand for extended use.



Image: Detailed view of the mouse, illustrating its adjustable DPI settings, silent click feature, and ergonomic design for comfortable use.

Auto Sleep Mode

To conserve battery power, both the keyboard and mouse will automatically enter sleep mode after 5 minutes of inactivity. To wake them up, simply click any key on the keyboard or move/click the mouse.



Image: An illustration showing the keyboard and mouse in auto-sleep mode, with text indicating that pressing any key on the keyboard or clicking the mouse will wake them up.

Maintenance

Battery Replacement

When the keyboard or mouse stops responding or experiences lag, it may be time to replace the batteries. Follow the steps in the "Setup Guide" to open the battery compartments and replace the AA batteries.

Cleaning

- Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- To clean under the keycaps, gently remove them as shown in the "Operating Instructions" section and use compressed air or a small brush to clear debris.

Troubleshooting

- **No Response from Keyboard/Mouse:**
  - Ensure both devices are turned ON.
  - Check battery levels and replace if necessary.
  - Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
  - Move the keyboard and mouse closer to the USB receiver to ensure they are within the 33ft operating range.
- **Lag or Intermittent Connection:**
  - Interference from other wireless devices (e.g., Wi-Fi routers, other wireless peripherals) can affect performance. Try moving the receiver or devices away from potential sources of interference.
  - Ensure there are no large metal objects between the devices and the receiver.
- **Multimedia Keys Not Working (especially on Mac):**
  - While compatible with various OS, full multimedia shortcut functionality may be optimized for Windows. Some functions might not be fully compatible with macOS or Linux without additional software or system settings adjustments.

Specifications

Brand	MOFII
Model	B0DNDVDZSR
Color	Violet
Connectivity Technology	2.4GHz Wireless (USB Receiver)
Keyboard Layout	104-key Full Size with Numeric Pad
Mouse DPI Levels	800 / 1200 / 1600
Operating Range	Up to 33 feet (10 meters)
Power Source	1 x AA Battery (Keyboard), 1 x AA Battery (Mouse)
Auto Sleep Mode	After 5 minutes of inactivity
Compatible Devices	Laptop, PC, Desktop, Chromebook
Compatible OS	Windows 7/8/10/11/XP/Vista, Linux, Chrome
Item Weight	3.2 ounces (Mouse)
Package Dimensions	17.95 x 5.59 x 2.83 inches



Image: Detailed diagram showing the dimensions of both the MOFII wireless keyboard and mouse, including length, width, and height measurements.

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your product or visit the official MOFII website. You may also contact MOFII customer service directly for assistance with product inquiries, troubleshooting, or warranty claims.

Protection plans may be available for purchase separately to extend coverage beyond the standard manufacturer's warranty. Please check with your retailer for details on available protection plans.

© 2025 MOFII. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNDVDZSR

More documents and user manuals: **https://manuals.plus/**