

Vormooi V71

Vormooi V71 Digital Voice Recorder User Manual

Model: V71

1. INTRODUCTION

Thank you for choosing the Vormooi V71 Digital Voice Recorder. This device is designed for high-quality audio recording, offering extensive storage, long battery life, and intuitive operation. Please read this manual carefully to understand its features and ensure optimal performance.



Figure 1: Vormooi V71 Digital Voice Recorder with accessories.

2. PRODUCT OVERVIEW

2.1. What's in the Box

- 1x Vormooi V71 Digital Voice Recorder
- 1x 3.5mm External Microphone
- 1x USB-C Data Cable
- 1x 64GB TF Memory Card (pre-installed)
- 1x 3.5mm Transcription Cable
- 1x Lanyard
- 1x User Manual



Figure 2: Package contents of the Vormooi V71 recorder.

2.2. Device Layout and Controls

Familiarize yourself with the buttons and ports on your Vormooi V71 recorder:



Figure 3: Labeled components of the Vormooi V71 recorder.

- **USB-C Port:** For charging and data transfer.

- **Lock/Unlock Switch:** Prevents accidental button presses. Slide up to lock, down to unlock.
- **Previous / Fast Rewind Button:** Navigate backward or fast rewind during playback.
- **TF Card Slot:** For inserting a microSD (TF) card to expand storage.
- **Menu / Settings Button:** Access device settings and menu options.
- **Power / Play / Pause / OK Button:** Long press to power on/off, short press to play/pause or confirm selections.
- **3.5mm Jack:** For connecting headphones or the external microphone.
- **Record / Save Switch:** Slide up to start recording, slide down to save the recording.
- **Volume +/- Buttons:** Adjust playback volume.
- **Next / Fast Forward Button:** Navigate forward or fast forward during playback.
- **Back / Delete Files Button:** Go back in menus or delete selected files.

3. SETUP

3.1. Initial Charging

Before first use, fully charge the device using the provided USB-C cable connected to a computer or a compatible USB power adapter. A full charge takes approximately 2 hours and provides up to 110 hours of continuous recording at 512kbps.



Figure 4: The recorder's display showing battery status and recording time.

3.2. Memory Card

The Vormooi V71 comes with 32GB of built-in memory and a pre-installed 64GB TF card, providing a total of 96GB storage. This allows for approximately 7000 hours of recording at 32kbps. The device supports TF cards up to 128GB. If using an additional TF card, it must be formatted within the recorder for proper functionality.



Figure 5: Illustration of the recorder's 96GB storage capacity.

4. OPERATING INSTRUCTIONS

4.1. Basic Recording

To start recording, simply slide the red button on the right side of the recorder upwards. The device will begin recording immediately. To save the recording, slide the button downwards. This one-touch operation ensures you can capture audio quickly and efficiently.

360° Omni-directional 1536K Recording



Figure 6: One-touch record/save functionality.

4.2. Recording Methods

The V71 offers multiple recording options:

- **Built-in Dual Microphones:** For general recording, utilizing automatic noise reduction.
- **External Microphone:** Connect the included 3.5mm external microphone for close-range audio capture, reducing friction noise and improving clarity.
- **Line-in Recording:** Use the 3.5mm transcription cable to connect to a mobile phone, computer, or MP3 player for direct audio recording.



Figure 7: Using the external microphone for recording.

4.3. Voice Activated Recording (AVR)

Enable Voice Activated Recording (AVR) in the settings. The recorder will automatically start recording when sound is detected and pause when there is no sound or the sound level is too low. This feature helps conserve memory and battery life.

4.4. Playback

Use the built-in speaker or connect headphones to the 3.5mm jack for audio playback. Adjust the volume using the +/- buttons. The device supports variable speed playback and A-B repeat functions, which are useful for transcription or language learning.

4.5. Menu Navigation

The V71 features a 2.15-inch color screen with four main UI interfaces: Music, Recording, Folders, and Settings. Use the 'MENU' button to access options and the 'PREV'/'NEXT' buttons to navigate. The 'POWER/PLAY' button confirms selections, and 'DEL/BACK' returns to the previous screen.

4.6. Password Protection

Set a 6-digit password in the settings to protect your recordings and privacy. Once enabled, the password will be required to access the device or connect it to a computer.

5. FILE MANAGEMENT

5.1. Transferring Files to PC

Connect the recorder to your computer using the USB-C cable. The device will appear as a removable disk, allowing you to easily transfer recording files to your PC. Recordings are automatically named with the date and time for easy organization.

5.2. Deleting Files

You can delete files directly from the device using the 'DEL/BACK' button during playback or within the file management menu. The device supports one-click deletion for convenience.

6. MAINTENANCE

To ensure the longevity of your Vormooi V71 recorder:

- Keep the device dry and away from extreme temperatures.

- Clean the screen and body with a soft, dry cloth. Avoid abrasive cleaners.
- Avoid dropping the device or subjecting it to strong impacts.
- Charge the battery regularly, even if not in frequent use, to maintain battery health.

7. TROUBLESHOOTING

If you encounter issues with your Vormooi V71, consider the following:

- **Device not turning on:** Ensure the battery is charged. Connect to a power source and try again.
- **Cannot record:** Check if the 'Record/Save' switch is in the correct position. Ensure there is sufficient storage space. Verify the microphone input setting (internal, external, line-in) is correct.
- **Poor audio quality:** Check recording bitrate settings. Ensure the microphone is not obstructed. Reduce background noise in the recording environment.
- **Device unresponsive:** Try performing a soft reset by long-pressing the power button. If the issue persists, you may consider restoring factory settings (note: this will not delete files).
- **Formatting TF card:** If you insert a new TF card and it's not recognized, format it directly on the device via the System Settings menu. This ensures compatibility.

8. SPECIFICATIONS

Brand	Vormooi
Model	V71
Dimensions	10 x 3.9 x 1.26 cm
Weight	98 g
Memory Capacity	96 GB (32GB internal + 64GB TF card)
Screen Size	2.15 inches
Battery Life	Up to 110 hours (at 512kbps)
Recording Formats	MP3, WAV (PCM 32-1536Kbps)
Music Formats	MP3, WMA, WAV, FLAC, APE, OGG
Interface	USB-C
Compatible Devices	PC, MP3 Player, Smartphone

9. WARRANTY AND SUPPORT

Vormooi offers comprehensive after-sales support for your product:

- **2-Year Warranty:** If the device fails due to non-human factors within 2 years of purchase, please contact Vormooi for a replacement or refund.
- **Technical Support:** Lifetime technical support is available.
- **Response Time:** Expect a response to inquiries within 24 hours.

For support, please contact us via Amazon's station letter or the after-sales email provided with your purchase. We appreciate your support and understanding.

Related Documents - V71

Digitale Diktiergeräte  Benutzerhandbuch - V71(DE) Bitte lesen Sie sorgfältig, bevor Sie es verwenden, die meisten Probleme können vermieden werden! Die Kundendienst-E-Mail lautet: Vormann@IAS.com	Benutzerhandbuch V71: Digitale Diktiergeräte - Anleitung und Spezifikationen Umfassendes Benutzerhandbuch für das digitale Diktiergerät V71 von Chongqing Zini E-commerce Co. Enthält Anleitungen zur Bedienung, Aufnahmeeinstellungen, Systemkonfiguration und technische Spezifikationen.
Registratore Vocale  V15(T) MANUALE D'ISTRUZIONI	V15 Registratore Vocale Manuale d'Istruzioni Manuale d'istruzioni completo per il registratore vocale V15, che copre la configurazione iniziale, la registrazione, la riproduzione e la risoluzione dei problemi.
Digitale Diktiergeräte  Benutzerhandbuch - V71(DE) Bitte lesen Sie sorgfältig, bevor Sie es verwenden, die meisten Probleme können vermieden werden! Die Kundendienst-E-Mail lautet: Vormann@IAS.com	Benutzerhandbuch V71: Digitale Diktiergeräte - Anleitung und Spezifikationen Umfassendes Benutzerhandbuch für das digitale Diktiergerät V71 von Chongqing Zini E-commerce Co. Enthält Anleitungen zur Bedienung, Aufnahmeeinstellungen, Systemkonfiguration und technische Spezifikationen.
 Roland V71 DRUM SOUND MODULE Advanced Drum Synthesis and Performance	Roland V71 Drum Sound Module: Reference Manual for Advanced Drum Synthesis and Performance This comprehensive reference manual guides users through the capabilities of the Roland V71 Drum Sound Module. Designed for musicians and producers, the V71 offers advanced sound creation, extensive customization options, and versatile performance features for both studio and live applications.
Registratore Vocale  V15(T) MANUALE D'ISTRUZIONI	V15 Registratore Vocale Manuale d'Istruzioni Manuale d'istruzioni completo per il registratore vocale V15, che copre la configurazione iniziale, la registrazione, la riproduzione e la risoluzione dei problemi.
 SHEARWATER Shearwater Peregrine 固件版本 V89 发布说明	Shearwater Peregrine V89 Firmware Release Notes Detailed release notes for Shearwater Peregrine firmware version V89, documenting all updates, fixes, and improvements across various firmware versions from V89 down to V29.



[pdf]

docId 4EF0B0768D992598A244EC1DA6D434E5 Administrator Manuale utente 96GB Registratore Vocale Digitale 110 ore Audio Professionale con 2 15 Schermo Colori Microfono Esterno Vormooi MP3 Portatile Attivazione per Lezioni Riunioni Amazon it Cancelleria e prodotti ufficio A1aMgiMmpgL ref dp product quick view m media amazon images I |||

Registratore Vocale Manuale d uso - **V71** IT Si prega di leggere attentamente prima dell uso, la maggior parte dei problemi pu essere evitata L e-mail post-vendita Vormooi 163.com Registratore Vocale Produttore: Chongqing Zini E-commerce Co. Indirizzo: 30-1, No.1, Annex 1, No.88 Shiranpan, Shapin...

lang:it score:30 filesize: 1.67 M page_count: 47 document date: 2024-11-19



[Benutzerhandbuch V71: Digitale Diktiergeräte - Anleitung und Spezifikationen](#)

Umfassendes Benutzerhandbuch für das digitale Diktiergerät V71 von Chongqing Zini E-commerce Co. Enthält Anleitungen zur Bedienung, Aufnahmeeinstellungen, Systemkonfiguration und technische Spezifikationen.

lang:de score:25 filesize: 1.66 M page_count: 48 document date: 2024-11-19



[pdf]

docId DAB25778337F6C5BC8E8513CBAB3E8AE Administrator Manuel de l utilisateur 96GB Dictaphone 110H Enregistreur Vocal Numérique avec Micro Externe 2 15 Écran Couleur Audio MP3 Activation Vocale Vormooi Voix Lecture pour Reunions Classes Amazon fr Fournitures bureau A1101g5TfKL ref dp product quick view m media amazon images I |||

Enregistreur Vocal Numrique Manuel de l utilisateur - **V71** FR Veuillez lire attentivement avant de l utiliser, la plupart des problmes peuvent tre vits L adresse lectronique du service aprs-vente est la suivante Vormooi 163.com Enregistreur Vocal Numrique Fabricant: Chongqing Zini E-commerce Co....

lang:fr score:24 filesize: 1.73 M page_count: 47 document date: 2024-11-19

