

[Manuals.plus](#) /

› [Zerodis](#) /

› Zerodis Curved Stitch Needle Plate Instruction Manual

Zerodis Zerodisgyqdsi7o16

Zerodis Curved Stitch Needle Plate Instruction Manual

Model: Zerodisgyqdsi7o16 | Brand: Zerodis

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Zerodis Curved Stitch Needle Plate. Please read this manual thoroughly before use to ensure proper function and longevity of the product.

2. PRODUCT OVERVIEW

The Zerodis Curved Stitch Needle Plate is a high-quality replacement needle plate designed for specific Juki sewing machine models. It is crafted from durable materials to ensure stable and precise sewing results.

Key Features:

- **Strong Compatibility:** Suitable for Juki HZL 353, 355, 357, 358, 359, 8032MC, 8206 VS, 380AT.
- **Premium Materials:** Constructed from Q235 carbon steel and plastic for durability and resistance to high-strength sewing operations.
- **Transparent Cover Plate:** Allows clear observation of the sewing process and needle movement, enhancing efficiency and accuracy.
- **Easy Installation:** Designed for straightforward replacement and maintenance.
- **Enhanced Sewing Experience:** Contributes to stable and efficient sewing operations.

Product Components:



Figure 2.1: Top view of the needle plate, showing the main surface and the transparent cover for bobbin access.



Figure 2.2: Angled view of the needle plate, highlighting its metallic finish and integrated transparent section.




Figure 2.3: Underside view of the needle plate, showing the black plastic components and screw points for attachment.



Figure 2.4: Top view of the needle plate with the transparent cover slightly open, revealing the bobbin area.



Figure 2.5: Close-up view of the transparent cover and its sliding mechanism, designed for easy access.



Figure 2.6: Another angled perspective of the needle plate, showing the feed dog slots and needle opening.




Figure 2.7: The needle plate with approximate dimensions (8.2cm x 8cm) indicated, providing scale.



Figure 2.8: Detailed underside view, showing the mounting brackets and screw holes for secure attachment to the sewing machine.



Figure 2.9: Close-up of a small metallic detail on the transparent cover, indicating a latch or hinge point.

3. SETUP AND INSTALLATION

The needle plate is designed for easy installation. Follow these steps to replace or install the needle plate on your compatible Juki sewing machine:

1. **Preparation:** Ensure your sewing machine is turned off and unplugged from the power source for safety.
2. **Access the Needle Plate Area:** Depending on your Juki model, you may need to open a cover or remove existing components to access the needle plate.
3. **Remove Old Needle Plate (if applicable):** If replacing an old needle plate, carefully unscrew any retaining screws and lift the old plate away. Keep screws in a safe place.
4. **Position the New Needle Plate:** Align the new Curved Stitch Needle Plate with the mounting holes on your sewing machine. Ensure the feed dog slots and needle opening are correctly oriented.
5. **Secure the Needle Plate:** Use the appropriate screws to firmly attach the new needle plate. Do not overtighten.
6. **Verify Installation:** Gently test the movement of the feed dogs and ensure the transparent cover opens and closes smoothly.
7. **Reconnect Power:** Once installed, you may reconnect your sewing machine to the power source.

Note: Refer to your specific Juki sewing machine's user manual for detailed instructions on accessing and replacing the needle plate if you encounter difficulties.

4. OPERATING INSTRUCTIONS

The Curved Stitch Needle Plate functions as a standard needle plate, providing a stable surface for fabric movement during sewing. Its transparent cover offers a unique advantage for monitoring the sewing process.

Using the Transparent Cover:

- The transparent cover allows for direct observation of the bobbin area and needle movement trajectory.
- This feature is particularly useful for:
 - Monitoring bobbin thread levels.
 - Troubleshooting thread jams or skipped stitches by observing the needle and bobbin interaction.
 - Ensuring accurate stitch formation.
- To access the bobbin, slide the transparent cover open as indicated by the arrow on the plate.

No special operation is required for the needle plate itself beyond its proper installation. Continue to operate your sewing machine as per its original manufacturer's instructions.

5. MAINTENANCE

Regular maintenance of your needle plate ensures optimal sewing performance and extends its lifespan. The Q235 carbon steel and plastic construction are designed for durability, but proper care is still essential.

Cleaning:

- **Lint and Dust Removal:** Frequently remove lint, dust, and thread scraps that accumulate under and around the needle plate. Use a small brush or vacuum cleaner attachment.
- **Surface Cleaning:** Wipe the surface of the needle plate with a soft, dry cloth. For stubborn residue, a slightly damp cloth can be used, followed immediately by drying.
- **Transparent Cover:** Keep the transparent cover clean to maintain visibility. Avoid abrasive cleaners that could scratch the plastic.

Inspection:

- Periodically inspect the needle plate for any signs of wear, such as nicks, burrs, or scratches, especially around the needle hole and feed dog slots. These can snag fabric or affect stitch quality.

- Ensure the transparent cover slides smoothly and securely.

Note: Always turn off and unplug your sewing machine before performing any cleaning or maintenance.

6. TROUBLESHOOTING

This section addresses common issues that may arise related to the needle plate. For general sewing machine issues, consult your sewing machine's original manual.

Problem	Possible Cause	Solution
Fabric snagging on needle plate	Burrs or rough spots on the needle plate surface, especially around the needle hole or feed dog slots.	Inspect the needle plate for damage. If minor, gently smooth with very fine sandpaper (use extreme caution). If significant, replacement may be necessary.
Transparent cover not sliding smoothly	Accumulation of lint or debris in the sliding mechanism.	Clean the tracks of the transparent cover thoroughly with a small brush or compressed air.
Needle hitting the needle plate	Incorrect needle installation, bent needle, or needle plate not properly secured.	Ensure the needle is correctly inserted and not bent. Verify the needle plate is securely fastened and aligned.

7. SPECIFICATIONS

Attribute	Detail
Product Name	Curved Stitch Needle Plate
Model Number	Zerodisgyqdsi7o16
Brand	Zerodis
Material	Q235 Carbon Steel, Plastic
Dimensions (Approx.)	8.2cm x 8cm (3.23in x 3.15in)
Item Weight	2.57 ounces
Compatibility	Juki HZL-353, HZL-355, HZL-357, HZL-358, HZL-359, 8032MC, 8206, VS-380AT

8. WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support for your Zerodis Curved Stitch Needle Plate, please refer to the documentation provided at the time of purchase or contact the manufacturer directly.

Manufacturer: Zerodis

Return Policy: This product typically adheres to a 30-day refund/replacement policy. Please check with your retailer for specific return terms.

For technical assistance or inquiries, please visit the official Zerodis store or contact their customer service department.

Note: Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Zerodis. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question