

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Vinsetto](#) /

› [Vinsetto Executive Massage Office Chair with Footrest \(Model 921-674V80CW\) - Instruction Manual](#)

Vinsetto 921-674V80CW

Vinsetto Executive Massage Office Chair with Footrest (Model 921-674V80CW) - Instruction Manual

INTRODUCTION

Thank you for choosing the Vinsetto Executive Massage Office Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your chair. Please read it thoroughly before use and retain it for future reference.



Image: The Vinsetto Executive Massage Office Chair in Cream White, showcasing its design and features.

SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage:

- **Assembly Required:** Ensure all parts are correctly assembled according to the instructions before use.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 265 lbs (120 kg).
- **Remote Control:** Always use the wired remote control with caution. Avoid pulling or tangling the cord.
- **Placement:** Use the chair on a stable, level surface.
- **Children and Pets:** Keep children and pets away from the chair during operation and adjustment.

SETUP AND ASSEMBLY

Assembly of this chair is required. Please refer to the detailed assembly instructions provided in the product packaging for step-by-step guidance. Ensure all components are present and undamaged before beginning assembly.

General Assembly Steps (Consult packaging for specifics):

1. Attach the casters to the chair base.
2. Insert the gas lift cylinder into the base.
3. Secure the armrests to the seat cushion.
4. Attach the backrest to the seat cushion and armrests.
5. Mount the assembled seat and backrest onto the gas lift cylinder.
6. Connect the massage unit wiring and place the remote control in its designated pocket.

OPERATING INSTRUCTIONS

1. Massage and Heating Function

The chair features a six-point vibration massage system with five modes and lumbar heating. The remote control allows for easy adjustment of these functions.

VIBRATION MASSAGE

6 powerful vibration motors to relax your body



Image: The remote control for the massage and heating functions, illustrating the various massage points and control buttons.

- **Power Button:** Press to turn the massage and heating functions on or off.
- **Mode Button:** Cycle through five different vibration massage modes.
- **Intensity Buttons:** Adjust the intensity of the vibration massage.
- **Heat Button:** Activate or deactivate the lumbar heating function.
- **Timer Button:** Set a timer for the massage session.
- **Massage Area Buttons:** Select specific areas for massage (e.g., back, lumbar, thighs).

The remote control can be stored in the side pocket of the chair when not in use.

2. Reclining Function and Footrest

The chair offers a reclining backrest up to 135 degrees and includes a retractable footrest for extended comfort.



Image: Visual guide demonstrating the chair's reclining angles for working, watching, and relaxing.

- **Recline Lever:** Locate the recline lever on the side of the chair (typically on the right). Pull the lever upwards to unlock the backrest.
- **Adjusting Recline:** Lean back to the desired angle (up to 135°). Release the lever to lock the backrest in position.
- **Footrest Operation:** To extend the footrest, pull it out from underneath the seat. To retract, push it back until it is fully stored.



Image: A close-up view of the chair's retractable footrest in its extended position.

3. Height Adjustment

The chair's height can be adjusted to suit your desk and personal preference.

HEIGHT ADJUSTABLE



Adjustable seat height

Image: The height adjustment lever located beneath the seat, with arrows indicating the direction for raising or lowering the chair.

- **To Raise:** While seated, lift your weight slightly off the seat and pull the height adjustment lever upwards. The chair will rise. Release the lever at the desired height.
- **To Lower:** While seated, pull the height adjustment lever upwards. The chair will lower under your weight. Release the lever at the desired height.

4. Swivel and Wheels

The chair features a 360-degree swivel function and smooth-rolling casters for easy movement.

- **Swivel:** The chair seat can rotate freely 360 degrees.
- **Movement:** The casters allow the chair to be moved easily across hard floor surfaces. Ensure the path is clear of obstructions.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your Vinsetto office chair.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the microfibre fabric.
- **Casters:** Periodically check casters for hair or debris and clean as needed to ensure smooth rolling.
- **Fasteners:** Regularly inspect all screws and bolts to ensure they are tight. Retighten if necessary.
- **Electrical Components:** Keep the remote control and power cords dry and away from liquids.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder malfunction or lever not engaged correctly.	Ensure the lever is fully pulled. If the issue persists, the gas lift may need replacement.
Massage function not working.	Power cord disconnected, remote control malfunction, or unit off.	Check power connection. Ensure remote is plugged in and powered on. Try different massage modes.
Chair squeaks or wobbles.	Loose fasteners or uneven assembly.	Tighten all screws and bolts. Re-check assembly steps.
Footrest does not extend/retract smoothly.	Obstruction or mechanism issue.	Check for obstructions. Ensure the mechanism is clean and free of debris.

SPECIFICATIONS

Key specifications for the Vinsetto Executive Massage Office Chair (Model 921-674V80CW):



Image: Detailed dimensions of the chair, including width, depth, and height measurements.

Feature	Detail
Model Number	921-674V80CW
Overall Dimensions	25.5" W x 28.25" D x 43" - 46" H
Seat Dimensions	22.5" W x 17.75" D
Seat Height	21.75" - 24.75"
Backrest Height	28.75 Inches (from seat)
Arm Height	6.75 Inches (from seat)
Maximum Recline Angle	135°

Feature	Detail
Weight Capacity	265 lbs (120 kg)
Material	Microfibre (100% Polyester), Foam Fill
Special Features	6-point Vibration Massage, Lumbar Heating, Adjustable Height, Reclining, Retractable Footrest, Swivel Wheels
Color	Cream White

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Vinsetto customer service directly. Contact details can typically be found on the manufacturer's website or on the product packaging.

