Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Enabot EBO ROLA Mini 2K / ROLA Smart Cat Water Fountain

Enabot ROLA Mini 2K Pet Camera Robot & ROLA Smart Cat Water Fountain User Manual

Model: ROLA Mini 2K / ROLA Smart Cat Water Fountain

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Enabot ROLA Mini 2K Pet Camera Robot and ROLA Smart Cat Water Fountain. The ROLA Mini robot allows for remote interaction with your pets, offering 2K resolution video, two-way audio, and mobility. The ROLA Smart Cat Water Fountain ensures your pet has access to fresh, filtered water with smart monitoring features.



Image: The Enabot ROLA Mini 2K Pet Camera Robot (white and black spherical robot) and the ROLA Smart Cat Water Fountain (translucent beige water dispenser) are shown side-by-side, highlighting the complete pet care system.

Setup

ROLA Mini 2K Pet Camera Robot Setup

1. **Unboxing and Initial Charge:** Carefully remove the ROLA Mini robot from its packaging. Connect the robot to a power source using the provided magnetic USB-C charging cable. Ensure the robot is fully charged before first use.
2. **Download the ROLA App:** Search for 'ROLA App' in your device's app store and download it.
3. **Connect to Wi-Fi:** Open the ROLA App and follow the on-screen instructions to connect your ROLA Mini robot to your home's 2.4 GHz Wi-Fi network. The robot will guide you through the pairing process.
4. **Power On:** Once connected, the ROLA Mini robot will power on and be ready for use.

ROLA Smart Cat Water Fountain Setup

1. **Identify Components:** The fountain consists of a detachable water tank, a wireless pump, and a battery-operated base unit.
2. **Assembly:** Place the wireless pump securely within the detachable water tank. Ensure the 6° tilted stainless steel water tray is correctly positioned on top of the tank.
3. **Fill with Water:** Fill the detachable water tank with clean water up to the maximum fill line.

4. **Power On:** Place the assembled water tank onto the battery-operated base unit. The fountain will automatically power on.
5. **App Connection:** Connect the ROLA Smart Cat Water Fountain to the ROLA App to monitor hydration levels and settings.



Image: Contents of the ROLA Smart Cat Water Fountain box, including the fountain unit, a sponge, a filter, and a 1.5m braided USB-C charge cable. Dimensions are also indicated.

Operating Your Devices

ROLA Mini 2K Pet Camera Robot Operation

- **Remote Control:** Use the ROLA App to remotely control the robot's movement. You can navigate it around your home to interact with your pets.
- **2K Resolution Camera:** The integrated 2K camera provides clear video feed, allowing you to see your pets in detail.
- **Voice Chat:** Utilize the two-way audio feature to speak to your pets and hear their responses through the app.
- **Paw Button Push:** Your pet can press the paw button on the robot to initiate a voice call to your connected device, allowing them to 'call' you.

- **Automatic Righting:** The ROLA Mini robot is designed to automatically right itself if it gets knocked over, ensuring continuous operation.

ROLA Smart Cat Water Fountain Operation

- **Remote Hydration Check:** Monitor your cat's hydration effortlessly through the ROLA App. Check the fountain's status from anywhere.
- **Sensing Stream & Continuous Stream:** The fountain offers different modes for water dispensing, including a sensing stream that activates when your pet is near, and a continuous stream.
- **Ultra-Quiet Circulation:** The fountain operates with ultra-quiet circulation, designed not to disturb your pet's rest.



Image: The ROLA Smart Cat Water Fountain is shown next to a smartphone displaying the ROLA App interface, which provides real-time hydration data and device status.

Maintenance

ROLA Mini 2K Pet Camera Robot Maintenance

- **Cleaning:** Wipe the exterior of the robot with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

- **Battery:** The ROLA Mini features a 5000 mAh battery. Recharge as needed using the magnetic USB-C charging port.

ROLA Smart Cat Water Fountain Maintenance

- **Cleaning:** The detachable water tank and wireless pump are fully washable. The battery-operated base unit is NOT washable and should be kept dry. Regular cleaning prevents buildup and ensures fresh water.
- **Filter Replacement:** The fountain utilizes a 3-layer filtration system to remove impurities, hair, and odors. Replace the filter regularly as indicated by the app or visual inspection to maintain water quality.
- **Water Level Monitoring:** The ROLA App will alert you to low water levels, prompting you to refill the tank.
- **Low Battery Alerts:** The app will also notify you when the fountain's battery is low, indicating it's time for a recharge.




Image: The ROLA Smart Cat Water Fountain disassembled, showing the detachable water tank, wireless pump, and stainless steel tray, illustrating its easy-to-clean design. Note: The base unit is not washable.



Image: A diagram illustrating the 3-layer filtration process of the ROLA Smart Cat Water Fountain, showing non-woven fabric and activated carbon layers that remove impurities, hair, and odors.

Troubleshooting

- **Connectivity Issues:** Ensure your ROLA devices are connected to a 2.4 GHz Wi-Fi network. 5 GHz networks are not supported. Check your Wi-Fi signal strength in the app.
- **Robot Not Responding:** Verify the ROLA Mini robot is charged. If unresponsive, try restarting the robot by holding the power button or by connecting it to power.
- **Fountain Not Dispensing Water:** Check the water level in the tank. Ensure the wireless pump is correctly seated and free from obstructions.
- **App Not Updating Data:** Ensure your smartphone has a stable internet connection and the ROLA App is updated to the latest version.

Specifications

Feature	Detail
ROLA Mini Camera Resolution	2K
ROLA Mini Battery Capacity	5000 mAh
ROLA Mini Charging	Magnetic USB-C
ROLA Fountain Water Tray Angle	6° Tilted
ROLA Fountain Water Tank Material	Transparent ABS
ROLA Fountain Filtration	3-layer (Non-Woven Fabric, Activated Carbon)
Wi-Fi Compatibility	2.4 GHz only
ASIN	B0DNF5KYTN
Date First Available	November 18, 2024

Warranty and Support

For detailed warranty information, technical support, or service inquiries, please refer to the official Enabot EBO website or the product packaging. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNF5KYTN

More documents and user manuals: **https://manuals.plus/**